RO system – quick guide

One button. Four gestures. The system beeps to confirm what it heard.

1
Short press
The system starts. It may flush itself briefly first – that is normal.

2
Collect the water
After about 12 minutes you hear 3 long beeps: the water is ready.

3
Done
Take your water right away. The system runs its own post-flush shortly after.

The four gestures

● **Short**	▮▮ **Long**	▮▮▮▮ **Super-long**	●● **Double-tap**
just tap	hold 1–5 s	hold 5 s or more	2 quick taps

What the button does right now

Gesture	System is idle	System is filtering	System is flushing
● **Short**	**Make water** about 12 minutes	**Stop** clean shutdown	**Stop** cancel the flush
▮▮ **Long**	**Make a lot of water** 1 hour in one go	**Stop + save the time** see overleaf	**Stop** cancel the flush
▮▮▮▮ **Super-long**	**Long flush – 15 minutes.** Always works, whatever the system is doing. Use it after a filter change or a long standstill. No drinking water comes out during it.		
●● **Double-tap**	**Manual mode** for disinfection only, see overleaf	ignored	

What the sounds mean

1 short beep	Short press recognised
1 long beep	Long press recognised
1 very long beep	Super-long press recognised – long flush starting
2 short beeps	Double-tap recognised – manual mode
3 long beeps	**Your water is ready**
1 short + 1 long	Greeting – the system has just been switched on

Important: you never have to switch anything off or flush anything by hand. The system ends every cycle cleanly and looks after the membrane by itself. After you stop it with the button the pump keeps running for a few seconds until the pressure is released – do not disconnect anything during that time.

For rare occasions

None of this is needed day to day. Page 1 is enough for making water.

What the system does on its own

Every 8 hours
It flushes itself so that no germs can develop in the membrane. If it starts up without you touching it, that is normal.

Before filtering
If it has been idle for more than 5 minutes it runs a short pre-flush and discards the first water. The first water after a standstill is poorer – it never reaches your glass.

After filtering
About 30 seconds after your water is ready it flushes the membrane once more. You can take your water immediately.

Setting the fill quantity (“my bottle is full”)

By default the system filters for 12 minutes. If that does not match your jug or bottle, set the time yourself – no computer needed:

1. Start	Put your container underneath and **press briefly**.
2. Wait	Wait until the container holds exactly as much water as you want from now on.
3. Save	Now **press and hold** (1–5 s). The system stops **and remembers that duration** for every future short press.

The time is kept when the system is switched off (anything from 30 seconds to 1 hour is allowed) and can be set again as often as you like.

Long flush (15 minutes)

Press and hold for 5 seconds until you hear one very long beep. The system then flushes the membrane for 15 minutes. **No drinking water** comes out; the water goes to the drain.

Useful after a filter or membrane change, after a long standstill (a holiday, say), or if the water ever tastes odd. It always works – even mid-cycle – and a short press cancels it at any time.

Manual mode – for disinfection only

Manual mode exists solely for disinfection with hydrogen peroxide (H_2O_2). Quantity, soak time and order are given in the **manufacturer's handbook (AquaMichel Mini)** – **follow the handbook for those**. This page only describes what the button does.

Entering	**Double-tap** while idle (two quick short presses). You hear two short beeps.
Pump on / off	Every **short press** toggles the pump: on, off, on, off … This is how you push the quantity of water the handbook asks for through the system.
Leaving	**Press and hold**. The pump stops and everything closes cleanly. The system then behaves normally again.
Automation	While you are in manual mode the system does **not** flush on its own, so it cannot interrupt a long soak.

> **Caution:** in manual mode the membrane does not protect itself – there is no pre-flush and no post-flush. Use it only for disinfection and leave it afterwards with a long press. After disinfecting, flush the system thoroughly as described in the handbook before you drink the water again.