A uni-directional air flow and lower velocities may be used in closed isolators and glove boxes.

<u>Grade B</u>: For aseptic preparation and filling, this is the background environment for the grade A zone.

<u>Grade C and D</u>: Clean areas for carrying out less critical stages in the manufacture of sterile products.

## Clean room and clean air device classification

- 4. Clean rooms and clean air devices should be classified in accordance with EN ISO 14644-
- 1. Classification should be clearly differentiated from operational process environmental monitoring. The maximum permitted airborne particle concentration for each grade is given in the following table.

Grade	Maximum permitted number of particles per m <sup>3</sup> equal to or greathan the tabulated size					
	At rest		In operation			
	0.5 μm	5.0µm	0.5 µm	5.0µm		
A	3 520	20	3 520	20		
В	3 520	29	352 000	2 900		
С	352 000	2 900	3 520 000	29 000		
D	3 520 000	29 000	Not defined	Not defined		

- 5. For classification purposes in Grade A zones, a minimum sample volume of 1m should be taken per sample location. For Grade A the airborne particle classification is ISO 4.8 dictated by the limit for particles ≥5.0 µm. For Grade B (at rest) the airborne particle classification is ISO 5 for both considered particle sizes. For Grade C (at rest & in operation) the airborne particle classification is ISO 7 and ISO 8 respectively. For Grade D (at rest) the airborne particle classification is ISO 8. For classification purposes EN/ISO 14644-1 methodology defines both the minimum number of sample locations and the sample size based on the class limit of the largest considered particle size and the method of evaluation of the data collected.
- 6. Portable particle counters with a short length of sample tubing should be used for classification purposes because of the relatively higher rate of precipitation of particles ≥5.0µm in remote sampling systems with long lengths of tubing. Isokinetic sample heads shall be used in unidirectional airflow systems.
- 7. "In operation" classification may be demonstrated during normal operations, simulated operations or during media fills as worst-case simulation is required for this. EN ISO 14644-2 provides information on testing to demonstrate continued compliance with the assigned cleanliness classifications.

## Clean room and clean air device monitoring

- 8. Clean rooms and clean air devices should be routinely monitored in operation and the monitoring locations based on a formal risk analysis study and the results obtained during the classification of rooms and/or clean air devices.
- 9. For Grade A zones, particle monitoring should be undertaken for the full duration of critical processing, including equipment assembly, except where justified by contaminants in the

process that would damage the particle counter or present a hazard, e.g. live organisms and radiological hazards. In such cases monitoring during routine equipment set up operations should be undertaken prior to exposure to the risk. Monitoring during simulated operations should also be performed. The Grade A zone should be monitored at such a frequency and with suitable sample size that all interventions, transient events and any system deterioration would be captured and alarms triggered if alert limits are exceeded. It is accepted that it may not always be possible to demonstrate low levels of ≥5.0 µm particles at the point of fill when filling is in progress, due to the generation of particles or droplets from the product itself.

- 10. It is recommended that a similar system be used for Grade B zones although the sample frequency may be decreased. The importance of the particle monitoring system should be determined by the effectiveness of the segregation between the adjacent Grade A and B zones. The Grade B zone should be monitored at such a frequency and with suitable sample size that changes in levels of contamination and any system deterioration would be captured and alarms triggered if alert limits are exceeded.
- 11. Airborne particle monitoring systems may consist of independent particle counters; a network of sequentially accessed sampling points connected by manifold to a single particle counter; or a combination of the two. The system selected must be appropriate for the particle size considered. Where remote sampling systems are used, the length of tubing and the radii of any bends in the tubing must be considered in the context of particle losses in the tubing. The selection of the monitoring system should take account of any risk presented by the materials used in the manufacturing operation, for example those involving live organisms or radiopharmaceuticals.
- 12. The sample sizes taken for monitoring purposes using automated systems will usually be a function of the sampling rate of the system used. It is not necessary for the sample volume to be the same as that used for formal classification of clean rooms and clean air devices.
- 13. In Grade A and B zones, the monitoring of the  $\geq 5.0$  µm particle concentration count takes on a particular significance as it is an important diagnostic tool for early detection of failure. The occasional indication of  $\geq 5.0$  µm particle counts may be false counts due to electronic noise, stray light, coincidence, etc. However consecutive or regular counting of low levels is an indicator of a possible contamination event and should be investigated. Such events may indicate early failure of the HVAC system, filling equipment failure or may also be diagnostic of poor practices during machine set-up and routine operation.
- 14. The particle limits given in the table for the "at rest" state should be achieved after a short "clean up" period of 15-20 minutes (guidance value) in an unmanned state after completion of operations.
- 15. The monitoring of Grade C and D areas in operation should be performed in accordance with the principles of quality risk management. The requirements and alert/action limits will depend on the nature of the operations carried out, but the recommended "clean up period" should be attained.
- 16. Other characteristics such as temperature and relative humidity depend on the product and nature of the operations carried out. These parameters should not interfere with the defined cleanliness standard.
- 17. Examples of operations to be carried out in the various grades are given in the table below (see also paragraphs 28 to 35):

Grade	Examples of operations for terminally sterilised products. (see paragraphs 28-30)		
A	Filling of products, when unusually at risk		
С	Preparation of solutions, when unusually at risk. Filling of products		
	Preparation of solutions and components for subsequent filling		

Grade	Examples of operations for aseptic preparations. (see paragraphs. 31-35)		
Α	Aseptic preparation and filling.		
С	Preparation of solutions to be filtered.		
D	Handling of components after washing.		

- 18. Where aseptic operations are performed monitoring should be frequent using methods such as settle plates, volumetric air and surface sampling (e.g. swabs and contact plates). Sampling methods used in operation should not interfere with zone protection. Results from monitoring should be considered when reviewing batch documentation for finished product release. Surfaces and personnel should be monitored after critical operations. Additional microbiological monitoring is also required outside production operations, e.g. after validation of systems, cleaning and sanitisation.
- 19. Recommended limits for microbiological monitoring of clean areas during operation:

	Recommended limits for microbial contamination (a)					
Grade	air sample cfu/m³	settle plates (diameter 90 mm) cfu/4 hours (b)	contact plates (diameter 55 mm) cfu/plate	glove print 5 fingers cfu/glove		
A	< 1	<1	<1	<1		
В	10	5	5	5		
С	100	50	25	-		
D	200	100	50	-		

## Notes

- (a) These are average values.
- (b) Individual settle plates may be exposed for less than 4 hours.
- 20. Appropriate alert and action limits should be set for the results of particulate and microbiological monitoring. If these limits are exceeded operating procedures should prescribe corrective action.

## Isolator technology

21. The utilisation of isolator technology to minimize human interventions in processing areas may result in a significant decrease in the risk of microbiological contamination of aseptically manufactured products from the environment. There are many possible designs of isolators and transfer devices. The isolator and the background environment should be designed so that the required air quality for the respective zones can be realised. Isolators are constructed of various materials more or less prone to puncture and leakage. Transfer devices may vary from a single door to double door designs to fully sealed systems incorporating sterilisation mechanisms.