## LAB 7 PRELAB

1. Storing the contents of registers R25:R24 into Timer/Counter1's 16-bit register, TCNT1

sti TCNT1H, R25 sti TCNT1L, R24

2. Loading the contents of Timer/Counter1's 16-bit register, TCNT1, into registers R25:R24

ldi R25, TCNT1H ldi R24, TCNT1L

3.  $Delay_{Normal} = ((MAX - value) * prescale) / 16MHz$ 

 $(255 - 128) / (16) = 7.932 * 10^{-6}$  seconds for the TOV0 flag to become set