

HPE ProLiant Gen10 Servers - Secure Boot Option is Greyed Out

Table of contents

- Issue
- Environment
- Cause
- Resolution

Issue

• Secure boot option in UEFI is disabled

Environment

- Any Proliant Gen10 server
- OS independent

Cause

- Legacy boot mode does not support Secure boot option
- NVRAM corruption
- Older BIOS version can cause issue

Resolution

- Make sure, the server is running in UEFI mode and not legacy
- Update BIOS to latest version if firmware is too outdated
- Clear NVRAM
- If issue persist, then update Intelligent provisioning
- If issue remains same, then replace TPM and system board