

### Chapter 8

### Digital Design and Computer Architecture, 2nd Edition


David Money Harris and Sarah L. Harris





# Chapter 8 :: Topics

- Introduction
- Memory System Performance Analysis
- Caches
- Virtual Memory
- Memory-Mapped I/O
- Summary






# NEMOR

### Introduction

- Computer performance depends on:
  - Processor performance
  - Memory system performance

### **Memory Interface**








### Processor-Memory Gap

In prior chapters, assumed access memory in 1 clock cycle – but hasn't been true since the 1980's







# Memory System Challenge

Make memory system appear as fast as processor

Use hierarchy of memories

• Ideal memory:

- Fast
- Cheap (inexpensive)
- Large (capacity)


But can only choose two!







## Memory Hierarchy







## Locality

Exploit locality to make memory accesses fast

- Temporal Locality:
  - Locality in time
  - If data used recently, likely to use it again soon
  - How to exploit: keep recently accessed data in higher levels of memory hierarchy
- Spatial Locality:
  - Locality in space
  - If data used recently, likely to use nearby data soon
  - How to exploit: when access data, bring nearby data into higher levels of memory hierarchy too



### Memory Performance

- **Hit:** data found in that level of memory hierarchy
- Miss: data not found (must go to next level)

Hit Rate = # hits / # memory accesses

= 1 - Miss Rate

Miss Rate = # misses / # memory accesses

= 1 - Hit Rate

• Average memory access time (AMAT): average time for processor to access data

$$\mathbf{AMAT} = t_{\text{cache}} + MR_{\text{cache}}[t_{MM} + MR_{MM}(t_{VM})]$$





- A program has 2,000 loads and stores
- 1,250 of these data values in cache
- Rest supplied by other levels of memory hierarchy
- What are the hit and miss rates for the cache?





- A program has 2,000 loads and stores
- 1,250 of these data values in cache
- Rest supplied by other levels of memory hierarchy
- What are the hit and miss rates for the cache?

Hit Rate = 1250/2000 = 0.625

**Miss Rate** = 750/2000 = 0.375 = 1 - Hit Rate





- Suppose processor has 2 levels of hierarchy: cache and main memory
- $t_{\text{cache}} = 1$  cycle,  $t_{MM} = 100$  cycles
- What is the AMAT of the program from Example 1?





- Suppose processor has 2 levels of hierarchy: cache and main memory
- $t_{\text{cache}} = 1$  cycle,  $t_{MM} = 100$  cycles
- What is the AMAT of the program from Example 1?

**AMAT** = 
$$t_{\text{cache}} + MR_{\text{cache}}(t_{MM})$$
  
=  $[1 + 0.375(100)]$  cycles  
= **38.5 cycles**





### Gene Amdahl, 1922-

- Amdahl's Law: the effort spent increasing the performance of a subsystem is wasted unless the subsystem affects a large percentage of overall performance
- Co-founded 3 companies, including one called Amdahl Corporation in 1970







### Cache

- Highest level in memory hierarchy
- Fast (typically ~ 1 cycle access time)
- Ideally supplies most data to processor
- Usually holds most recently accessed data





### Cache Design Questions

- What data is held in the cache?
- How is data found?
- What data is replaced?

Focus on data loads, but stores follow same principles





### What data is held in the cache?

- Ideally, cache anticipates needed data and puts it in cache
- But impossible to predict future
- Use past to predict future temporal and spatial locality:
  - Temporal locality: copy newly accessed data into cache
  - Spatial locality: copy neighboring data into cache too



# Cache Terminology

- Capacity (*C*):
  - number of data bytes in cache
- Block size (b):
  - bytes of data brought into cache at once
- Number of blocks (B = C/b):
  - number of blocks in cache: B = C/b
- Degree of associativity (N):
  - number of blocks in a set
- Number of sets (S = B/N):
  - each memory address maps to exactly one cache set



### How is data found?

- Cache organized into S sets
- Each memory address maps to exactly one set
- Caches categorized by # of blocks in a set:
  - Direct mapped: 1 block per set
  - N-way set associative: N blocks per set
  - -Fully associative: all cache blocks in 1 set
- Examine each organization for a cache with:
  - Capacity (C = 8 words)
  - Block size (b = 1 word)





### Example Cache Parameters

- C = 8 words (capacity)
- b = 1 word (block size)
- So, B = 8 (# of blocks)

Ridiculously small, but will illustrate organizations



# SYSTEMS MEMORY

### Direct Mapped Cache



11...111**110**11...111**110**11...111**101**11...111**100**

11...111**011**00

11...111**010**00

11...111**001**00

11...111**000**00

•

00...001**001**00

00...00100000

00...000**111**00

00...000**110**00

00...000**101**00


00...000**100**00

00...000**011**00

00...000**010**00

00...000**001**00

00...000**000**00



Set Number

7 (111)

6 (**110**)

5 (101)

4 (100)

3 (011)

2 (010)

1 (001)

0 (000)

2<sup>30</sup> Word Main Memory

mem[0x00...04]


mem[0x00...00]

2<sup>3</sup> Word Cache Chapter 8 <20>



# SYSTEMS NEMORY

### Direct Mapped Cache Hardware





# loop: done:

### Direct Mapped Cache Performance


001

3

Byte

00

Set Offset



	_		
V	Tag	Data	
0			Set 7 (111)
0			Set 6 (110)
0			Set 5 (101)
0			Set 4 (100)
1	0000	mem[0x000C]	Set 3 (011)
1	0000	mem[0x0008]	Set 2 (010)
1	0000	mem[0x0004]	Set 1 (001)
0			Set 0 (000)

Miss Rate = ?



# NEMORY

### Direct Mapped Cache Performance

			Byte
Memory	Tag		Offset
Address	0000	001	00
Address		3	

### # MIPS assembly code

145 thb

	addi	$\gamma \cup \sigma$	$\mathcal{A}_{\mathcal{A}}$
loop:	beq	\$t0,	\$0, done
	lw	\$t1,	0x4(\$0)
	lw	\$t2,	0xC(\$0)
	lw	\$t3,	0x8(\$0)
	addi	\$t0,	\$t0, -1
	j	loop	

 $\Diamond \cap$ 

_1	_
done	•
aonc	•

	V	Tag	Data	
	0			Set 7
	0			Set 6
	0			Set 5
	0			Set 4
	1	0000	mem[0x000C]	Set 3
	1	0000	mem[0x0008]	Set 2
>	1	0000	mem[0x0004]	Set 1
	0			Set 0

# **Temporal Locality Compulsory Misses**



(111)

(110)

(101) (100)


(011) (010)

(001)


(000)



### Direct Mapped Cache: Conflict




Miss Rate = ?





### Direct Mapped Cache: Conflict



### MIPS assembly code

	addi	\$t0,	<b>\$0,</b> 5
loop:	beq	\$t0,	\$0, done
	lw	\$t1,	0x4(\$0)
	lw	\$t2,	0x24(\$0)
	addi	\$t0,	\$t0, -1

loop

done:

JUC			
٧	Tag	Data	
0			Set 7 (111)
0			Set 6 (110)
0			Set 5 (101)
0			Set 4 (100)
0			Set 3 (011)
0			Set 2 (010)
1	0000	mem[0x0004]	Set 1 (001)
0			Set 0 (000)
-	•		-


Miss Rate = 10/10= 100%

**Conflict Misses** 



# SYSTEMS NEMORY

### N-Way Set Associative Cache





### N-Way Set Associative Performance

### # MIPS assembly code

```
addi $t0, $0, 5

loop: beq $t0, $0, done
 lw $t1, 0x4($0)
 lw $t2, 0x24($0)
 addi $t0, $t0, -1
 j loop
```

Miss Rate = ?

done:

Wa	ay	1	
	_		

'	W	ay	0

V	Tag	Data	V Tag	Data	
0			0		Set Set Set Set
0			0		Set
0			0		Set
0			0		Set





### N-Way Set Associative Performance

### # MIPS assembly code

addi \$t0, \$0, 5

loop: beq \$t0, \$0, done
 lw \$t1, 0x4(\$0)
 lw \$t2, 0x24(\$0)
 addi \$t0, \$t0, -1
 j loop

Miss Rate = 2/10 = 20%

Associativity reduces conflict misses

done:

Way 1 Way 0 Tag Data Data Tag Set 3 0 0 Set 2 0 0 Set 1 mem[0x00...24] mem[0x00...04] 00...10 00...00 Set 0 0 0





## Fully Associative Cache

V Tag Data V Tag Data



Reduces conflict misses


**Expensive to build** 






# Spatial Locality?

- Increase block size:
  - Block size, b = 4 words
  - -C = 8 words
  - Direct mapped (1 block per set)
  - Number of blocks, B = 2 (C/b = 8/4 = 2)



# SYSTEMS MEMORY

# Cache with Larger Block Size





### Direct Mapped Cache Performance

done:





### Direct Mapped Cache Performance

```
addi $t0, $0, 5

loop: beq $t0, $0, done

lw $t1, 0x4($0)

lw $t2, 0xC($0)

lw $t3, 0x8($0)


addi $t0, $t0, -1

j loop
```

Miss Rate = 1/15 = 6.67%

Larger blocks reduce compulsory misses through spatial locality

### done:





### Cache Organization Recap

- Capacity: C
- Block size: b
- Number of blocks in cache: B = C/b
- Number of blocks in a set: N
- Number of sets: S = B/N

Organization	Number of Ways (N)	Number of Sets $(S = B/N)$
Direct Mapped	1	B
N-Way Set Associative	1 < N < B	B/N
Fully Associative	В	1





### Capacity Misses

- Cache is too small to hold all data of interest at once
- If cache full: program accesses data X & evicts data Y
- Capacity miss when access Y again
- How to choose Y to minimize chance of needing it again?
- Least recently used (LRU) replacement: the least recently used block in a set evicted





### Types of Misses

- Compulsory: first time data accessed
- Capacity: cache too small to hold all data of interest
- Conflict: data of interest maps to same location in cache

Miss penalty: time it takes to retrieve a block from lower level of hierarchy





#### LRU Replacement

#### # MIPS assembly

```
lw $t0, 0x04($0)
lw $t1, 0x24($0)
lw $t2, 0x54($0)
```

		Way 1			Way 0			1
٧	U	Tag	Data	V	Tag	Dat	a	l
0	0	-		0				Set 3 (11)
0	0			0				Set 2 (10)
0	0			0				Set 1 (01)
0	0			0				Set 0 (00)



#### LRU Replacement

#### # MIPS assembly

```
lw $t0, 0x04($0)
lw $t1, 0x24($0)
lw $t2, 0x54($0)
```

		Way 1			١	Nay 0	1
٧	U	Tag	Data	V	Tag	Data	l
0	0			0			Set 3 (11)
0	0			0			Set 2 (10)
1	0	00010	mem[0x0024]	1	00000	mem[0x0004]	Set 1 (01)
0	0			0			Set 0 (00)

(	a	)
١,		,

		Way 1			\		
V	U	Tag	Data	٧	Tag	Data	l
0	0			0			Set 3 (11)
0	0			0			Set 2 (10)
1	1	00010	mem[0x0024]	1	00101	mem[0x0054]	Set 1 (01)
0	0			0			Set 0 (00)






### Cache Summary

- What data is held in the cache?
  - Recently used data (temporal locality)
  - Nearby data (spatial locality)
- How is data found?
  - Set is determined by address of data
  - Word within block also determined by address
  - In associative caches, data could be in one of several ways
- What data is replaced?
  - Least-recently used way in the set




# MEMORY

#### Miss Rate Trends





#### Miss Rate Trends



- Bigger blocks reduce compulsory misses
- Bigger blocks increase conflict misses






#### Multilevel Caches

- Larger caches have lower miss rates, longer access times
- Expand memory hierarchy to multiple levels of caches
- Level 1: small and fast (e.g. 16 KB, 1 cycle)
- Level 2: larger and slower (e.g. 256 KB, 2-6 cycles)
- Most modern PCs have L1, L2, and L3 cache



# MEMORY & KO SYSTEMS

#### Intel Pentium III Die








### Virtual Memory

- Gives the illusion of bigger memory
- Main memory (DRAM) acts as cache for hard disk





#### Memory Hierarchy




- Physical Memory: DRAM (Main Memory)
- Virtual Memory: Hard drive
  - Slow, Large, Cheap



# SYSTEMS MEMORY

#### Hard Disk



Takes milliseconds to seek correct location on disk





#### Virtual Memory

#### Virtual addresses

- Programs use virtual addresses
- Entire virtual address space stored on a hard drive
- Subset of virtual address data in DRAM
- CPU translates virtual addresses into *physical addresses* (DRAM addresses)
- Data not in DRAM fetched from hard drive

#### Memory Protection

- Each program has own virtual to physical mapping
- Two programs can use same virtual address for different data
- Programs don't need to be aware others are running
- One program (or virus) can't corrupt memory used by another





### Cache/Virtual Memory Analogues

Cache	Virtual Memory
Block	Page
Block Size	Page Size
Block Offset	Page Offset
Miss	Page Fault
Tag	Virtual Page Number

Physical memory acts as cache for virtual memory






## Virtual Memory Definitions

- Page size: amount of memory transferred from hard disk to DRAM at once
- Address translation: determining physical address from virtual address
- Page table: lookup table used to translate virtual addresses to physical addresses





#### Virtual & Physical Addresses




Most accesses hit in physical memory
But programs have the large capacity of virtual memory





#### Address Translation

#### Virtual Address



© 2007 Elsevier, Inc. All rights reserved





#### Virtual Memory Example

#### System:

- Virtual memory size:  $2 \text{ GB} = 2^{31} \text{ bytes}$
- Physical memory size:  $128 \text{ MB} = 2^{27} \text{ bytes}$
- Page size:  $4 \text{ KB} = 2^{12} \text{ bytes}$



#### Virtual Memory Example

#### System:

- Virtual memory size:  $2 GB = 2^{31}$  bytes
- Physical memory size:  $128 \text{ MB} = 2^{27} \text{ bytes}$
- Page size:  $4 \text{ KB} = 2^{12} \text{ bytes}$

#### Organization:

- Virtual address: 31 bits
- Physical address: 27 bits
- Page offset: 12 bits
- # Virtual pages =  $2^{31}/2^{12} = 2^{19}$  (VPN = 19 bits)
- # Physical pages =  $2^{27}/2^{12} = 2^{15}$  (PPN = 15 bits)



# EMS

#### Virtual Memory Example

- 19-bit virtual page numbers
- 15-bit physical page numbers

Physical Page
Number Physical Addresses

7FF 0x7FFF000 - 0x7FFFFFF
7FF 0x7FFE000 - 0x7FFFFFF

0001 0x0001000 - 0x0001FFF

0000 0x0000000 - 0x0000FFF

Physical Memory

Virtual Addresses

 0x7FFFF000 - 0x7FFFFFF
 7FFF

 0x7FFFE000 - 0x7FFFFF
 7FFF

 0x7FFFD000 - 0x7FFFDFF
 7FFFD

 0x7FFFB000 - 0x7FFFBFF
 7FFFB

 0x7FFFA000 - 0x7FFFAFF
 7FFFA

 0x7FFF9000 - 0x7FFF9FF
 7FFF9

0x00004000 - 0x00004FFF 0x00003000 - 0x00003FFF 0x00002000 - 0x00002FFF 0x00001000 - 0x00001FFF

0x00006000 - 0x00006FFF

0x00005000 - 0x00005FFF

Virtual Memory

0x00000000 - 0x00000FFF

© 2007 Elsevier, Inc. All rights reserved



Virtual

Page

Number

00006

00005

00004

00003

00002

00001

00000

## Virtual Memory Example

What is the physical address of virtual address **0x247C**?

Physical Page
Number Physical Addresses

7FF 0x7FFF000 - 0x7FFFFF
7FF 0x7FFE000 - 0x7FFFFF

0001 0x0001000 - 0x0001FFF
0000 0x0000000 - 0x0000FFF

Physical Memory

Virtual Addresses

0x7FFFF000 - 0x7FFFFFF 0x7FFFE000 - 0x7FFFEFFF 0x7FFFD000 0x7FFFC000 0x7FFFCFFF 0x7FFFB000 - 0x7FFFBFFF 0x7FFFA000 - 0x7FFFAFFF 0x7FFF9000 - 0x7FFF9FFF 0x00006000 - 0x00006FFF 0x00005000 - 0x00005FFF 0x00004000 - 0x00004FFF 0x00003000 - 0x00003FFF 0x00002000 - 0x00002FFF 0x00001000 - 0x00001FFF 0x00000000 - 0x00000FFF

Virtual Memory

© 2007 Elsevier, Inc. All rights reserved



Virtual

Page Number

7FFFF

7FFFE

7FFFD

7FFFC

7FFFB

7FFFA

7FFF9

00006

00005

00004 00003

00002

00001

00000

#### Virtual Memory Example

What is the physical address of virtual address 0x247C?

- VPN = 0x2
- VPN 0x2 maps to PPN 0x7FFF
- 12-bit page offset: **0x47C**
- Physical address = 0x7FFF47C

**Physical** Page

Number

Physical Addresses

7FFF 7FFE

0x7FFF000 - 0x7FFFFF 0x7FFE000 - 0x7FFEFFF

0001 0000 0x0001000 - 0x0001FFF 0x0000000 - 0x0000FFF

Physical Memory

Virtual Addresses

0x7FFFF000 - 0x7FFFFFF 0x7FFFE000 - 0x7FFFEFFF 0x7FFFD000 - 0x7FFFDFFF 0x7FFFC000 0x7FFFCFFF 0x7FFFB000 - 0x7FFFBFFF 0x7FFFA000 - 0x7FFFAFFF

0x7FFF9000 - 0x7FFF9FFF

0x00006000 - 0x00006FFF 0x00005000 - 0x00005FFF 0x00004000 - 0x00004FFF 0x00003000 - 0x00003FFF 0x00002000 - 0x00002FFF 0x00001000 - 0x00001FFF 0x00000000 - 0x00000FFF

Virtual Memory

Virtual Page Number

7FFFF 7FFFE 7FFFD 7FFFC 7FFFB

7FFFA 7FFF9

00006

00005 00004

00003

00002

00001 00000






#### How to perform translation?

- Page table
  - Entry for each virtual page
  - Entry fields:
    - Valid bit: 1 if page in physical memory
    - Physical page number: where the page is located



# MEMORY

#### Page Table Example







What is the physical address of virtual address **0x5F20**?

	Physical	
_V	Page Number	
0		
0		
1	0x0000	
1	0x7FFE	
0		<sub>a</sub>
0		g
	•	Page Table
	•	ge
0		)a(
0		
1	0x0001	
0		
0		
1	0x7FFF	
0		
0		






Virtual

**Address** 

What is the physical address of virtual address **0x5F20**?

- -VPN = 5
- Entry 5 in page table
   VPN 5 => physical
   page 1
- Physical address:0x1F20








Virtual

What is the physical address of virtual address **0x73E0**?






Virtual

**Address** 

What is the physical address of virtual address **0x73E0**?

- -VPN = 7
- Entry 7 is invalid
- Virtual page must be paged into physical memory from disk





#### Page Table Challenges

- Page table is large
  - usually located in physical memory
- Load/store requires 2 main memory accesses:
  - one for translation (page table read)
  - one to access data (after translation)
- Cuts memory performance in half
  - Unless we get clever...





#### Translation Lookaside Buffer (TLB)

- Small cache of most recent translations
- Reduces # of memory accesses for most loads/stores from 2 to 1






#### TLB

- Page table accesses: high temporal locality
  - Large page size, so consecutive loads/stores likely to access same page
- TLB
  - Small: accessed in < 1 cycle</p>
  - Typically 16 512 entries
  - Fully associative
  - > 99 % hit rates typical
  - Reduces # of memory accesses for most loads/stores from 2 to 1



# SYSTEMS VEMORY

#### Example 2-Entry TLB







#### **Memory Protection**

- Multiple processes (programs) run at once
- Each process has its own page table
- Each process can use entire virtual address space
- A process can only access physical pages mapped in its own page table





### Virtual Memory Summary

- Virtual memory increases capacity
- A subset of virtual pages in physical memory
- Page table maps virtual pages to physical pages – address translation
- A TLB speeds up address translation
- Different page tables for different programs provides memory protection





#### Memory-Mapped I/O

- Processor accesses I/O devices just like memory (like keyboards, monitors, printers)
- Each I/O device assigned one or more address
- When that address is detected, data read/written to I/O device instead of memory
  - A portion of the address space dedicated to I/O devices



#### Memory-Mapped I/O Hardware

#### Address Decoder:

 Looks at address to determine which device/memory communicates with the processor

#### I/O Registers:

Hold values written to the I/O devices


#### ReadData Multiplexer:

 Selects between memory and I/O devices as source of data sent to the processor






#### The Memory Interface





# SYSTEMS NEMORY

#### Memory-Mapped I/O Hardware







### Memory-Mapped I/O Code


- Suppose I/O Device 1 is assigned the address 0xFFFFFF4
  - Write the value 42 to I/O Device 1
  - Read value from I/O Device 1 and place in \$t3





### Memory-Mapped I/O Code


Write the value 42 to I/O Device 1 (0xFFFFFFF4)





### Memory-Mapped I/O Code

Read the value from I/O Device 1 and place in \$t3





# Input/Output (I/O) Systems

- Embedded I/O Systems
  - Toasters, LEDs, etc.
- PC I/O Systems






# Embedded I/O Systems

- Example microcontroller: PIC32
  - microcontroller
  - 32-bit MIPS processor
  - low-level peripherals include:
    - serial ports
    - timers
    - A/D converters



# Digital I/O

```
// C Code
#include <p3xxxx.h>
int main(void) {
  int switches;
  TRISD = 0xFF00;
                       // RD[7:0] outputs
                        // RD[11:8] inputs
 while (1) {
    // read & mask switches, RD[11:8]
    switches = (PORTD >> 8) \& 0xF;
    PORTD = switches; // display on LEDs
```



PIC32



# Serial I/O


- Example serial protocols
  - SPI: Serial Peripheral Interface
  - UART: Universal Asynchronous Receiver/Transmitter
  - Also: I<sup>2</sup>C, USB, Ethernet, etc.






### SPI: Serial Peripheral Interface


- Master initiates communication to slave by sending pulses on SCK
- Master sends SDO (Serial Data Out) to slave, msb first
- Slave may send data (SDI) to master, msb first





### UART: Universal Asynchronous Rx/Tx

- Configuration:
  - start bit (0), 7-8 data bits, parity bit (optional), 1+ stop bits (1)
  - data rate: 300, 1200, 2400, 9600, ...115200 baud
- Line idles HIGH (1)
- Common configuration:
  - 8 data bits, no parity, 1 stop bit, 9600 baud





#### Timers

```
// Create specified ms/us of delay using built-in timer
#include <P32xxxx.h>
void delaymicros(int micros) {
  if (micros > 1000) { // avoid timer overflow
   delaymicros(1000);
   delaymicros (micros-1000);
 else if (micros > 6) {
   TMR1 = 0;
                           // reset timer to 0
   T1CONbits.ON = 1;
                             // turn timer on
   PR1 = (micros-6) *20;
                             // 20 clocks per microsecond
                             // Function has overhead of ~6 us
   IFSObits.T1IF = 0;
                            // clear overflow flag
   while (!IFSObits.T1IF); // wait until overflow flag set
void delaymillis(int millis) {
 while (millis--) delaymicros(1000); // repeatedly delay 1 ms
                                     // until done
```



## Analog I/O

- Needed to interface with outside world
- Analog input: Analog-to-digital (A/D) conversion
  - Often included in microcontroller
  - N-bit: converts analog input from  $V_{ref-}V_{ref+}$  to 0-2<sup>N-1</sup>

#### Analog output:


- Digital-to-analog (D/A) conversion
  - Typically need external chip (e.g., AD558 or LTC1257)
  - N-bit: converts digital signal from 0-2<sup>N-1</sup> to  $V_{ref}$ - $V_{ref}$
- Pulse-width modulation






### Pulse-Width Modulation (PWM)

Average value proportional to duty cycle



Add high-pass filter on output to deliver average value







# Other Microcontroller Peripherals

- Examples
  - Character LCD
  - VGA monitor
  - Bluetooth wireless
  - Motors





# Personal Computer (PC) I/O Systems

- USB: Universal Serial Bus
  - USB 1.0 released in 1996
  - standardized cables/software for peripherals
- PCI/PCIe: Peripheral Component Interconnect/PCI Express
  - developed by Intel, widespread around 1994
  - 32-bit parallel bus
  - used for expansion cards (i.e., sound cards, video cards, etc.)
- DDR: double-data rate memory





## Personal Computer (PC) I/O Systems

- TCP/IP: Transmission Control Protocol and Internet Protocol
  - physical connection: Ethernet cable or Wi-Fi
- SATA: hard drive interface
- Input/Output (sensors, actuators, microcontrollers, etc.)
  - Data Acquisition Systems (DAQs)
  - USB Links



### I/O Bus Examples

	Firewire	USB 2.0	PCI Express	Serial ATA	Serial Attached SCSI
Intended use	External	External	Internal	Internal	External
Devices per channel	63	127	1	1	4
Data width	4	2	2 per lane	4	4
Peak bandwidth	50MB/s or 100MB/s	0.2MB/s, 1.5MB/s, or 60MB/s	250MB/s/lane 1×, 2×, 4×, 8×, 16×, 32×	300MB/s	300MB/s
Hot pluggable	Yes	Yes	Depends	Yes	Yes
Max length	4.5m	5m	0.5m	1m	8m
Standard	IEEE 1394	USB Implementers Forum	PCI-SIG	SATA-IO	INCITS TC T10

#### Typical Intel Server w/ I/O System

