

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

4.1 PRE-START CHECK

Magnetic cyclic trim

Magnetic trim button

Cyclic stick

Magnetic trim button

Cyclic stick

Cyclic stick

– Check function

– Press and hold

– Displace from neutral position

– Release

– Remains in trimmed position

– Trim to neutral position

5. PERFORMANCE DATA

No change in the basic Flight Manual data.

6. MASS AND BALANCE

6.1 EQUIPMENT LIST ENTRIES

System/Equipment Designation	Part No.	Mass (kg)	Arm (mm)	Massmoment (kgmm)
Magnetic Cyclic Trim	D133-620	1.0	1400	1400

7. SYSTEM DESCRIPTION

Operation is by means of a pushbutton on the cyclic stick grip. To reposition (trim) the cyclic stick, press and hold the pushbutton, place the cyclic stick in the desired position and release the pushbutton.

NOTE When trimming is desired, always press the pushbutton first and then position the cyclic stick.