

2. LIMITATIONS

2.1 FUEL JETTISONING LIMITATIONS

Airspeed 55 to 70 KIAS

Max rate of descent 1000 fpm

Fuel jettisoning is not approved during flight with **inflated** emergency floats (FMS 10-22).

Fuel jettisoning during hover flight is prohibited.

Fuel jettison valve must be closed prior to landing.

2.2 SYSTEM INSTALLATION LIMITATIONS

Only the Fuel Jettison System with Extension shall be installed when the following optional equipment is simultaneously installed:

Snow Skids	– FMS 10-18
Settling Protectors	– FMS 10-20
Emergency Flotation System	– FMS 10-22

The nozzle extension must be removed upon removal of the above listed equipment.

3. EMERGENCY AND MALFUNCTION PROCEDURES

3.1 FUEL JETTISONING

Conditions/Indications

Certain helicopter emergencies (e.g. single-engine failure in flight) may require jettisoning of the main tank fuel.

Procedure

NOTE Jettison fuel only in an actual emergency to reduce helicopter gross mass. If conditions permit, jettison fuel above 5000 ft AGL, over unpopulated areas and notify air traffic control.

Airspeed – 55 to 70 KIAS

FUEL JETT switch – OPEN

Main tank (M) fuel quantity – Monitor

When desired fuel quantity is reached or conditions dictate:

FUEL JETT switch – CLOSE

During prelanding check:

FUEL JETT switch – CLOSE