

2. LIMITATIONS

2.1 SYSTEM REQUIREMENT

An installed and operational heating and ventilation system is required for operation in extreme low temperatures (below -30°C).

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

No change in the basic Flight Manual data.

5. PERFORMANCE DATA

No change in the basic Flight Manual data.