

2. LIMITATIONS

2.1 KINDS OF OPERATION

The hoisting of persons shall be performed in accordance with the applicable national regulations.

2.2 OCCUPANTS

Only those persons who are necessary for accomplishment of the work activity directly associated with the hoisting operation may be carried in the helicopter.

2.2.1 Flight Crew

Minimum crew 2 (pilot and hoist operator)

The hoist shall be operated by qualified personnel only.

Hoist operator must be secured to helicopter by retaining harness P/N 117-80417 or equivalent.

With the exception of performing emergency cable cutting, pilot operation of the hoist is permissible only when voice communication is maintained between pilot and hoist operator.

2.3 MASS AND LOAD LIMITS

2.3.1 Maximum Gross Mass

EFFECTIVITY *Variants CB, CB-2, CDN-B, CBS, CBS-2 and CDN-BS*

No change in the basic Flight Manual data.

EFFECTIVITY *Variants CB-4, CDN-B-4, CBS-4, and CDN-BS-4*

Max combined gross mass including hoist load 2400 kg (5291 lb)

EFFECTIVITY *ALL*

2.3.2 Maximum Hoist Load Limits

Raising 270 kg (600 lb)

Lowering 200 kg (440 lb)

NOTE Load limits are based upon the maximum usable cable length of 30 m (98 ft).

2.4 CENTER OF GRAVITY LIMITS

2.4.1 Longitudinal CG

No change in the basic Flight Manual data.