

3.3 SYSTEM EMERGENCY/MALFUNCTION CONDITIONS

3.3.1 Electrical Short Circuit

Conditions/Indications

- Voltmeter indicates low voltage
- Ammeter may indicate excessive current
- Failure of equipment powered by affected bus
- **GEN 1** and/or **GEN 2** warning light may come on

Procedure

- | | |
|--------------------------------|-------------------|
| 1. Both generator field sw | – GEN TRIP |
| 2. Both STARTER/GENERATOR sw | – Off |
| 3. CURRENT IND sw | – BUS BAR (BATT) |
| 4. Electrical consumption | – Reduce |
| 5. Ammeter and voltmeter | – Monitor |
| 6. LAND AS SOON AS PRACTICABLE | |

Residual Battery Endurance					
Continuous load [A]	15	20	25	30	40
Time [min]	60	45	35	30	22
NOTE Calculations are based on an assumed minimum battery capacity of 15 Ah. Times include 10-min landing light operation and 10-min radio transmitting.					

If electrical short circuit indications continue:

- | | |
|-----------------------------|--|
| 7. Battery sw | – Off if flight conditions permit |
| 8. LAND AS SOON AS POSSIBLE | |