

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

No change in the basic Flight Manual data.

5. PERFORMANCE DATA

No change in the basic Flight Manual data.

6. MASS AND BALANCE

6.1 LOADING DATA

When calculating CG of passengers seated on the sectioned bench, use an arm of 2740 mm.

6.2 EQUIPMENT LIST ENTRIES

System/Equipment Designation	Part No.	Mass (kg)	Arm (mm)	Massmoment (kgmm)
Passenger Sectioned Bench Seat	105-82501	10.0	2800	28000
Passenger Sectioned Bench Seat	D131-1132	10.0	2800	28000

7. SYSTEM DESCRIPTION

The sectioned bench-type passenger seat is installed at the rear bulkhead of the cabin. The seat is designed for three persons (two seated on the LH section) and is constructed of two separate canvas covered tubular frameworks joined together with locking pins. The LH seat section may be removed separately allowing for cargo stowage space and still retain seating for one passenger. All three seating positions are equipped with lap safety belts.

NOTE Seats delivered with helicopters S-897 and subsequent are additionally equipped with a shoulder harness for each seating position.