

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

NOTE If an emergency landing is necessary, switch searchlight off prior to touchdown.

4. NORMAL PROCEDURES

4.1 SEARCHLIGHT OPERATION

CAUTION • STANDBY MAGNETIC COMPASS AND ADF (IF INSTALLED) ARE UNRELIABLE WITH SEARCHLIGHT ON.

- CARGO HOOK MIRROR (IF INSTALLED) MUST BE COVERED OR REMOVED.

- LAND ON LEVEL SURFACE DUE TO LOW SEARCHLIGHT GROUND CLEARANCE - APPROX 20 CM (8 IN.).

4.1.1 Activation

Remote control handle	– Release from retaining clip
-----------------------	-------------------------------

Power pushbutton	– Press
------------------	---------

NOTE Lamp will reach full brightness after approx 15 sec; longer under cold environmental conditions.

Directional control switch	– Use as necessary to position light beam
----------------------------	---

4.1.2 Deactivation

CAUTION ALLOW LAMP TO REACH FULL BRIGHTNESS BEFORE SWITCHING OFF.

Power pushbutton	– Press
------------------	---------

Remote control handle	– Secure in retaining clip
-----------------------	----------------------------

CAUTION ALLOW LAMP TO COOL 30 TO 60 SEC BEFORE REACTIVATING.

5. PERFORMANCE DATA

No change in the basic Flight Manual data.