

4.2 SEARCHLIGHT OPERATION

NOTE The ADF receiver range is greatly reduced during searchlight operation.

4.2.1 Activation

MASTER switch – ON

CAUTION HOLDING THE START SWITCH IN THE START POSITION AFTER LAMP IGNITION MAY DAMAGE THE EQUIPMENT.

START switch – Place and hold in START until lamp ignites, then release

NOTE Lamp ignition normally takes approx 5 sec. Release START switch immediately after lamp ignites.

FOCUS switch – Operate as desired

Directional control switch – Operate as desired

4.2.2 Deactivation

MASTER switch – OFF

CAUTION ALLOW LAMP TO COOL A MINIMUM 60 SEC BEFORE REACTIVATION.

5. PERFORMANCE DATA

Rate of climb is reduced by 40 fpm due to increased drag.