

2. LIMITATIONS

2.1 INSTALLATION LIMITS

The high clearance landing gear shall not be installed together with the following listed equipment:

Snow Skids	FMS 10-18
Emergency Flotation System	FMS 10-22

NOTE On helicopters fitted with Rescue Hoist System (FMS 10-17), long boarding steps must be installed on the high clearance landing gear.

2.2 OPERATIONAL LIMITS

2.2.1 Slope Operations

Slope operations (takeoff/landing) are limited in the degree of sloping terrain upon which the maneuver may be performed:

Ground sloping down to the left	max 10°
Ground sloping down to the right	max 8°
Ground sloping down forward	max 5°
Ground sloping down rearward	max 5°

2.2.2 Fixed External Loads

Flights with fixed external loads are approved for VFR only.

Only those persons who are necessary for accomplishment of the flight may be carried in the helicopter during flights with fixed external loads.

Max allowable load on each lower fuselage mount
(two at STA 4 and two at STA 9) 75 kg (165 lb)

Max external load dimensions:

Length	2500 mm
Width	600 mm
Height	400 mm

The helicopter CG with external load must lie within the longitudinal CG limits during the entire flight.