

2. LIMITATIONS

2.1 SYSTEM LIMITS

The windshield washer pump must be allowed to cool several minutes after completing 10 successive wash operations.

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

- | | |
|--------------------------------|---------------------|
| ★ Washer reservoir fluid level | – As required |
| Filler cap | – Secure |
| Elec cables and fluid line | – Connected, secure |
| Windshield wipers | – Condition |
- ★ To be checked each flight before takeoff.

4.2 SYSTEM OPERATION

CAUTION OPERATE WIPERS ONLY WHEN WINDSHIELD IS WET.

- | | |
|-----------------------|---|
| WIPER-OFF-WASH switch | – WASH and release, repeat as necessary |
| WIPER-OFF-WASH switch | – WIPER |
| WIPER-OFF-WASH switch | – OFF, wipers return to park position |

5. PERFORMANCE DATA

No change in the basic Flight Manual data.