

4. NORMAL PROCEDURES

No change in the basic Flight Manual data.

5. PERFORMANCE DATA

No change in the basic Flight Manual data.

6. MASS AND BALANCE

6.1 EQUIPMENT LIST ENTRIES

System/Equipment Designation	Part No.	Mass (kg)	Arm (mm)	Massmoment (kgmm)
Transmission Chip Warning	105-98265	0.27	3330	899
Tail-rotor/Intermediate Gearbox Chip Warning	105-982656	0.23	5800	1334

7. SYSTEM DESCRIPTION

Either the main transmission alone or the main transmission together with the tail-rotor and intermediate gearboxes may be fitted with chip detectors. The chip detectors are connected to a **T. PLUG** warning light either direct (main transmission only) or via a selector switch on the overhead console (main transmission with gearboxes).

The **T. PLUG** warning light will activate when excessive metallic particles are detected by one of the magnetic chip detectors. The three-position T PLUG selector switch (if fitted) is spring-loaded to the center ALL position and is used to determine the source of the warning; i.e. when placed in the MAIN position and the warning light remains on the main-transmission chip detector is affected, when placed in the TR/IGB position and the warning light remains on either the tail-rotor or intermediate gearbox chip detector is affected. The **T. PLUG** warning light circuit is powered by the Main Bus via a fuse.

