

**WARNING** DO NOT TEST OR OPERATE THE IR FILTER ON THE GROUND WITH THE SEARCHLIGHT LAMP ACTIVATED. THE IR LIGHT BEAM IS INVISIBLE TO THE NAKED EYE AND POTENTIALLY HAZARDOUS TO THE EYES AND SKIN AT DISTANCES OF LESS THAN 500 FT.

- |                     |                                                                                                    |
|---------------------|----------------------------------------------------------------------------------------------------|
| IR filter           | – Condition, function                                                                              |
| MASTER switch       | – ON                                                                                               |
| IR ON/IR OFF switch | – Place in IR ON position; verify that IR filter actuates and that IR ON indicator light comes on  |
|                     | – Place in IR OFF position; verify that IR filter retracts and that IR ON indicator light goes off |
| MASTER switch       | – OFF                                                                                              |

## 4.2 SEARCHLIGHT OPERATION

**NOTE** The ADF receiver range is greatly reduced during searchlight operation.

### 4.2.1 Activation

- |               |      |
|---------------|------|
| MASTER switch | – ON |
|---------------|------|

**CAUTION** HOLDING THE START SWITCH IN THE START POSITION AFTER LAMP IGNITION MAY DAMAGE THE EQUIPMENT.

- |              |                                                            |
|--------------|------------------------------------------------------------|
| START switch | – Place and hold in START until lamp ignites, then release |
|--------------|------------------------------------------------------------|

**NOTE** Lamp ignition normally takes approx 5 sec. Release START switch immediately after lamp ignites.

- |                            |                      |
|----------------------------|----------------------|
| FOCUS switch               | – Operate as desired |
| Directional control switch | – Operate as desired |
| IR ON/IR OFF switch        | – Operate as desired |

### 4.2.2 Deactivation

**NOTE** When not in use, it is recommended to position the searchlight facing forward with the IR filter closed over the lamp.

- |               |       |
|---------------|-------|
| MASTER switch | – OFF |
|---------------|-------|

**CAUTION** ALLOW LAMP TO COOL A MINIMUM 60 SEC BEFORE REACTIVATION.

## 5. PERFORMANCE DATA

Rate of climb is reduced by 40 fpm due to increased drag.