

SECTION 4

NORMAL PROCEDURES

TABLE OF CONTENTS

	<u>Page</u>
4.1 GENERAL	4 - 1
4.2 PREPARATION FOR FLIGHT	4 - 1
4.2.1 Flight Restrictions	4 - 1
4.2.2 Flight Planning	4 - 1
4.2.3 Mass and Balance	4 - 1
4.3 PREFLIGHT CHECK	4 - 1
4.3.1 General	4 - 1
4.3.2 Exterior Check	4 - 2
4.3.3 Interior Check	4 - 9
4.4 STARTING ENGINES	4 - 11
4.4.1 Starting First Engine	4 - 11
4.4.2 Starting Second Engine	4 - 13
4.5 SYSTEM CHECKS	4 - 13
4.5.1 Hydraulic Checks	4 - 13
4.5.2 Electrical and Avionic Checks	4 - 14A
4.5.3 Miscellaneous Checks	4 - 15
4.6 PRE-TAKEOFF CHECK	4 - 15
4.6.1 On Ground	4 - 15
4.6.2 At Hover	4 - 16
4.7 CRUISE CHECK	4 - 16
4.8 PRE-LANDING CHECK	4 - 16
4.9 ENGINE SHUTDOWN	4 - 16
4.9.1 Normal	4 - 16
4.9.2 Deceleration Check	4 - 17

	<u>Page</u>
4.10 COLD WEATHER STARTING INFORMATION	4 - 18
4.11 FLIGHT CHARACTERISTICS	4 - 19
4.11.1 Flight Controls	4 - 19
4.11.2 Lateral Control Characteristics	4 - 20

LIST OF FIGURES

Fig. 4-1 Exterior Check Sequence	4 - 2
--	-------