

SECTION 7**SYSTEM DESCRIPTION****TABLE OF CONTENTS**

	<u>Page</u>
7.1 GENERAL	7 - 1
7.2 LOCATION AREAS	7 - 1
7.2.1 Nose Compartment	7 - 1
7.2.2 Cabin	7 - 1
7.2.3 Cargo Compartment	7 - 1
7.2.4 Avionics Equipment Bay	7 - 1
7.2.5 Tail Boom	7 - 1
7.2.6 Landing Gear	7 - 2
7.3 COCKPIT ARRANGEMENT	7 - 2
7.3.1 Instrument Panel and Console Layout	7 - 2
7.3.2 Crew Member Seats	7 - 2
7.4 EMERGENCY EQUIPMENT	7 - 2
7.4.1 Engine Overheat and Fire Detection	7 - 2
7.4.2 Portable Fire Extinguisher	7 - 2
7.4.3 First Aid Kit	7 - 2
7.4.4 Emergency VHF Radio	7 - 2
7.5 POWER PLANT AND RELATED SYSTEMS	7 - 8
7.5.1 Engines	7 - 8
7.5.2 Air Induction	7 - 8
7.5.3 Inlet Anti-icing System	7 - 10
7.5.4 Fuel and Control System	7 - 10
7.5.5 Oil System	7 - 10
7.5.6 Starting and Ignition System	7 - 12
7.5.7 Control System	7 - 12
7.5.8 Indicators	7 - 13
7.5.9 Annunciators	7 - 13

	<u>Page</u>
7.6 FUEL SYSTEM	7 - 14
7.6.1 Storage	7 - 14
7.6.2 Supply	7 - 14
7.6.3 Indicators	7 - 14
7.6.4 Annunciators	7 - 16
7.7 POWER TRAIN	7 - 16
7.7.1 Main Transmission	7 - 16
7.7.2 Main Transmission Oil System	7 - 16
7.7.3 Main Transmission Indicators	7 - 18
7.7.4 Main Transmission Annunciators	7 - 18
7.7.5 Mast Moment Indication System	7 - 18
7.7.6 Tail Rotor Drive Shafts	7 - 20
7.7.7 Intermediate Gearbox	7 - 20
7.7.8 Tail Rotor Gearbox	7 - 20
7.8 ROTOR SYSTEM	7 - 21
7.8.1 Main Rotor	7 - 21
7.8.2 Main Rotor Head	7 - 21
7.8.3 Main Rotor Blades	7 - 21
7.8.4 Tail Rotor Assembly	7 - 21
7.9 FLIGHT CONTROL SYSTEM	7 - 24
7.9.1 Cyclic Stick	7 - 24
7.9.2 Collective Lever	7 - 24
7.9.3 Directional Control Pedals	7 - 24
7.9.4 Cyclic Trim System	7 - 24
7.9.5 Flight Control Servos	7 - 26
7.10 HYDRAULIC SYSTEM	7 - 28
7.11 ELECTRICAL SYSTEM	7 - 31
7.11.1 Power Supply	7 - 31
7.11.2 Distribution	7 - 31
7.11.3 Controls, Indicators and Annunciators	7 - 31
7.11.4 Circuit Protection	7 - 34

	<u>Page</u>
7.12 LIGHTING EQUIPMENT	7 - 34
7.12.1 Position Lights	7 - 34
7.12.2 Anticollision Lights	7 - 34
7.12.3 Instrument Lights	7 - 35
7.12.4 Utility Light	7 - 35
7.12.5 Interior Lights	7 - 35
7.12.6 Annunciator Lights	7 - 35
7.12.7 Rpm Warning System	7 - 35
7.13 FLIGHT INSTRUMENTS	7 - 37
7.13.1 Pitot-static System	7 - 37
7.13.2 Barometric Altimeter	7 - 37
7.13.3 Vertical Speed Indicator	7 - 37
7.13.4 Airspeed Indicator	7 - 37
7.13.5 Clock	7 - 38
7.13.6 Standby Magnetic Compass	7 - 38
7.13.7 Outside Air Temperature (OAT) Indicator	7 - 38

LIST OF FIGURES

Fig. 7-1 Location Areas and Access	7 - 3
Fig. 7-2 Typical Cockpit Layout	7 - 4
Fig. 7-3 Typical Instrument Panel	7 - 5
Fig. 7-4 Typical Center Console Switch Panel	7 - 6
Fig. 7-5 Typical Overhead Console	7 - 7
Fig. 7-6 Engine Component Locations	7 - 9
Fig. 7-7 Engine Oil System Schematic	7 - 11
Fig. 7-8 Fuel System Schematic	7 - 15
Fig. 7-9 Power Train	7 - 17
Fig. 7-10 Main Transmission Monitoring Systems	7 - 19
Fig. 7-11 Main Rotor	7 - 22

	<u>Page</u>
Fig. 7-12 Tail Rotor Assembly	7 - 23
Fig. 7-13 Flight Control System	7 - 25
Fig. 7-14 Cyclic Stick Grip and Collective Lever Controls	7 - 27
Fig. 7-15 Dual Hydraulic Module	7 - 29
Fig. 7-16 Hydraulic System Schematic	7 - 30
Fig. 7-17 Electrical System Schematic	7 - 32
Fig. 7-18 Typical Fuse Panel Layout	7 - 33
Fig. 7-19 Alphabetical Listing of Warning/Caution Lights	7 - 36