

SECTION 8**HANDLING, SERVICING, AND MAINTENANCE****TABLE OF CONTENTS**

	<u>Page</u>
8.1 GENERAL	8 - 1
8.2 GROUND HANDLING	8 - 1
8.2.1 Towing	8 - 1
8.2.2 Parking	8 - 2
8.2.3 Mooring	8 - 4
8.3 SERVICING	8 - 4
8.3.1 Refueling	8 - 4
8.3.2 Defueling	8 - 5
8.3.3 Engine Oil System	8 - 6
8.3.4 Main Transmission	8 - 6
8.3.5 Rotor Hub Reservoir	8 - 6
8.3.6 Intermediate Gearbox	8 - 6
8.3.7 Tail Rotor Gearbox	8 - 6
8.3.8 Hydraulic Systems	8 - 6
8.3.9 Engine Compressor Rinsing	8 - 7
8.4 COLD WEATHER OPERATION - GENERAL PRACTICES	8 - 7
8.4.1 Fuels	8 - 7
8.4.2 Fuel/Additive Blending	8 - 7
8.4.3 Mixing Alternate Fuel	8 - 8
8.4.4 Oils	8 - 9
8.4.5 Preheating	8 - 9
8.5 MAINTENANCE	8 - 9

LIST OF FIGURES

Fig. 8-1	Ground Handling	8 - 3
----------	-----------------------	-------

