

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

Shoulder harness lock – Function

5. PERFORMANCE DATA

No change in the basic Flight Manual data.

6. MASS AND BALANCE

6.1 EQUIPMENT LIST ENTRIES

System/Equipment Designation	Part No.	Mass (kg)	Arm (mm)	Massmoment (kgmm)
Shoulder Harnesses-Pilot/Copilot, with Inertial Reel	105-70321	3.0	2100 (1850)	6300 (5550)
NOTE Above values in parentheses apply to Model S Variants.				

7. SYSTEM DESCRIPTION

The pilot and copilot adjustable shoulder harnesses are each equipped with an inertial reel. The inertial reel provides the crewmember with relative freedom of movement during normal operations, however, will automatically lock and restrain the crewmember during actual emergencies. A 2-3g acceleration will automatically lock the inertial reel and the reel will remain locked until being manually released. The reel may also be manually locked in any desired position.

A lever, mounted on the LH side of each pilot seat, has three positions to select operation of the inertial reel:

Lever position forward	Manually locked
Lever position center	Automatic (normal position)
Lever position aft	Release