

SECTION 1

GENERAL

TABLE OF CONTENTS

	<u>Page</u>
1.1 GENERAL	1 - 1
1.2 ORGANIZATION OF THE MANUAL	1 - 1
1.2.1 Approved Data	1 - 1
1.2.2 Description of the Sections	1 - 1
1.2.3 Page Numbering	1 - 2
1.2.4 Flight Manual Supplements (FMS)	1 - 3
1.2.5 Flight Manual Appendices (FMA)	1 - 3
1.3 EFFECTIVITY STATEMENTS	1 - 4
1.3.1 Definition of Effectivity Identification	1 - 4
1.3.2 Method of Indicating Effectivity	1 - 4
1.3.3 Incorporating Pages Having Entire Page Effectivity Statements	1 - 5
1.4 REVISION SERVICE	1 - 5
1.4.1 Revisions	1 - 5
1.4.2 Minor Revisions	1 - 5
1.4.3 Temporary Revisions	1 - 5
1.4.4 Identifying Revised Material	1 - 5
1.5 FLIGHT MANUAL APPLICABILITY	1 - 6
1.6 GENERAL DESCRIPTION OF THE HELICOPTER	1 - 7
1.7 HELICOPTER DIMENSIONS	1 - 7
1.8 CONVERSION CHARTS	1 - 7
1.9 TERMINOLOGY AND DEFINITIONS OF TERMS	1 - 15
1.9.1 Warnings, Cautions and Notes	1 - 15
1.9.2 Use of Procedural Terms	1 - 15
1.10 ABBREVIATIONS AND SYMBOLS	1 - 16

LIST OF FIGURES

	<u>Page</u>
Fig. 1-1 Principal Dimensions	1 - 8
Fig. 1-2 Conversion Chart: Celsius - Fahrenheit	1 - 9
Fig. 1-3 Conversion Chart: Kilometers/Hour - Knots	1 - 10
Fig. 1-4 Conversion Chart: Meters/Second - Feet/Minute	1 - 11
Fig. 1-5 Conversion Chart: Kilograms - Pounds	1 - 12
Fig. 1-6 Conversion Chart: Liters - US Gal - Imp. Gal	1 - 13
Fig. 1-7 Conversion Chart: Hectopascals - Inches of Mercury	1 - 14