SECTION 4 Set-Up & Operation


Initial Cleansing & First Brew




CAUTION: Two sharp needles are used to puncture the K-Cup® packs. One is above the K-Cup® Pack Holder and the other is in the bottom of the K-Cup® Pack Holder. To avoid risk of injury, do not put your fingers inside the K-Cup® Pack Assembly Housing.



CAUTION: During the brewing process, the water gets extremely hot. To avoid risk of injury, do not lift the Handle or open the K-Cup® Pack Assembly Housing until brewing is complete.



Remove all tape and cardboard.





Plug the Power Cord into an independent, grounded outlet.



For accurate measuring, do not fill if the Handle is up. In the down position it prevents water from entering the lower heating compartment.





Press the Power Button. The Add Water Indicator will flash blue.

The Power Button does not illuminate.





Pour water anywhere within the Cold Water Reservoir until it reaches up to the rim of your desired fill level on the Water Level Guide (minimum of 6 oz.). Lower the lid.

- For accurate measuring, do not fill if the Handle is up.
- → Bottled or filtered water is recommended; distilled or reverse osmosis water is not.

SECTION 4 Set-Up & Operation (continued)



Let water fully drain into brewer before lowering the Handle.



DO NOT remove foil lid or puncture K-Cup® pack.



Lift the Handle. Water starts to drain from the Cold Water Reservoir into the brewer.

If you add more than 10 oz., excess water goes into the Drip Tray.



Place mug on the Drip Tray.

If you want to use a taller mug, you can slide the Drip Tray out, but you will lose the benefit of the tray to catch the excess water.



Insert the K-Cup® pack into the K-Cup® Pack Holder.

Do not add a K-Cup® pack if you are performing the initial cleansing brew.



Wait until all water has drained (5 seconds) into the brewer before lowering the Handle completely.

10



The BREW Button will flash blue. Press the BREW Button.

① CAUTION: Do not lift the Handle while brewing.



The BREW Button will flash red to indicate that the water is heating. After about 2 minutes, the BREW Button will turn solid red when the beverage starts to dispense.

Remove used K-Cup® pack after brewing.
CAUTION: K-Cup® pack will be hot.



Enjoy your beverage! Your brewer is ready to use again or you can power it off.

As a safety feature, brewer automatically shuts off after 90 seconds.

If completing the initial cleansing brew, discard hot water into the sink. Your brewer is ready to use again.