


Print calibration

Print at 100% / Actual size on A4. Disable Fit in the viewer and driver.

Measure the square horizontally and vertically between line centres.

Both dimensions must be 100 mm before you assemble the gores.



Use the same printer, paper size and scaling settings for every page.

If printing the gores as a separate job, keep these settings unchanged.

Repeat this check after changing the printer, paper or print settings.

Gore 01

Gore 02




Gore 03

+


+

+


+



Gore 01



Gore 02



Gore 03

