


+49 9951 959 2019
service-de@einhell.com



Article number: 4431110
Ident number: 21041



Spare parts

Pos	Art.	Ident number	Product Name
099	443111004099	00000	color box
105	443111003105	00000	contacts
109	443111003109	00000	switch operating lever
110	443111003110	00000	spring
111	443111003111	00000	compensator
112	443111003112	00000	micro switch
113	443111003113	00000	soft start electronics
114	443111003114	00000	dejam coil
117	443111003117	00000	face spanner
118	443111003118	00000	grinding wheel
128	443111003128	00000	coupling disc
130	443111003130	00000	additional handle
134	443111003134	00000	screw
790	443111004790	00000	Manual
792	443111004792	00000	Safety instructions
901	443111003901	00010	Screw Assembly
902	443111003902	00010	arrest button assy.
903	443111003903	00010	Screw Assembly
904	443111003904	00010	Guard / Protection Device Asse
905	443111003905	00010	Complete Motor Assembly
906	443111004906	00010	front cover assembly
909	443111003909	00010	Housing Assembly
918	443111003918	00010	Tool Fixture Assembly

Screw Assembly

Article number: 443111003901
Ident number: 00010

Spare parts

Pos	Art.	Ident number	Product Name
147	443111003147	00000	screw
148	443111003148	00000	standard washer
149	443111003149	00000	spring washer

arrest button assy.

Article number: 443111003902
Ident number: 00010

Spare parts

Pos	Art.	Ident number	Product Name
106	443111003106	00000	spring
107	443111003107	00000	retaining ring

Guard / Protection Device Asse

Article number: 443111003904
Ident number: 00010

Spare parts

Pos	Art.	Ident number	Product Name
131	443111003131	00000	grinding wheel guard

Complete Motor Assembly

Article number: 443111003905
Ident number: 00010

Spare parts

front cover assembly

Article number: 443111004906
Ident number: 00010

Spare parts

Pos	Art.	Ident number	Product Name
119	443111003119	00000	output shaft
120	443111003120	00000	retainer
121	443111003121	00000	gear wheel
122	443111003122	00000	cotter
123	443111003123	00000	spring lock washer
124	443111003124	00000	drive shaft
125	443111003125	00000	retaining ring
126	443111003126	00000	bevel gear
127	443111003127	00000	cotter
137	443111003137	00000	ball bearing
138	443111003138	00000	screw
140	443111004140	00000	washer screw
143	443111003143	00000	decoration cover
144	443111003144	00000	screw
145	443111003145	00000	gear cover
146	443111003146	00000	ball bearing
147	443111003147	00000	screw
148	443111003148	00000	standard washer
149	443111003149	00000	spring washer
150	443111003150	00000	ball bearing holder
151	443111003151	00000	screw
952	443111003952	00010	Gear housing assembly

Housing Assembly

Article number: 443111003909
Ident number: 00010

Spare parts

Pos	Art.	Ident number	Product Name
132	443111003132	00000	half box left
133	443111003133	00000	half box right

Tool Fixture Assembly

Article number: 443111003918
Ident number: 00010

Spare parts

Pos	Art.	Ident number	Product Name
115	443111003115	00000	flange within
116	443111003116	00000	flange outside

Gear housing assembly

Article number: 443111003952
Ident number: 00010

Spare parts

Pos	Art.	Ident number	Product Name
136	443111003136	00000	gear housing
139	443111003139	00000	needle bearing
140	443111003140	00000	bearing bush