

iSC GmbH
Customer Service
Eschenstraße 6
94405 Landau/Isar


Telephone:
Email:

+49 9951 959 2019
service-de@einhell.com



Cordless Jig Saw
TC-JS 18 Li - Solo

Article number: 4321209
Ident number: 21031



Spare parts

Pos	Art.	Ident number	Product Name
001	432120901001	00000	switch on/off (Black)
099	432120903099	00000	color box
100	432120901100	00000	reverser pendular lift (Black)
101	432120901101	00000	spring
102	432120901102	00000	retaining ring
103	432120901103	00000	ball
104	432120901104	00000	bolt
105	432120901105	00000	start up lock (Black)
106	432120901106	00000	return spring
107	432120901107	00000	guidance up
109	432120901109	00000	spring
110	432120901110	00000	bush
111	432120901111	00000	blinds
112	432120901112	00000	bail
113	432120901113	00000	screw ST3,4 x 16
114	432120901114	00000	decoration cover (Red)
115	432120901115	00000	sliding shoe
116	432120901116	00000	sliding plate
117	432120901117	00000	fastening plate
118	432120901118	00000	screw M4 x 12
119	432120901119	00000	square nut
120	432120901120	00000	clamping part
121	432120901121	00000	bolt
122	432120901122	00000	contacts
123	432120901123	00000	Hexagon socket key
124	432120903124	00000	saw blade for wood
125	432120901125	00000	exhausting adapter
126	432120901126	00000	splinter guard
128	432120901128	00000	dejam coil
129	432120901129	00000	current limiting PCB
909	432120901909	00000	Housing Assembly (Einhell Red)
915	432120901915	00000	Complete Drive Unit Assembly
951	432120901951	00000	Lift Rod Assembly
952	432120901952	00000	Guide Roller Holder Assembly