

 PT. MNA SERANG	WORKING INSTRUCTION CAPASITOR MODULE REPLACEMENT REACTIVE MAINTENANCE	WI/MNASRG-E&I-19-006	
		Dept.	ENGINEERING
		Section	E&I
		Revision	0
		Effective Date	
		Page	1 of 2

Instruksi / Instruction Pre-Action / Pre-Action
--

	
---	--

Siapkan obeng dan bor tangan (<i>Prepare screwdriver and hand-drill</i>)	Koordinasi dengan user plant (<i>Coordinate with the plant user</i>)
--	--

	
---	--

Siapkan JSA, Work Permit LOTO dan form LOTO (<i>Prepare JSA, LOTO Work Permit and LOTO form</i>)	Matikan sumber energi terkait dan lakukan pemasangan LOTO pada breaker dan key switch (<i>Turn off the power source and install LOTO on breaker and key switch</i>)
--	---


Penggantian / Replacement

	
--	---

Lepaskan 2 kabel kontrol kontaktor dan 3 kabel input kontaktor (<i>Disconnect the 2 control cables and 3 input cables of the contactor</i>)	Lepaskan semua fuse pengaman (<i>Lepaskan semua protection fuse.</i>)
---	---

	
---	--

Lepaskan plat support menggunakan hand-drill. (<i>Remove the supporting plate by using hand-drill.</i>)	Lepaskan kabel yang pada terminal dan cabut ke arah luar modul kapasitor. (<i>Disconnect the cables on the terminal and withdraw the capacitor module</i>)
---	--

	
Pasang modul kapasitor baru dan hubungkan semua kabel yang dilepas dari terminal sebelumnya (<i>Install the new capsitor module and reconnect all cables that are disconnected from terminals.</i>)	