

 PT. MNA SERANG	WORKING INSTRUCTION	WTMNASRG-E&I-19-008	
		Dept.	ENGINEERING
	RM MOTOR	Section	E&I
		Revision	0
		Effective Date	01-Sep-19
		Page	1 of 1

 	
Uukur nominal tegangan pada Starter motor (<i>Measure the nominal voltage on Motor Starter .</i>)	Uukur nominal arus pada Starter motor (<i>Measure the nominal Current on Motor Starter .</i>)
	 
Potong winding sedekat mungkin dengan motor (<i>Cut winding as close as possible to motor .</i>)	Bersihkan stator & rotor (<i>Clean stator & rotor</i>)
 	
Ganti bearing jika sudah rusak (<i>Replace bearing if already damaged</i>)	pasang kembali motor. check nominal arus & tegangan (<i>Re-Install motor., Check current & voltage nominal</i>)