

Doc.No	Date	Rev	DCS DELTAV - SOFTWARE	Created by	Approved by	wilmar
WI/DCS/S/003	20/07/2021	0	IFIX SYSTEM - HMI DCS CAN'T RUNNING	Robby K N	M. Yazid	

Information

This document was created and purposed as a work instruction to fix Ifix System (HMI DCS can't running)

Error Message : "Ifix system not Started"




Root Cause : Services Ifix already running

FlexLock - Window Desktop Access

- 1.1 Go to FlexLock and Select Window Desktop
- 1.2 Right click on taskbar and select Task Manager
- 1.3 On tab processes, select FIX.EXE
- 1.4 Click on End Task




1



DeltaV Operate

- 2.1 Close Task Manager
- 2.2 On FlexLock, Select DeltaV Desktop
- 2.3 On FlexLock, Select DeltaV Operate
- 2.4 Wait till HMI Graphic is Running

2



LogOff DeltaV

- 3.1 On DeltaV Operate Click DeltaV LogOn Icon
- 3.2 Select LogOff
- 3.3 Click Close (X)

3

