

Revision No	Revision Date	Title	Prepared	Checked	Approved
REV00-00	23/10/2020	WORK INSTRUCTIONS ON VIRTUAL SERVER DISASTER RECOVERY	RK	MY	CV

1

AFTER POWER RECOVERED, MAKE SURE THE RELATED MCB THAT SUPPLYING POWER TO SERVER PANEL IS SWITCHED ON




2

IF SERVER DOESN'T START ITSELF, THEN PUSH THE MAIN POWER BUTTON SHOWN IN **RED** CIRCLE BELOW, AND WAIT FOR FEW MINUTES UNTIL ALL OTHER POWER LEDS LIT ON




3

LOGIN TO CLUSTERDC COMPUTER, THEN OPEN/DOUBLE CLICK "DELTAV VIRTUAL STUDIO", THEN CLICK "OK" AS SHOWN BELOW




4

IN THE DELTAV VIRTUAL STUDIO SOFTWARE, CHECK IF THERE ARE SOME VIRTUAL MACHINES (VM) DON'T RUN THEMSELVES. VM WITH **GREEN** BULLET MEANS RUNNING. VM WITHOUT BULLET MEANS NOT RUNNING




5

TO START PARTICULAR MACHINE, RIGHT CLICK ON THE CORRESPONDING VM, THEN CLICK START




6

AFTER FEW SECONDS, THEN **GREEN** BULLET WILL COME OUT, MEANING VM ALREADY STARTED/RUNNING



Revision No	Revision Date	Title	Prepared	Checked	Approved
REV00-00	23/10/2020	WORK INSTRUCTIONS ON VIRTUAL SERVER DISASTER RECOVERY	RK	MY	CV


IF CERTAIN VM IS NOT SHOWN IN THE DELTAV VIRTUAL STUDIO, THEN WE HAVE TO ENTER TO "FAIL OVER CLUSTER MANAGER" SOFTWARE



IN THE FAILOVER CLUSTER MANAGER, FIND THE VM THAT FAILED TO START IN THE "ROLES" UNDER CORRESPONDING CLUSTERDC, FOR EXAMPLE HERE IN CLUSTERDC2, THERE IS FAIL VM, I.E. CB-OWS2. ITS STATUS IS **OFF**



TO START THIS CB-OWS2 MACHINE, ON THE RIGHT PANE, CLICK ON THE "CB-OWS2", THEN CLICK "CONNECT..."



AFTER FEW SECONDS, THEN THE STATUS OF "CB-OWS2 VM CHANGE TO RUNNING. THE MACHINE NOW CAN BE USED

