







 PT. MNA SERANG	WORKING INSTRUCTION Level Switch Reactive Maintenance	WI/MNASRG-E&I-19-107	
		Dept.	ENGINEERING
		Section	E&I
		Revision	0
		Effective Date	
		Page	1 of 1 page

Instruksi / <i>Instruction</i>	
Persiapan Alignment / <i>Prepare of Alignment Process</i>	
	
Siapkan peralatan dan APD (<i>Prepare equipment and APD</i>)	Identification: Kealahan pada pembacaan level switch (<i>Incorrectly Switch</i>)
Pengecekan Elemen Sensor/ <i>Sensor Element Checking</i>	
	
1. Periksa catu daya pada komponen elektronik level switch <i>Check the power supply; (check the load on direct load switching electronics).</i>	2. Atur ke mode awal pada koil elektronik level switch <i>Set the correct mode on the electronics coil</i>
	
3. Cek probe level switch <i>check level switch probe</i>	4. Reset dan tunggu 5 detik <i>Reset and wait 5 second</i>
	
5. Jika tidak bisa berfungsi kembali, ganti level switch <i>Replace the level switch</i>	6. Ganti level switch baru dan lakukan kalibrasi <i>Fit the factory supplied cassette and then calibrate.</i>