


 PT. MNA SERANG	WORKING INSTRUCTION	WI/MNASRG-E&I-19-202	
	DELTA V DCS RIO INTERFACE RM	Dept.	ENGINEERING
		Section	E&I
		Revision	0
		Effective Date	01-Sep-19
		Page	1 of 2

Identifikasi / Identification	
	
LED Integrity pada layer Diagnostic berwarna merah (<i>Integrity LED on Diagnostic screen turns red</i>)	LED Error dari Modul RIO Interface berwarna merah (<i>RIO Interface Error LED module turns red</i>)
Reset Modul / Modul Reset	
 	 
Kendurkan Sekrup dan check secara manual (<i>Loosen the screw and check Manually</i>)	Lepaskan Modul & pastikan tidak ada pin yang rusak (<i>Unplug the modul & make sure no pin(s) bended</i>)
 	
Kencangkan Sekrup dan check secara manual (<i>Tighten the screw and check manually</i>)	Pasang kembali RIO card & Check modul HMI(<i>Re-Plug the RIO Card & Check the HMI Modul</i>)