


DELTA V DCS SYSTEM HARDWARE MONITORING


First step: Klik tombol "Start" dan pilih deltaV Run
(Click the start button, and choose DeltaV Run)




Second step: Periksa apakah ada alarm pada bagian bawah HMI (Check if there's any alarm on the lower side of the panel)




Third step: Klik alarm yang muncul, catat indikasi & "advise" (Click the alarm shown, note down the indication & advise)




Fourth step : Klik ikon "Condition Summary" (Click the "condition summary" icon)




Fifth step: Periksa apakah error yang muncul pada hardware, lalu catat (Check if there's any error shown, then note it down)



Sixth step: Klik tombol "Start" dan pilih deltaV Explorer (Click the start button, and choose DeltaV Explorer)



Seventh step: Periksa & catat indikasi warning yang terlihat (Check & note the Warning Indication Shown)



Last step: Koordinasi dengan tim operasional (Coordination with operational team)

