

IO List - Loading/Unloading

Wilmar Industrial Complex PT MNA Serang, Indonesia

End Customer: Wilmar Industrial Complex PT MNA
Serang, Indonesia

End Customer Reference Number:

Document File Name: 3258585-PSS-PASH-DWG-00051

Document Status: For Final

Authorisations

	Name	Function	Signature
Developed By:	Zul Hasyidi Hassan	Project Engineer	ZHH 
Reviewed By:	Liow Kok Loong	Lead Engineer	LKL 
Released By:	Mohd. Nazim Ismail	Project Manager	MNI 

Distribution

Name	Company	Name	Company

Revision History

Rev	Status	Description	Date	Developed By	Reviewed By
A	For Review	Issued for Review	9-Nov-18	ZHH	LKL
0	For Final	Issued for Final	27-Sep-19	ZHH	LKL

© Emerson Automation Solution. All rights reserved. Unauthorized duplication, in whole or in part, is prohibited. Trademarks identified in this document are owned by one of the Emerson Process Management group of companies. Unless otherwise agreed to in writing by the parties, any information provided in this document is confidential or proprietary and may not be used or disclosed without the expressed written permission of Emerson Process Management.

Emerson Automation Solution
Process System and Solutions

No. 1, Block A, Jalan SS13/5, SS13
Subang Jaya, 47500, Selangor
Malaysia
T +60 (3) 5624-2888
F +60 (3) 5638-1010
www.EmersonProcess.com

Emerson Automation Solution - Confidential and Proprietary

										RIO CABINET										SYSTEM CABINET						
										Marshalling				Relay				DELTA V				DELTA V				
Vendor's tags	Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	Range Proposed (kg/H)	Signal Type	Electrical Connection	Cabinet Name	TB Name	Term. (+)	Term. (-)	24V(+) Term.	24V(-) Term.	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)	Cabinet Name	Controller
FT-90302	FT90302	LU1-FT90302	LU1_FT90302		Flow Meter	AI		4-20 mA HART	2 wire	LU1-RIO-001	TB-AI	55	56								S2	12	23	24	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	57	58								S2	13	25	26	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	59	60								S2	14	27	28	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	61	62								S2	15	29	30	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	63	64								S2	16	31	32	REF-DCS-001	REF-CTRL1_1
FT-92001A	FT92001A	TF1-FT92001A	TF1_FT92001A		Flow Meter	AI	0- 125 m3/h	4-20 mA HART	4 wire	LU1-RIO-001	TB-AI	65	66								S3	1	1	2	REF-DCS-001	REF-CTRL1_1
FT-92009A	FT92009A	TF1-FT92009A	TF1_FT92009A		Flow Meter	AI	0- 125 m3/h	4-20 mA HART	4 wire	LU1-RIO-001	TB-AI	67	68								S3	2	3	4	REF-DCS-001	REF-CTRL1_1
FT-92004A	FT92004A	TF1-FT92004A	TF1_FT92004A		Flow Meter	AI	0- 125 m3/h	4-20 mA HART	4 wire	LU1-RIO-001	TB-AI	69	70								S3	3	5	6	REF-DCS-001	REF-CTRL1_1
FT-92011A	FT92011A	TF1-FT92011A	TF1_FT92011A		Flow Meter	AI	0- 125 m3/h	4-20 mA HART	4 wire	LU1-RIO-001	TB-AI	71	72								S3	4	7	8	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	73	74								S3	5	9	10	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	75	76								S3	6	11	12	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	77	78								S3	7	13	14	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	79	80								S3	8	15	16	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	81	82								S3	9	17	18	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	83	84								S3	10	19	20	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	85	86								S3	11	21	22	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	87	88								S3	12	23	24	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	89	90								S3	13	25	26	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	91	92								S3	14	27	28	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	93	94								S3	15	29	30	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AI	95	96								S3	16	31	32	REF-DCS-001	REF-CTRL1_1
TCV-2401	TCV2401	LU1-TCV2401	LU1_TT2401		Control Valve	AO		4-20 mA HART	2 wire	LU1-RIO-001	TB-AO	1	2								S5	1	1	2	REF-DCS-001	REF-CTRL1_1
TCV-2402	TCV2402	LU1-TCV2402	LU1_TT2402		Control Valve	AO		4-20 mA HART	2 wire	LU1-RIO-001	TB-AO	3	4								S5	2	3	4	REF-DCS-001	REF-CTRL1_1
TCV-2403	TCV2403	LU1-TCV2403	LU1_TT2403		Control Valve	AO		4-20 mA HART	2 wire	LU1-RIO-001	TB-AO	5	6								S5	3	5	6	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AO	7	8								S5	4	7	8	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AO	9	10								S5	5	9	10	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AO	11	12								S5	6	11	12	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AO	13	14								S5	7	13	14	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-001	TB-AO	15	16								S5	8	15	16	REF-DCS-001	REF-CTRL1_1
SV-2401A	V2401A-ZO	LU1-V2401A-ZO	LU1_V2401A		Actuated Valve	DI		DI Dry Contact	2 wire	LU1-RIO-002	TB-DI	1	2								S1	1	1	NA	REF-DCS-001	REF-CTRL1_1
SV-2401A	V2401A-ZC	LU1-V2401A-ZC	LU1_V2401A		Actuated Valve	DI		DI Dry Contact	2 wire	LU1-RIO-002	TB-DI	3	4								S1	2	2	NA	REF-DCS-001	REF-CTRL1_1
SV-2401B	V2401B-ZO	LU1-V2401B-ZO	LU1_V2401B		Actuated Valve	DI		DI Dry Contact	2 wire	LU1-RIO-002	TB-DI	5	6								S1	3	3	NA	REF-DCS-001	REF-CTRL1_1
SV-2401B	V2401B-ZC	LU1-V2401B-ZC	LU1_V2401B		Actuated Valve	DI		DI Dry Contact	2 wire	LU1-RIO-002	TB-DI	7	8								S1	4	4	NA	REF-DCS-001	REF-CTRL1_1
SV-2401C	V2401C-ZO	LU1-V2401C-ZO	LU1_V2401C		Actuated Valve	DI		DI Dry Contact	2 wire	LU1-RIO-002	TB-DI	9	10								S1	5	5	NA	REF-DCS-001	REF-CTRL1_1
SV-2401C	V2401C-ZC	LU1-V2401C-ZC	LU1_V2401C		Actuated Valve	DI		DI Dry Contact	2 wire	LU1-RIO-002	TB-DI	11	12								S1	6	6	NA	REF-DCS-001	REF-CTRL1_1
SV-2401D	V2401D-ZO	LU1-V2401D-ZO	LU1_V2401D		Actuated Valve	DI		DI Dry Contact	2 wire	LU1-RIO-002	TB-DI	13	14								S1	7	7	NA	REF-DCS-001	REF-CTRL1_1
SV-2401D	V2401D-ZC	LU1-V2401D-ZC	LU1_V2401D		Actuated Valve	DI		DI Dry Contact	2 wire	LU1-RIO-002	TB-DI	15	16								S1	8	8	NA	REF-DCS-001	REF-CTRL1_1
SV-2401E	V2401E-ZO	LU1-V2401E-ZO	LU1_V2401E		Actuated Valve	DI		DI Dry Contact	2 wire	LU1-RIO-002	TB-DI	17	18								S1	9	9	NA	REF-DCS-001	REF-CTRL1_1

										RIO CABINET														SYSTEM CABINET		
										Marshalling				Relay				DELTA V				DELTA V				
Vendor's tags	Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	IO Type	Range Proposed (kg/H)	Signal Type	Electrical Connection	Cabinet Name	TB Name	Term. (+)	Term. (-)	24V(+) Term.	24V(-) Term.	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)	Cabinet Name	Controller
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-002	TB-DO	49	50			14	11	RDO1-25	A1	A2	S6	25	25	NA	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-002	TB-DO	51	52			14	11	RDO1-26	A1	A2	S6	26	26	NA	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-002	TB-DO	53	54			14	11	RDO1-27	A1	A2	S6	27	27	NA	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-002	TB-DO	55	56			14	11	RDO1-28	A1	A2	S6	28	28	NA	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-002	TB-DO	57	58			14	11	RDO1-29	A1	A2	S6	29	29	NA	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-002	TB-DO	59	60			14	11	RDO1-30	A1	A2	S6	30	30	NA	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-002	TB-DO	61	62			14	11	RDO1-31	A1	A2	S6	31	31	NA	REF-DCS-001	REF-CTRL1_1
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	LU1-RIO-002	TB-DO	63	64			14	11	RDO1-32	A1	A2	S6	32	32	NA	REF-DCS-001	REF-CTRL1_1