




RP2350

- Power
- Ground
- UART / UART (default)
- GPIO, PIO, and PWM
- ADC
- SPI / SPI (default)
- I2C / I2C (default)
- System Control
- Debugging

Infineon 43439

- GPIO