Generated: 12.04.2023 16:36:05

Legende: Links and Buttons

ein Link	Gleicher Tab. Link innerhalb dieses Dokumentes				
MP Home	Neuer Tab. Die offizielle Micropython Referenz des entsprechenden Modules wird geöffnet				
MP Home highlight	Neuer Tab. Die offizielle Micropython Referenz wird geöffnet und das entsprechende Module highlighted				
MP ESP32 highlight	Neuer Tab. Die ESP32 Micropython Referenz wird geöffnet und das entsprechende Module highlighted				
Extern	Neuer Tab. Intersessante Seite in Bezug zum entsprechenden Micropython Modul wird geöffnet				
Extern highlight	Neuer Tab. Intersessante Seite wird geöffnet und das entsprechende Module highlighted				
YouTube	Neuer Tab. YouTube Clip, welche das Thema behandelt				

Overview of all modules

_boot	esp	onewire	uctypes	upip_utarfile	utime
_onewire	esp32	uarray	uerrno	uplatform	utimeq
_thread	flashbdev	uasyncio/core	uhashlib	upysh	uwebsocket
_uasyncio	framebuf	uasyncio/event	uheapq	urandom	uzlib
_webrepl	gc	uasyncio/funcs	uio	ure	webrepl
apa106	inisetup	uasyncio/lock	ujson	urequests	webrepl_setup
btree	math	uasyncio/stream	umachine	uselect	websocket_helper
builtins	micropython	ubinascii	umqtt/robust	usocket	
cmath	neopixel	ubluetooth	umqtt/simple	ussl	
dht	network	ucollections	uos	ustruct	
ds18x20	ntptime	ucryptolib	upip	usys	

boot

- object <module '_boot' from '_boot.py'> is of type module
- uos -- <module 'uos'>
- __name__ -- _boot
- gc -- <module 'gc'>

- __file__ -- _boot.py
- bdev -- <Partition type=1, subtype=129, address=2097152, size=2097152, label=vfs, encrypted=0>

onewire

- object <module 'onewire'> is of type module
- __name__ -- onewire
- reset -- <function>
- readbit -- <function>
- readbyte -- <function>
- writebit -- <function>
- writebyte -- <function>
- crc8 -- <function>

--> Overview

thread

MP Home

- object <module '_thread'> is of type module
- __name__ -- _thread
- LockType -- <class 'lock'>
- get ident -- <function>
- stack_size -- <function>
- start new thread -- <function>
- exit -- <function>
- allocate_lock -- <function>

--> Overview

_thread --> LockType

- __enter__ -- <function>
- __exit__ -- <function>
- acquire -- <function>
- locked -- <function>
- object <class 'lock'> is of type type
- release -- <function>

--> _thread

--> Overview

_uasyncio

```
object <module '_uasyncio'> is of type module__name__ -- _uasyncio
```

• TaskQueue -- <class 'TaskQueue'>

• Task -- <class 'Task'>

--> Overview

_uasyncio --> TaskQueue

```
• object <class 'TaskQueue'> is of type type
```

- peek -- <function>
- pop -- <function>
- push -- <function>
- remove -- <function>

--> _uasyncio

--> Overview

_uasyncio --> Task

• object <class 'Task'> is of type type

--> _uasyncio

--> Overview

_webrepl

```
object <module '_webrepl'> is of type module
```

```
• __name__ -- _webrepl
```

- webrepl -- <class '_webrepl'>
- password -- <function>

--> Overview

_webrepl --> _webrepl

- close -- <function>
- object <class '_webrepl'> is of type type
- read -- <function>
- readinto -- <function>
- write -- <function>

--> _webrepl

--> Overview

apa106

MP ESP32 highlight

```
• object <module 'apa106' from 'apa106.py'> is of type module
```

```
• APA106 -- <class 'APA106'>
```

- NeoPixel -- <class 'NeoPixel'>
- __name__ -- apa106
- __file__ -- apa106.py

--> Overview

apa106 --> APA106

MP ESP32 highlight

- ORDER -- (0, 1, 2, 3)
- __module__ -- apa106
- __qualname__ -- APA106
- object <class 'APA106'> is of type type

--> apa106

--> Overview

apa106 --> NeoPixel

MP ESP32 highlight

- ORDER -- (1, 0, 2, 3)
- __getitem__ -- <function __getitem__ at 0x3ffe8e10>
- __init__ -- <function __init__ at 0x3ffe8e20>
- __len__ -- <function __len__ at 0x3ffe8e40>
- __module__ -- neopixel
- __qualname__ -- NeoPixel
- __setitem__ -- <function __setitem__ at 0x3ffe8e00>
- fill -- <function fill at 0x3ffe8e50>
- object <class 'NeoPixel'> is of type type
- write -- <function write at 0x3ffe8e60>

--> apa106

--> Overview

btree

```
object <module 'btree'> is of type module
__name__ -- btree
open -- <function>
INCL -- 1
DESC -- 2
```

builtins

```
• object <module 'builtins'> is of type module
• __name__ -- builtins
• __build_class__ -- <function>
• __import__ -- <function>
__repl_print__ -- <function>
• bool -- <class 'bool'>
• bytes -- <class 'bytes'>
• bytearray -- <class 'bytearray'>
• complex -- <class 'complex'>
dict -- <class 'dict'>
enumerate -- <class 'enumerate'>
• filter -- <class 'filter'>
• float -- <class 'float'>
frozenset -- <class 'frozenset'>
• int -- <class 'int'>
• list -- <class 'list'>
map -- <class 'map'>
memoryview -- <class 'memoryview'>
• object -- <class 'object'>
property -- <class 'property'>
• range -- <class 'range'>
reversed -- <class 'reversed'>
set -- <class 'set'>
• slice -- <class 'slice'>
• str -- <class 'str'>
• super -- <class 'super'>
• tuple -- <class 'tuple'>
type -- <class 'type'>
• zip -- <class 'zip'>
classmethod -- <class 'classmethod'>
• staticmethod -- <class 'staticmethod'>
• Ellipsis -- Ellipsis
• NotImplemented -- NotImplemented
• abs -- <function>
```

- all -- <function>
- any -- <function>
- bin -- <function>
- callable -- <function>
- compile -- <function>
- chr -- <function>
- delattr -- <function>
- dir -- <function>
- divmod -- <function>
- eval -- <function>
- exec -- <function>
- execfile -- <function>
- getattr -- <function>
- setattr -- <function>
- globals -- <function>
- hasattr -- <function>
- hash -- <function>
- help -- <function>
- hex -- <function>
- id -- <function>
- input -- <function>
- isinstance -- <function>
- issubclass -- <function>
- iter -- <function>
- len -- <function>
- locals -- <function>
- max -- <function>
- min -- <function>
- next -- <function>
- oct -- <function>
- open -- <function>
- ord -- <function>
- pow -- <function>
- print -- <function>
- repr -- <function>
- round -- <function>
- sorted -- <function>
- sum -- <function>
- BaseException -- <class 'BaseException'>
- ArithmeticError -- <class 'ArithmeticError'>
- AssertionError -- <class 'AssertionError'>
- AttributeError -- <class 'AttributeError'>
- EOFError -- <class 'EOFError'>
- Exception -- <class 'Exception'>
- GeneratorExit -- <class 'GeneratorExit'>
- ImportError -- <class 'ImportError'>

- IndentationError -- <class 'IndentationError'>
- IndexError -- <class 'IndexError'>
- KeyboardInterrupt -- <class 'KeyboardInterrupt'>
- KeyError -- <class 'KeyError'>
- LookupError -- <class 'LookupError'>
- MemoryError -- <class 'MemoryError'>
- NameError -- <class 'NameError'>
- NotImplementedError -- <class 'NotImplementedError'>
- OSError -- <class 'OSError'>
- OverflowError -- <class 'OverflowError'>
- RuntimeError -- <class 'RuntimeError'>
- StopAsyncIteration -- <class 'StopAsyncIteration'>
- StopIteration -- <class 'StopIteration'>
- SyntaxError -- <class 'SyntaxError'>
- SystemExit -- <class 'SystemExit'>
- TypeError -- <class 'TypeError'>
- UnicodeError -- <class 'UnicodeError'>
- ValueError -- <class 'ValueError'>
- ViperTypeError -- <class 'ViperTypeError'>
- ZeroDivisionError -- <class 'ZeroDivisionError'>

builtins --> bool

MP Home highlight

- object <class 'bool'> is of type type
- --> builtins
- --> Overview

builtins --> bytes

- center -- <function>
- count -- <function>
- decode -- <function>
- endswith -- <function>
- find -- <function>
- format -- <function>
- index -- <function>
- isalpha -- <function>
- isdigit -- <function>
- islower -- <function>
- isspace -- <function>

- isupper -- <function>
- join -- <function>
- lower -- <function>
- lstrip -- <function>
- object <class 'bytes'> is of type type
- partition -- <function>
- replace -- <function>
- rfind -- <function>
- rindex -- <function>
- rpartition -- <function>
- rsplit -- <function>
- rstrip -- <function>
- split -- <function>
- splitlines -- <function>
- startswith -- <function>
- strip -- <function>
- upper -- <function>

--> builtins

--> Overview

builtins --> bytearray

MP Home highlight

- append -- <function>
- decode -- <function>
- extend -- <function>
- object <class 'bytearray'> is of type type

--> builtins

--> Overview

builtins --> complex

MP Home highlight

- object <class 'complex'> is of type type
- --> builtins
- --> Overview

builtins --> dict

- __delitem__ -- <function>
- __getitem__ -- <function>
- __setitem__ -- <function>
- clear -- <function>
- copy -- <function>
- fromkeys -- <classmethod>
- get -- <function>
- items -- <function>
- keys -- <function>
- object <class 'dict'> is of type type
- pop -- <function>
- popitem -- <function>
- setdefault -- <function>
- update -- <function>
- values -- <function>
- --> builtins
- --> Overview

builtins --> enumerate

MP Home highlight

- object <class 'enumerate'> is of type type
- --> builtins
- --> Overview

builtins --> filter

MP Home highlight

- object <class 'filter'> is of type type
- --> builtins
- --> Overview

builtins --> float

- object <class 'float'> is of type type
- --> builtins
- --> Overview

builtins --> frozenset

MP Home highlight

- __contains__ -- <function>
- copy -- <function>
- difference -- <function>
- intersection -- <function>
- isdisjoint -- <function>
- issubset -- <function>
- issuperset -- <function>
- object <class 'frozenset'> is of type type
- symmetric_difference -- <function>
- union -- <function>

--> builtins

--> Overview

builtins --> int

MP Home highlight

- from_bytes -- <classmethod>
- object <class 'int'> is of type type
- to_bytes -- <function>

--> builtins

--> Overview

builtins --> list

MP Home highlight

- append -- <function>
- clear -- <function>
- copy -- <function>
- count -- <function>
- extend -- <function>
- index -- <function>
- insert -- <function>
- object <class 'list'> is of type type
- pop -- <function>
- remove -- <function>
- reverse -- <function>
- sort -- <function>

--> builtins

builtins --> map

MP Home highlight

- object <class 'map'> is of type type
- --> builtins
- --> Overview

builtins --> memoryview

MP Home highlight

- object <class 'memoryview'> is of type type
- --> builtins
- --> Overview

builtins --> object

MP Home highlight

- __delattr__ -- <function>
- __init__ -- <function>
- __new__ -- <staticmethod>
- __setattr__ -- <function>
- object <class 'object'> is of type type
- --> builtins
- --> Overview

builtins --> property

MP Home highlight

- deleter -- <function>
- getter -- <function>
- object <class 'property'> is of type type
- setter -- <function>
- --> builtins
- --> Overview

builtins --> range

MP Home highlight

- object <class 'range'> is of type type
- --> builtins
- --> Overview

builtins --> reversed

MP Home highlight

- object <class 'reversed'> is of type type
- --> builtins
- --> Overview

builtins --> set

MP Home highlight

- __contains__ -- <function>
- add -- <function>
- clear -- <function>
- copy -- <function>
- difference -- <function>
- difference_update -- <function>
- discard -- <function>
- intersection -- <function>
- intersection_update -- <function>
- isdisjoint -- <function>
- issubset -- <function>
- issuperset -- <function>
- object <class 'set'> is of type type
- pop -- <function>
- remove -- <function>
- symmetric_difference -- <function>
- symmetric_difference_update -- <function>
- union -- <function>
- update -- <function>

--> builtins

--> Overview

builtins --> slice

- object <class 'slice'> is of type type
- --> builtins
- --> Overview

builtins --> str

MP Home highlight

Extern

- center -- <function>
- count -- <function>
- encode -- <function>
- endswith -- <function>
- find -- <function>
- format -- <function>
- index -- <function>
- isalpha -- <function>
- isdigit -- <function>
- islower -- <function>
- isspace -- <function>
- isupper -- <function>
- join -- <function>
- lower -- <function>
- lstrip -- <function>
- object <class 'str'> is of type type
- partition -- <function>
- replace -- <function>
- rfind -- <function>
- rindex -- <function>
- rpartition -- <function>
- rsplit -- <function>
- rstrip -- <function>
- split -- <function>
- splitlines -- <function>
- startswith -- <function>
- strip -- <function>
- upper -- <function>

--> builtins

--> Overview

builtins --> super

MP Home highlight

object <class 'super'> is of type type

- --> builtins
- --> Overview

builtins --> tuple

MP Home highlight

- count -- <function>
- index -- <function>
- object <class 'tuple'> is of type type
- --> builtins
- --> Overview

builtins --> type

MP Home highlight

- object <class 'type'> is of type type
- --> builtins
- --> Overview

builtins --> zip

MP Home highlight

- object <class 'zip'> is of type type
- --> builtins
- --> Overview

builtins --> classmethod

MP Home highlight

- object <class 'classmethod'> is of type type
- --> builtins
- --> Overview

builtins --> staticmethod

MP Home highlight

• object <class 'staticmethod'> is of type type

- --> builtins
- --> Overview

builtins --> BaseException

- object <class 'BaseException'> is of type type
- --> builtins
- --> Overview

builtins --> ArithmeticError

Extern highlight

- object <class 'ArithmeticError'> is of type type
- --> builtins
- --> Overview

builtins --> AssertionError

MP Home highlight

- object <class 'AssertionError'> is of type type
- --> builtins
- --> Overview

builtins --> AttributeError

MP Home highlight

- object <class 'AttributeError'> is of type type
- --> builtins
- --> Overview

builtins --> EOFError

Extern highlight

- object <class 'EOFError'> is of type type
- --> builtins
- --> Overview

builtins --> Exception

MP Home highlight

- object <class 'Exception'> is of type type
- --> builtins
- --> Overview

builtins --> GeneratorExit

- object <class 'GeneratorExit'> is of type type
- --> builtins
- --> Overview

builtins --> ImportError

MP Home highlight

- object <class 'ImportError'> is of type type
- --> builtins
- --> Overview

builtins --> IndentationError

Extern highlight

- object <class 'IndentationError'> is of type type
- --> builtins
- --> Overview

builtins --> IndexError

MP Home highlight

- object <class 'IndexError'> is of type type
- --> builtins
- --> Overview

builtins --> KeyboardInterrupt

- object <class 'KeyboardInterrupt'> is of type type
- --> builtins
- --> Overview

builtins --> KeyError

MP Home highlight

- object <class 'KeyError'> is of type type
- --> builtins
- --> Overview

builtins --> LookupError

Extern highlight

- object <class 'LookupError'> is of type type
- --> builtins
- --> Overview

builtins --> MemoryError

MP Home highlight

- object <class 'MemoryError'> is of type type
- --> builtins
- --> Overview

builtins --> NameError

MP Home highlight

- object <class 'NameError'> is of type type
- --> builtins
- --> Overview

builtins --> NotImplementedError

MP Home highlight

object <class 'NotImplementedError'> is of type type

- --> builtins
- --> Overview

builtins --> OSError

MP Home highlight

- object <class 'OSError'> is of type type
- --> builtins
- --> Overview

builtins --> OverflowError

Extern highlight

- object <class 'OverflowError'> is of type type
- --> builtins
- --> Overview

builtins --> RuntimeError

MP Home highlight

- object <class 'RuntimeError'> is of type type
- --> builtins
- --> Overview

builtins --> StopAsyncIteration

- object <class 'StopAsyncIteration'> is of type type
- --> builtins
- --> Overview

builtins --> StopIteration

- object <class 'StopIteration'> is of type type
- --> builtins
- --> Overview

builtins --> SyntaxError

MP Home highlight

- object <class 'SyntaxError'> is of type type
- --> builtins
- --> Overview

builtins --> SystemExit

MP Home highlight

- object <class 'SystemExit'> is of type type
- --> builtins
- --> Overview

builtins --> TypeError

MP Home highlight

- object <class 'TypeError'> is of type type
- --> builtins
- --> Overview

builtins --> UnicodeError

Extern highlight

- object <class 'UnicodeError'> is of type type
- --> builtins
- --> Overview

builtins --> ValueError

MP Home highlight

- object <class 'ValueError'> is of type type
- --> builtins
- --> Overview

builtins --> ViperTypeError

- object <class 'ViperTypeError'> is of type type
- --> builtins
- --> Overview

builtins --> ZeroDivisionError

MP Home highlight

- object <class 'ZeroDivisionError'> is of type type
- --> builtins
- --> Overview

cmath

MP Home

- object <module 'cmath'> is of type module
- __name__ -- cmath
- e -- 2.718282
- pi -- 3.141593
- phase -- <function>
- polar -- <function>
- rect -- <function>
- exp -- <function>
- log -- <function>
- log10 -- <function>
- sqrt -- <function>
- cos -- <function>
- sin -- <function>

--> Overview

dht

MP ESP32 highlight

- object <module 'dht' from 'dht.py'> is of type module
- DHTBase -- <class 'DHTBase'>
- __name__ -- dht
- __file__ -- dht.py
- sys -- <module 'sys'>
- DHT11 -- <class 'DHT11'>
- dht_readinto -- <function>

• DHT22 -- <class 'DHT22'>

--> Overview

dht --> DHTBase

- __init__ -- <function __init__ at 0x3fff9e20>
- __module__ -- dht
- __qualname__ -- DHTBase
- measure -- <function measure at 0x3fff9e10>
- object <class 'DHTBase'> is of type type

--> dht

--> Overview

dht --> DHT11

MP ESP32 highlight

- __module__ -- dht
- __qualname__ -- DHT11
- humidity -- <function humidity at 0x3fff9ed0>
- object <class 'DHT11'> is of type type
- temperature -- <function temperature at 0x3fff9ec0>

--> dht

--> Overview

dht --> DHT22

MP ESP32 highlight

- __module__ -- dht
- __qualname__ -- DHT22
- humidity -- <function humidity at 0x3fff9f80>
- object <class 'DHT22'> is of type type
- temperature -- <function temperature at 0x3fff9f70>

--> dht

--> Overview

ds18x20

MP ESP32 highlight

• object <module 'ds18x20' from 'ds18x20.py'> is of type module

- const -- <function>
- DS18X20 -- <class 'DS18X20'>
- __name__ -- ds18x20
- __file__ -- ds18x20.py

ds18x20 --> DS18X20

MP ESP32 highlight

- __init__ -- <function __init__ at 0x3fffb5a0>
- __module__ -- ds18x20
- __qualname__ -- DS18X20
- convert_temp -- <function convert_temp at 0x3fffb5d0>
- object <class 'DS18X20'> is of type type
- read_scratch -- <function read_scratch at 0x3fffb5b0>
- read_temp -- <function read_temp at 0x3fffb5e0>
- scan -- <function scan at 0x3fffb590>
- write_scratch -- <function write_scratch at 0x3fffb5c0>

--> ds18x20

--> Overview

esp

- object <module 'esp'> is of type module
- __name__ -- esp
- osdebug -- <function>
- flash read -- <function>
- flash_write -- <function>
- flash_erase -- <function>
- flash_size -- <function>
- flash_user_start -- <function>
- gpio_matrix_in -- <function>
- gpio_matrix_out -- <function>
- dht_readinto -- <function>
- LOG_NONE -- 0
- LOG_ERROR -- 1
- LOG_WARNING -- 2
- LOG_INFO -- 3
- LOG_DEBUG -- 4
- LOG_VERBOSE -- 5

esp32

MP Home

- object <module 'esp32'> is of type module
- __name__ -- esp32
- wake_on_touch -- <function>
- wake_on_ext0 -- <function>
- wake_on_ext1 -- <function>
- gpio_deep_sleep_hold -- <function>
- raw_temperature -- <function>
- hall_sensor -- <function>
- idf_heap_info -- <function>
- NVS -- <class 'NVS'>
- Partition -- <class 'Partition'>
- RMT -- <class 'RMT'>
- ULP -- <class 'ULP'>
- WAKEUP_ALL_LOW -- False
- WAKEUP_ANY_HIGH -- True
- HEAP_DATA -- 4
- HEAP_EXEC -- 1

--> Overview

esp32 --> NVS

Extern

MP Home highlight



YouTube

- commit -- <function>
- erase_key -- <function>
- get_blob -- <function>
- get_i32 -- <function>
- object <class 'NVS'> is of type type
- set blob -- <function>
- set_i32 -- <function>

--> esp32

--> Overview

esp32 --> Partition

MP Home highlight

• BOOT -- 0

- RUNNING -- 1
- TYPE_APP -- 0
- TYPE DATA -- 1
- find -- <staticmethod>
- get_next_update -- <function>
- info -- <function>
- ioctl -- <function>
- mark_app_valid_cancel_rollback -- <classmethod>
- object <class 'Partition'> is of type type
- readblocks -- <function>
- set boot -- <function>
- writeblocks -- <function>

--> esp32

--> Overview

esp32 --> RMT

MP ESP32 highlight

- __del__ -- <function>
- bitstream_channel -- <staticmethod>
- clock_div -- <function>
- deinit -- <function>
- loop -- <function>
- object <class 'RMT'> is of type type
- source freq -- <function>
- wait_done -- <function>
- write_pulses -- <function>

--> esp32

--> Overview

esp32 --> ULP

MP ESP32 highlight

- RESERVE_MEM -- 512
- load_binary -- <function>
- object <class 'ULP'> is of type type
- run -- <function>
- set_wakeup_period -- <function>

--> esp32

--> Overview

flashbdev

Extern highlight

- object <module 'flashbdev' from 'flashbdev.py'> is of type module
- Partition -- <class 'Partition'>
- bdev -- <Partition type=1, subtype=129, address=2097152, size=2097152, label=vfs, encrypted=0>
- __name__ -- flashbdev
- __file__ -- flashbdev.py

--> Overview

flashbdev --> Partition

Extern highlight

- BOOT -- 0
- RUNNING -- 1
- TYPE APP -- 0
- TYPE_DATA -- 1
- find -- <staticmethod>
- get_next_update -- <function>
- info -- <function>
- ioctl -- <function>
- mark_app_valid_cancel_rollback -- <classmethod>
- object <class 'Partition'> is of type type
- readblocks -- <function>
- set_boot -- <function>
- writeblocks -- <function>

--> flashbdev

--> Overview

framebuf

- object <module 'framebuf'> is of type module
- __name__ -- framebuf
- FrameBuffer -- <class 'FrameBuffer'>
- FrameBuffer1 -- <function>
- MVLSB -- 0
- MONO_VLSB -- 0
- RGB565 -- 1

- GS2_HMSB -- 5
- GS4_HMSB -- 2
- GS8 -- 6
- MONO_HLSB -- 3
- MONO_HMSB -- 4

framebuf --> FrameBuffer

Extern MP Home YouTube

- blit -- <function>
- fill -- <function>
- fill_rect -- <function>
- hline -- <function>
- line -- <function>
- object <class 'FrameBuffer'> is of type type
- pixel -- <function>
- rect -- <function>
- scroll -- <function>
- text -- <function>
- vline -- <function>

--> framebuf

--> Overview

gc

MP Home

- object <module 'gc'> is of type module
- __name__ -- gc
- collect -- <function>
- disable -- <function>
- enable -- <function>
- isenabled -- <function>
- mem_free -- <function>
- mem_alloc -- <function>
- threshold -- <function>

--> Overview

inisetup

Extern

- object <module 'inisetup' from 'inisetup.py'> is of type module
- bdev -- <Partition type=1, subtype=129, address=2097152, size=2097152, label=vfs, encrypted=0>
- __name__ -- inisetup
- __file__ -- inisetup.py
- uos -- <module 'uos'>
- fs_corrupted -- <function fs_corrupted at 0x3ffe7980>
- setup -- <function setup at 0x3ffe7990>
- check_bootsec -- <function check_bootsec at 0x3ffe79a0>

--> Overview

math

- object <module 'math'> is of type module
- __name__ -- math
- e -- 2.718282
- pi -- 3.141593
- tau -- 6.283185
- inf -- inf
- nan -- nan
- sqrt -- <function>
- pow -- <function>
- exp -- <function>
- expm1 -- <function>
- log -- <function>
- log2 -- <function>
- log10 -- <function>
- cosh -- <function>
- sinh -- <function>
- tanh -- <function>
- acosh -- <function>
- asinh -- <function>
- atanh -- <function>
- cos -- <function>
- sin -- <function>
- tan -- <function>
- acos -- <function>
- asin -- <function>
- atan -- <function>atan2 -- <function>
- ceil -- <function>

- copysign -- <function>
- fabs -- <function>
- floor -- <function>
- fmod -- <function>
- frexp -- <function>
- ldexp -- <function>
- modf -- <function>
- isfinite -- <function>
- isinf -- <function>
- isnan -- <function>
- isclose -- <function>
- trunc -- <function>
- radians -- <function>
- degrees -- <function>
- factorial -- <function>
- erf -- <function>
- erfc -- <function>
- gamma -- <function>
- lgamma -- <function>

micropython

MP Home

- object <module 'micropython'> is of type module
- __name__ -- micropython
- const -- <function>
- opt_level -- <function>
- mem_info -- <function>
- qstr_info -- <function>
- stack_use -- <function>
- alloc_emergency_exception_buf -- <function>
- heap_lock -- <function>
- heap_unlock -- <function>
- kbd_intr -- <function>
- schedule -- <function>

--> Overview

neopixel

MP Home

• object <module 'neopixel' from 'neopixel.py'> is of type module

- bitstream -- <function>
- NeoPixel -- <class 'NeoPixel'>
- __name__ -- neopixel
- __file__ -- neopixel.py

neopixel --> NeoPixel

MP ESP32 highlight

- ORDER -- (1, 0, 2, 3)
- __getitem__ -- <function __getitem__ at 0x3ffe8e10>
- __init__ -- <function __init__ at 0x3ffe8e20>
- __len__ -- <function __len__ at 0x3ffe8e40>
- __module__ -- neopixel
- __qualname__ -- NeoPixel
- __setitem__ -- <function __setitem__ at 0x3ffe8e00>
- fill -- <function fill at 0x3ffe8e50>
- object <class 'NeoPixel'> is of type type
- write -- <function write at 0x3ffe8e60>

--> neopixel

--> Overview

network

- object <module 'network'> is of type module
- __name__ -- network
- __init__ -- <function>
- WLAN -- <function>
- LAN -- <function>
- PPP -- <function>
- phy_mode -- <function>
- STA_IF -- 0
- AP_IF -- 1
- MODE_11B -- 1
- MODE 11G -- 2
- MODE_11N -- 4
- AUTH_OPEN -- 0
- AUTH_WEP -- 1
- AUTH_WPA_PSK -- 2
- AUTH_WPA2_PSK -- 3
- AUTH_WPA_WPA2_PSK -- 4

- AUTH_WPA2_ENTERPRISE -- 5
- AUTH_WPA3_PSK -- 6
- AUTH WPA2 WPA3 PSK -- 7
- AUTH_MAX -- 8
- PHY_LAN8720 -- 0
- PHY_IP101 -- 1
- PHY_RTL8201 -- 2
- PHY_DP83848 -- 3
- ETH_INITIALIZED -- 0
- ETH_STARTED -- 1
- ETH STOPPED -- 2
- ETH_CONNECTED -- 3
- ETH_DISCONNECTED -- 4
- ETH_GOT_IP -- 5
- STAT_IDLE -- 1000
- STAT_CONNECTING -- 1001
- STAT_GOT_IP -- 1010
- STAT_NO_AP_FOUND -- 201
- STAT_WRONG_PASSWORD -- 202
- STAT_BEACON_TIMEOUT -- 200
- STAT_ASSOC_FAIL -- 203
- STAT_HANDSHAKE_TIMEOUT -- 204

ntptime

Extern

Extern

- object <module 'ntptime' from 'ntptime.py'> is of type module
- socket -- <module 'usocket'>
- NTP_DELTA -- 3155673600
- struct -- <module 'ustruct'>
- __name__ -- ntptime
- __file__ -- ntptime.py
- host -- pool.ntp.org
- time -- <function time at 0x3ffe7930>
- settime -- <function settime at 0x3ffed280>

--> Overview

onewire

MP ESP32 highlight

• object <module 'onewire' from 'onewire.py'> is of type module

```
• __name__ -- onewire
• _ow -- <module 'onewire'>
• OneWireError -- <class 'OneWireError'>
• __file__ -- onewire.py
• OneWire -- <class 'OneWire'>
```

onewire --> OneWireError

```
• __module__ -- onewire
• __qualname__ -- OneWireError

    object <class 'OneWireError'> is of type type
```

--> onewire

--> Overview

onewire --> OneWire

MP ESP32 highlight

```
• MATCH_ROM -- 85
• SEARCH ROM -- 240
• SKIP_ROM -- 204
• __init__ -- <function __init__ at 0x3ffedb60>
• __module__ -- onewire
• __qualname__ -- OneWire
_search_rom -- <function _search_rom at 0x3ffedc20>
• crc8 -- <function crc8 at 0x3ffedc30>

    object <class 'OneWire'> is of type type

• readbit -- <function readbit at 0x3ffedb80>
• readbyte -- <function readbyte at 0x3ffedb90>
```

- writebit -- <function writebit at 0x3ffedbb0>

• readinto -- <function readinto at 0x3ffedba0>

 reset -- <function reset at 0x3ffedbc0> • scan -- <function scan at 0x3ffedc10>

write -- <function write at 0x3ffedbf0>

writebyte -- <function writebyte at 0x3ffedbe0>

select_rom -- <function select_rom at 0x3ffedc00>

--> onewire

--> Overview

uarray

- object <module 'uarray'> is of type module
- __name__ -- uarray
- array -- <class 'array'>

uarray --> array

MP Home

- append -- <function>
- decode -- <function>
- extend -- <function>
- object <class 'array'> is of type type

--> uarray

--> Overview

uasyncio/core

• select -- <module 'uselect'>

MP Home Extern Extern • object <module 'uasyncio/core' from 'uasyncio/core.py'> is of type module • sys -- <module 'sys'> • Task -- <class 'Task'> new_event_loop -- <function new_event_loop at 0x3fff00d0> • _promote_to_task -- <function _promote_to_task at 0x3fff0050> name -- uasyncio/core • run -- <function run at 0x3ffeff30> current_task -- <function current_task at 0x3fff00c0> _task_queue -- <TaskQueue> • _io_queue -- <IOQueue object at 3fff00f0> sleep_ms -- <function sleep_ms at 0x3ffefe20> • sleep -- <function sleep at 0x3ffefe60> • ticks add -- <function> • _exc_context -- {'future': None, 'message': "Task exception wasn't retrieved", 'exception': None} • ticks diff -- <function> • TaskQueue -- <class 'TaskQueue'> SingletonGenerator -- <class 'SingletonGenerator'> TimeoutError -- <class 'TimeoutError'> file -- uasyncio/core.py • _stopper -- <generator> Loop -- <class 'Loop'> • IOQueue -- <class 'IOQueue'>

- _stop_task -- None
- CancelledError -- <class 'CancelledError'>
- get_event_loop -- <function get_event_loop at 0x3fff0240>
- run_until_complete -- <function run_until_complete at 0x3ffeff10>
- ticks -- <function>
- create_task -- <function create_task at 0x3fff00b0>

uasyncio/core --> Task

MP Home

- object <class 'Task'> is of type type
- --> uasyncio/core
- --> Overview

uasyncio/core --> TaskQueue

MP Home

- object <class 'TaskQueue'> is of type type
- peek -- <function>
- pop -- <function>
- push -- <function>
- remove -- <function>

--> uasyncio/core

--> Overview

uasyncio/core --> SingletonGenerator

MP Home

- __init__ -- <function __init__ at 0x3ffefe50>
- __iter__ -- <function __iter__ at 0x3ffefe40>
- __module__ -- uasyncio/core
- __next__ -- <function __next__ at 0x3ffefe80>
- __qualname__ -- SingletonGenerator
- object <class 'SingletonGenerator'> is of type type

--> uasyncio/core

--> Overview

uasyncio/core --> TimeoutError

MP Home

- __module__ -- uasyncio/core
- __qualname__ -- TimeoutError
- object <class 'TimeoutError'> is of type type

--> uasyncio/core

--> Overview

uasyncio/core --> Loop

MP Home

- __module__ -- uasyncio/core
- __qualname__ -- Loop
- _exc_handler -- None
- call_exception_handler -- <function call_exception_handler at 0x3fff01e0>
- close -- <function close at 0x3fff01a0>
- create_task -- <function create_task at 0x3ffeff70>
- default_exception_handler -- <function default_exception_handler at 0x3fff01d0>
- get_exception_handler -- <function get_exception_handler at 0x3fff01c0>
- object <class 'Loop'> is of type type
- run_forever -- <function run_forever at 0x3ffeff80>
- run_until_complete -- <function run_until_complete at 0x3fff0180>
- set_exception_handler -- <function set_exception_handler at 0x3fff01b0>
- stop -- <function stop at 0x3fff0190>

--> uasyncio/core

--> Overview

uasyncio/core --> IOQueue

MP Home

- __init__ -- <function __init__ at 0x3ffeffb0>
- __module__ -- uasyncio/core
- __qualname__ -- IOQueue
- _dequeue -- <function _dequeue at 0x3ffeffe0>
- _enqueue -- <function _enqueue at 0x3ffeffa0>
- object <class 'IOQueue'> is of type type
- queue_read -- <function queue_read at 0x3ffeffc0>
- queue_write -- <function queue_write at 0x3ffeffd0>
- remove -- <function remove at 0x3ffefff0>
- wait io event -- <function wait io event at 0x3fff0000>

--> uasyncio/core

uasyncio/core --> CancelledError

MP Home

- __module__ -- uasyncio/core
- __qualname__ -- CancelledError
- object <class 'CancelledError'> is of type type

--> uasyncio/core

--> Overview

uasyncio/event

MP Home

- object <module 'ubinascii'> is of type module
- __name__ -- ubinascii
- hexlify -- <function>
- unhexlify -- <function>
- a2b_base64 -- <function>
- b2a_base64 -- <function>
- crc32 -- <function>

--> Overview

ubluetooth

MP Home

- object <module 'ubluetooth'> is of type module
- __name__ -- ubluetooth
- BLE -- <class 'BLE'>
- UUID -- <class 'UUID'>
- FLAG_READ -- 2
- FLAG WRITE -- 8
- FLAG_NOTIFY -- 16
- FLAG INDICATE -- 32
- FLAG_WRITE_NO_RESPONSE -- 4

--> Overview

ubluetooth --> BLE

- active -- <function>
- config -- <function>
- gap_advertise -- <function>
- gap_connect -- <function>
- gap_disconnect -- <function>
- gap_scan -- <function>
- gattc_discover_characteristics -- <function>
- gattc_discover_descriptors -- <function>
- gattc_discover_services -- <function>
- gattc_exchange_mtu -- <function>
- gattc_read -- <function>
- gattc_write -- <function>
- gatts_indicate -- <function>
- gatts_notify -- <function>
- gatts_read -- <function>
- gatts_register_services -- <function>
- gatts_set_buffer -- <function>
- gatts_write -- <function>
- irq -- <function>
- object <class 'BLE'> is of type type

--> ubluetooth

--> Overview

ubluetooth --> UUID

MP Home

- object <class 'UUID'> is of type type
- --> ubluetooth
- --> Overview

ucollections

MP Home

- object <module 'ucollections'> is of type module
- __name__ -- ucollections
- deque -- <class 'deque'>
- namedtuple -- <function>
- OrderedDict -- <class 'OrderedDict'>

--> Overview

ucollections --> deque

MP Home highlight

- append -- <function>
- object <class 'deque'> is of type type
- popleft -- <function>
- --> ucollections
- --> Overview

ucollections --> OrderedDict

MP Home

MP Home highlight

- __delitem__ -- <function>
- __getitem__ -- <function>
- __setitem__ -- <function>
- clear -- <function>
- copy -- <function>
- fromkeys -- <classmethod>
- get -- <function>
- items -- <function>
- keys -- <function>
- object <class 'OrderedDict'> is of type type
- pop -- <function>
- popitem -- <function>
- setdefault -- <function>
- update -- <function>
- values -- <function>

--> ucollections

--> Overview

ucryptolib

MP Home

- object <module 'ucryptolib'> is of type module
- __name__ -- ucryptolib
- aes -- <class 'aes'>

--> Overview

ucryptolib --> aes

MP Home

MP Home highlight

Extern

- decrypt -- <function>
- encrypt -- <function>
- object <class 'aes'> is of type type

--> ucryptolib

--> Overview

uctypes

- object <module 'uctypes'> is of type module
- __name__ -- uctypes
- struct -- <class 'struct'>
- sizeof -- <function>
- addressof -- <function>
- bytes_at -- <function>
- bytearray_at -- <function>
- NATIVE -- 2
- LITTLE_ENDIAN -- 0
- BIG_ENDIAN -- 1
- VOID -- 0
- UINT8 -- 0
- INT8 -- 134217728
- UINT16 -- 268435456
- INT16 -- 402653184
- UINT32 -- 536870912
- INT32 -- 671088640
- UINT64 -- 805306368
- INT64 -- 939524096
- BFUINT8 -- -1073741824
- BFINT8 -- -939524096
- BFUINT16 -- -805306368
- BFINT16 -- -671088640
- BFUINT32 -- -536870912
- BFINT32 -- -402653184
- BF_POS -- 17
- BF_LEN -- 22
- FLOAT32 -- -268435456
- FLOAT64 -- -134217728
- SHORT -- 402653184
- USHORT -- 268435456
- INT -- 671088640
- UINT -- 536870912
- LONG -- 671088640

- ULONG -- 536870912
- LONGLONG -- 939524096
- ULONGLONG -- 805306368
- PTR -- 536870912
- ARRAY -- -1073741824

uctypes --> struct

MP ESP32 highlight

• object <class 'struct'> is of type type

--> uctypes

--> Overview

uerrno

- object <module 'uerrno'> is of type module
- __name__ -- uerrno
- errorcode -- {1: 'EPERM', 2: 'ENOENT', 5: 'EIO', 9: 'EBADF', 11: 'EAGAIN', 12: 'ENOMEM', 13: 'EACCES', 17: 'EEXIST', 19: 'ENODEV', 21: 'EISDIR', 22: 'EINVAL', 95: 'EOPNOTSUPP', 112: 'EADDRINUSE', 113: 'ECONNABORTED', 104: 'ECONNRESET', 105: 'ENOBUFS', 128: 'ENOTCONN', 116: 'ETIMEDOUT', 111: 'ECONNREFUSED', 118: 'EHOSTUNREACH', 120: 'EALREADY', 119: 'EINPROGRESS'}
- EPERM -- 1
- ENOENT -- 2
- EIO -- 5
- EBADF -- 9
- EAGAIN -- 11
- ENOMEM -- 12EACCES -- 13
- EEXIST -- 17
- ENODEV -- 19
- EISDIR -- 21
- EINVAL -- 22
- EOPNOTSUPP -- 95
- EADDRINUSE -- 112
- ECONNABORTED -- 113
- ECONNRESET -- 104
- ENOBUFS -- 105
- ENOTCONN -- 128
- ETIMEDOUT -- 116

- ECONNREFUSED -- 111
- EHOSTUNREACH -- 118
- EALREADY -- 120
- EINPROGRESS -- 119

uhashlib

MP Home

- object <module 'uhashlib'> is of type module
- __name__ -- uhashlib
- sha256 -- <class 'sha256'>
- sha1 -- <class 'sha1'>

--> Overview

uhashlib --> sha256

MP Home

- digest -- <function>
- object <class 'sha256'> is of type type
- update -- <function>

--> uhashlib

--> Overview

uhashlib --> sha1

MP Home

- digest -- <function>
- object <class 'sha1'> is of type type
- update -- <function>

--> uhashlib

--> Overview

uheapq

- object <module 'uheapq'> is of type module
- __name__ -- uheapq

- heappush -- <function>
- heappop -- <function>
- heapify -- <function>

uio

MP Home

- object <module 'uio'> is of type module
- __name__ -- uio
- open -- <function>
- IOBase -- <class 'IOBase'>
- FileIO -- <class 'FileIO'>
- TextIOWrapper -- <class 'TextIOWrapper'>
- StringIO -- <class 'StringIO'>
- BytesIO -- <class 'BytesIO'>
- BufferedWriter -- <class 'BufferedWriter'>

--> Overview

uio --> IOBase

MP Home

- object <class 'IOBase'> is of type type
- --> uio
- --> Overview

uio --> FileIO

- __del__ -- <function>
- __enter__ -- <function>
- __exit__ -- <function>
- close -- <function>
- flush -- <function>
- object <class 'FileIO'> is of type type
- read -- <function>
- readinto -- <function>
- readline -- <function>
- readlines -- <function>
- seek -- <function>
- tell -- <function>

write -- <function>

--> uio

--> Overview

uio --> TextlOWrapper

MP Home

- __del__ -- <function>
- __enter__ -- <function>
- __exit__ -- <function>
- close -- <function>
- flush -- <function>
- object <class 'TextIOWrapper'> is of type type
- read -- <function>
- readinto -- <function>
- readline -- <function>
- readlines -- <function>
- seek -- <function>
- tell -- <function>
- write -- <function>

--> uio

--> Overview

uio --> StringIO

MP Home

- __enter__ -- <function>
- __exit__ -- <function>
- close -- <function>
- flush -- <function>
- getvalue -- <function>
- object <class 'StringIO'> is of type type
- read -- <function>
- readinto -- <function>
- readline -- <function>
- seek -- <function>
- tell -- <function>
- write -- <function>

--> uio

--> Overview

uio --> BytesIO

MP Home

- __enter__ -- <function>
- __exit__ -- <function>
- close -- <function>
- flush -- <function>
- getvalue -- <function>
- object <class 'BytesIO'> is of type type
- read -- <function>
- readinto -- <function>
- readline -- <function>
- seek -- <function>
- tell -- <function>
- write -- <function>

--> uio

--> Overview

uio --> BufferedWriter

MP Home

- flush -- <function>
- object <class 'BufferedWriter'> is of type type
- write -- <function>

--> uio

--> Overview

ujson

MP Home

- object <module 'ujson'> is of type module
- __name__ -- ujson
- dump -- <function>
- dumps -- <function>
- load -- <function>
- loads -- <function>

--> Overview

umachine

- object <module 'umachine'> is of type module
- __name__ -- umachine
- mem8 -- <8-bit memory>
- mem16 -- <16-bit memory>
- mem32 -- <32-bit memory>
- freq -- <function>
- reset -- <function>
- soft_reset -- <function>
- unique_id -- <function>
- sleep -- <function>
- lightsleep -- <function>
- deepsleep -- <function>
- idle -- <function>
- disable_irq -- <function>
- enable_irq -- <function>
- bitstream -- <function>
- time_pulse_us -- <function>
- Timer -- <class 'Timer'>
- WDT -- <class 'WDT'>
- SDCard -- <class 'SDCard'>
- SLEEP -- 2
- DEEPSLEEP -- 4
- Pin -- <class 'Pin'>
- Signal -- <class 'Signal'>
- TouchPad -- <class 'TouchPad'>
- ADC -- <class 'ADC'>
- ADCBlock -- <class 'ADCBlock'>
- DAC -- <class 'DAC'>
- I2C -- <class 'I2C'>
- SoftI2C -- <class 'SoftI2C'>
- I2S -- <class 'I2S'>
- PWM -- <class 'PWM'>
- RTC -- <class 'RTC'>
- SPI -- <class 'SPI'>
- SoftSPI -- <class 'SoftSPI'>
- UART -- <class 'UART'>
- reset_cause -- <function>
- HARD_RESET -- 2
- PWRON_RESET -- 1
- WDT RESET -- 3
- DEEPSLEEP_RESET -- 4
- SOFT RESET -- 5
- wake_reason -- <function>
- PIN_WAKE -- 2

- EXT0_WAKE -- 2
- EXT1_WAKE -- 3
- TIMER WAKE -- 4
- TOUCHPAD_WAKE -- 5
- ULP_WAKE -- 6

umachine --> Timer

MP Home

- ONE_SHOT -- 0
- PERIODIC -- 1
- __del__ -- <function>
- deinit -- <function>
- init -- <function>
- object <class 'Timer'> is of type type
- value -- <function>

--> umachine

--> Overview

umachine --> WDT

MP Home

- feed -- <function>
- object <class 'WDT'> is of type type

--> umachine

--> Overview

umachine --> SDCard

MP Home

- __del__ -- <function>
- deinit -- <function>
- info -- <function>
- ioctl -- <function>
- object <class 'SDCard'> is of type type
- readblocks -- <function>
- writeblocks -- <function>

--> umachine

--> Overview

umachine --> Pin

MP Home

- DRIVE_0 -- 0
- DRIVE_1 -- 1
- DRIVE_2 -- 2
- DRIVE_3 -- 3
- IN -- 1
- IRQ_FALLING -- 2
- IRQ_RISING -- 1
- OPEN_DRAIN -- 7
- OUT -- 3
- PULL_DOWN -- 1
- PULL_UP -- 2
- WAKE_HIGH -- 5
- WAKE_LOW -- 4
- init -- <function>
- irq -- <function>
- object <class 'Pin'> is of type type
- off -- <function>
- on -- <function>
- value -- <function>

--> umachine

--> Overview

umachine --> Signal

MP Home

- object <class 'Signal'> is of type type
- off -- <function>
- on -- <function>
- value -- <function>

--> umachine

--> Overview

umachine --> TouchPad

- config -- <function>
- object <class 'TouchPad'> is of type type
- read -- <function>

--> umachine

--> Overview

umachine --> ADC

MP Home

- ATTN_0DB -- 0
- ATTN_11DB -- 3
- ATTN_2_5DB -- 1
- ATTN_6DB -- 2
- WIDTH_10BIT -- 10
- WIDTH_11BIT -- 11
- WIDTH_12BIT -- 12
- WIDTH_9BIT -- 9
- atten -- <function>
- block -- <function>
- init -- <function>
- object <class 'ADC'> is of type type
- read -- <function>
- read_u16 -- <function>
- read_uv -- <function>
- width -- <function>

--> umachine

--> Overview

umachine --> ADCBlock

MP Home

- connect -- <function>
- init -- <function>
- object <class 'ADCBlock'> is of type type

--> umachine

--> Overview

umachine --> DAC

MP Home

- object <class 'DAC'> is of type type
- write -- <function>

--> umachine

umachine --> I2C

MP Home

- init -- <function>
- object <class 'I2C'> is of type type
- readfrom -- <function>
- readfrom into -- <function>
- readfrom_mem -- <function>
- readfrom_mem_into -- <function>
- readinto -- <function>
- scan -- <function>
- start -- <function>
- stop -- <function>
- write -- <function>
- writeto -- <function>
- writeto_mem -- <function>
- writevto -- <function>

--> umachine

--> Overview

umachine --> SoftI2C

MP Home

- init -- <function>
- object <class 'SoftI2C'> is of type type
- readfrom -- <function>
- readfrom into -- <function>
- readfrom_mem -- <function>
- readfrom mem into -- <function>
- readinto -- <function>
- scan -- <function>
- start -- <function>
- stop -- <function>
- write -- <function>
- writeto -- <function>
- writeto_mem -- <function>
- writevto -- <function>

--> umachine

--> Overview

umachine --> I2S

- MONO -- 0
- RX -- 9
- STEREO -- 1
- TX -- 5
- deinit -- <function>
- init -- <function>
- irq -- <function>
- object <class 'I2S'> is of type type
- readinto -- <function>
- shift -- <staticmethod>
- write -- <function>

--> umachine

--> Overview

umachine --> PWM

MP Home

- deinit -- <function>
- duty -- <function>
- duty_ns -- <function>
- duty_u16 -- <function>
- freq -- <function>
- init -- <function>
- object <class 'PWM'> is of type type

--> umachine

--> Overview

umachine --> RTC

MP Home

- datetime -- <function>
- init -- <function>
- memory -- <function>
- object <class 'RTC'> is of type type

--> umachine

--> Overview

umachine --> SPI

- LSB -- 1
- MSB -- 0
- deinit -- <function>
- init -- <function>
- object <class 'SPI'> is of type type
- read -- <function>
- readinto -- <function>
- write -- <function>
- write_readinto -- <function>

--> umachine

--> Overview

umachine --> SoftSPI

MP Home

- LSB -- 1
- MSB -- 0
- deinit -- <function>
- init -- <function>
- object <class 'SoftSPI'> is of type type
- read -- <function>
- readinto -- <function>
- write -- <function>
- write_readinto -- <function>

--> umachine

--> Overview

umachine --> UART

- CTS -- 2
- INV_CTS -- 8
- INV_RTS -- 64
- INV_RX -- 4
- INV_TX -- 32
- RTS -- 1
- any -- <function>
- deinit -- <function>
- init -- <function>
- object <class 'UART'> is of type type

- read -- <function>
- readinto -- <function>
- readline -- <function>
- sendbreak -- <function>
- write -- <function>

--> umachine

--> Overview

umqtt/robust

- object <module 'umqtt/simple' from 'umqtt/simple.py'> is of type module
- socket -- <module 'usocket'>
- MQTTClient -- <class 'MQTTClient'>
- struct -- <module 'ustruct'>
- __name__ -- umqtt/simple
- __file__ -- umqtt/simple.py
- hexlify -- <function>
- MOTTException -- <class 'MOTTException'>

--> Overview

umqtt/simple --> MQTTClient

- __init__ -- <function __init__ at 0x3ffeec70>
- __module__ -- umqtt/simple
- __qualname__ -- MQTTClient
- recv len -- <function recv len at 0x3ffeecc0>
- _send_str -- <function _send_str at 0x3ffeec30>
- check msg -- <function check msg at 0x3ffeedb0>
- connect -- <function connect at 0x3ffeece0>
- disconnect -- <function disconnect at 0x3ffeed60>
- object <class 'MQTTClient'> is of type type
- ping -- <function ping at 0x3ffeed20>
- publish -- <function publish at 0x3ffeed40>
- set_callback -- <function set_callback at 0x3ffeeca0>
- set_last_will -- <function set_last_will at 0x3ffeed00>
- subscribe -- <function subscribe at 0x3ffeed80>
- wait_msg -- <function wait_msg at 0x3ffeeda0>

--> umqtt/simple

--> Overview

umqtt/simple --> MQTTException

module -- umqtt/simple

- __qualname__ -- MQTTException
- object <class 'MQTTException'> is of type type

--> umqtt/simple

--> Overview

uos

MP Home

- object <module 'uos'> is of type module
- __name__ -- uos
- uname -- <function>
- urandom -- <function>
- chdir -- <function>
- getcwd -- <function>
- listdir -- <function>
- mkdir -- <function>
- remove -- <function>
- rename -- <function>
- rmdir -- <function>
- stat -- <function>
- statvfs -- <function>
- unlink -- <function>
- dupterm -- <function>
- dupterm_notify -- <function>
- ilistdir -- <function>
- mount -- <function>
- umount -- <function>
- VfsFat -- <class 'VfsFat'>
- VfsLfs2 -- <class 'VfsLfs2'>

--> Overview

uos --> VfsFat

- chdir -- <function>
- getcwd -- <function>
- ilistdir -- <function>
- mkdir -- <function>
- mkfs -- <staticmethod>
- mount -- <function>
- object <class 'VfsFat'> is of type type
- open -- <function>

- remove -- <function>
- rename -- <function>
- rmdir -- <function>
- stat -- <function>
- statvfs -- <function>
- umount -- <function>

--> uos

--> Overview

uos --> VfsLfs2

MP Home

- chdir -- <function>
- getcwd -- <function>
- ilistdir -- <function>
- mkdir -- <function>
- mkfs -- <staticmethod>
- mount -- <function>
- object <class 'VfsLfs2'> is of type type
- open -- <function>
- remove -- <function>
- rename -- <function>
- rmdir -- <function>
- stat -- <function>
- statvfs -- <function>
- umount -- <function>

--> uos

--> Overview

upip

- object <module 'upip' from 'upip.py'> is of type module
- main -- <function main at 0x3ffe5520>
- url_open -- <function url_open at 0x3ffe51c0>
- fatal -- <function fatal at 0x3ffe51f0>
- ussl -- <module 'ussl'>
- usocket -- <module 'usocket'>
- _makedirs -- <function _makedirs at 0x3ffe52e0>
- save file -- <function save file at 0x3ffe5190>
- NotFoundError -- <class 'NotFoundError'>
- os -- <module 'uos'>
- expandhome -- <function expandhome at 0x3ffe51b0>

- __file__ -- upip.py
- cleanup files -- []
- uzlib -- <module 'uzlib'>
- tarfile -- <module 'upip_utarfile' from 'upip_utarfile.py'>
- install -- <function install at 0x3ffe5440>
- install_path -- None
- index_urls -- ['https://micropython.org/pi', 'https://pypi.org/pypi']
- sys -- <module 'sys'>
- __name__ -- upip
- install_pkg -- <function install_pkg at 0x3ffe5210>
- get pkg metadata -- <function get pkg metadata at 0x3ffe51d0>
- cleanup -- <function cleanup at 0x3ffe5500>
- gc -- <module 'gc'>
- file_buf --

- help -- <function help at 0x3ffe5510>
- gzdict sz -- 31
- op_split -- <function op_split at 0x3ffe5220>
- debug -- False
- errno -- <module 'uerrno'>
- install tar -- <function install tar at 0x3ffe51a0>
- json -- <module 'ujson'>

- warn_ussl -- True
- get_install_path -- <function get_install_path at 0x3ffe5460>

upip --> NotFoundError

- __module__ -- upip
- __qualname__ -- NotFoundError
- object <class 'NotFoundError'> is of type type

--> upip

--> Overview

upip_utarfile

- object <module 'upip_utarfile' from 'upip_utarfile.py'> is of type module
- FileSection -- <class 'FileSection'>
- TarInfo -- <class 'TarInfo'>
- __name__ -- upip_utarfile
- TarFile -- <class 'TarFile'>
- DIRTYPE -- dir
- TAR_HEADER -- {'name': (-1073741824, 100), 'size': (-1073741700, 11)}
- uctypes -- <module 'uctypes'>
- __file__ -- upip_utarfile.py
- roundup -- <function roundup at 0x3fff2f30>
- REGTYPE -- file

--> Overview

upip_utarfile --> FileSection

- __init__ -- <function __init__ at 0x3fff2fe0>
- __module__ -- upip_utarfile
- __qualname__ -- FileSection
- object <class 'FileSection'> is of type type
- read -- <function read at 0x3fff3050>
- readinto -- <function readinto at 0x3fff3070>
- skip -- <function skip at 0x3fff3030>

--> upip_utarfile

--> Overview

upip_utarfile --> TarInfo

- __module__ -- upip_utarfile
- __qualname__ -- TarInfo

- __str__ -- <function __str__ at 0x3fff3110>
- object <class 'TarInfo'> is of type type

--> upip_utarfile

--> Overview

upip_utarfile --> TarFile

- __init__ -- <function __init__ at 0x3fff31d0>
- __iter__ -- <function __iter__ at 0x3fff3100>
- __module__ -- upip_utarfile
- __next__ -- <function __next__ at 0x3fff31f0>
- __qualname__ -- TarFile
- extractfile -- <function extractfile at 0x3fff3200>
- next -- <function next at 0x3fff3010>
- object <class 'TarFile'> is of type type

--> upip_utarfile

--> Overview

uplatform

- object <module 'uplatform'> is of type module
- __name__ -- uplatform
- platform -- <function>
- python_compiler -- <function>
- libc_ver -- <function>

--> Overview

upysh

- upysh is intended to be imported using:
- from upysh import *
- To see this help text again, type "man".
- upysh commands:
- pwd, cd("new_dir"), ls, ls(...), head(...), cat(...)
- newfile(...), mv("old", "new"), rm(...), mkdir(...), rmdir(...),
- clear
- object <module 'upysh' from 'upysh.py'> is of type module
- man --
- upysh is intended to be imported using:
- from upysh import *
- To see this help text again, type "man".
- upysh commands:

```
• pwd, cd("new_dir"), ls, ls(...), head(...), cat(...)
• newfile(...), mv("old", "new"), rm(...), mkdir(...), rmdir(...),
• clear
• 1s -- 29 boot.py
• 448 main.py
• 1047 micropython_help.txt
• 1057 micropython_help_02.txt
• 1047 micropython_help_05.txt
• 1463 micropython_help_06.txt
• 0 python_help.txt
__file__ -- upysh.py
• rm -- <function>
• cd -- <function>
• __name__ -- upysh
• clear --
• pwd -- /
• Man -- <class 'Man'>
• mkdir -- <function>
• head -- <function head at 0x3ffed010>
• CLEAR -- <class 'CLEAR'>
• cat -- <function cat at 0x3ffed030>
• mv -- <function>
• sys -- <module 'sys'>
• os -- <module 'uos'>
rmdir -- <function>
• PWD -- <class 'PWD'>
• newfile -- <function newfile at 0x3ffed040>
• LS -- <class 'LS'>
```

upysh --> Man

```
__module__ -- upysh__qualname__ -- Man__repr__ -- <function __repr__ at 0x3ffecfa0>object <class 'Man'> is of type type
```

--> upysh

--> Overview

upysh --> CLEAR

```
__call__ -- <function __call__ at 0x3ffecef0>
__module__ -- upysh
__qualname__ -- CLEAR
__repr__ -- <function __repr__ at 0x3ffecf00>
```

• object <class 'CLEAR'> is of type type

--> upysh

--> Overview

upysh --> PWD

- __call__ -- <function __call__ at 0x3ffece50>
- __module__ -- upysh
- __qualname__ -- PWD
- __repr__ -- <function __repr__ at 0x3ffece60>
- object <class 'PWD'> is of type type

--> upysh

--> Overview

upysh --> LS

- __call__ -- <function __call__ at 0x3ffecdc0>
- __module__ -- upysh
- __qualname__ -- LS
- __repr__ -- <function __repr__ at 0x3ffecd90>
- object <class 'LS'> is of type type

--> upysh

--> Overview

urandom

MP Home

- object <module 'urandom'> is of type module
- __name__ -- urandom
- __init__ -- <function>
- getrandbits -- <function>
- seed -- <function>
- randrange -- <function>
- randint -- <function>
- choice -- <function>
- random -- <function>
- uniform -- <function>

--> Overview

ure

- object <module 'ure'> is of type module
- __name__ -- ure
- compile -- <function>
- match -- <function>
- search -- <function>
- sub -- <function>

--> Overview

urequests

MP ESP32 highlight

- object <module 'urequests' from 'urequests.py'> is of type module
- put -- <function put at 0x3fff24e0>
- post -- <function post at 0x3fff24d0>
- usocket -- <module 'usocket'>
- patch -- <function patch at 0x3fff24f0>
- request -- <function request at 0x3fff24b0>
- __file__ -- urequests.py
- __name__ -- urequests
- delete -- <function delete at 0x3fff2500>
- head -- <function head at 0x3fff2360>
- Response -- <class 'Response'>
- get -- <function get at 0x3fff2370>

--> Overview

urequests --> Response

- __init__ -- <function __init__ at 0x3fff23a0>
- __module__ -- urequests
- __qualname__ -- Response
- close -- <function close at 0x3fff2390>
- content -- content
- json -- <function json at 0x3fff2420>
- object <class 'Response'> is of type type
- text -- <property>

--> urequests

--> Overview

uselect

- object <module 'uselect'> is of type module
- __name__ -- uselect
- select -- <function>
- poll -- <function>
- POLLIN -- 1
- POLLOUT -- 4
- POLLERR -- 8
- POLLHUP -- 16

--> Overview

usocket

MP Home

- object <module 'usocket'> is of type module
- __name__ -- usocket
- __init__ -- <function>
- socket -- <class 'socket'>
- getaddrinfo -- <function>
- AF_INET -- 2
- AF_INET6 -- 10
- SOCK_STREAM -- 1
- SOCK_DGRAM -- 2
- SOCK_RAW -- 3
- IPPROTO_TCP -- 6
- IPPROTO UDP -- 17
- IPPROTO_IP -- 0
- SOL SOCKET -- 4095
- SO_REUSEADDR -- 4
- IP ADD MEMBERSHIP -- 3

--> Overview

usocket --> socket

- __del__ -- <function>
- accept -- <function>
- bind -- <function>
- close -- <function>
- connect -- <function>
- fileno -- <function>

- listen -- <function>
- makefile -- <function>
- object <class 'socket'> is of type type
- read -- <function>
- readinto -- <function>
- readline -- <function>
- recv -- <function>
- recvfrom -- <function>
- send -- <function>
- sendall -- <function>
- sendto -- <function>
- setblocking -- <function>
- setsockopt -- <function>
- settimeout -- <function>
- write -- <function>

--> usocket

--> Overview

ussl

MP Home

- object <module 'ussl'> is of type module
- __name__ -- ussl
- wrap_socket -- <function>

--> Overview

ustruct

MP Home

- object <module 'ustruct'> is of type module
- __name__ -- ustruct
- calcsize -- <function>
- pack -- <function>
- pack into -- <function>
- unpack -- <function>
- unpack_from -- <function>

--> Overview

usys

Hile in Micropython hat fehlgeschlagen

--> Overview

utime

MP Home

```
• object <module 'utime'> is of type module
```

```
• __name__ -- utime
```

- gmtime -- <function>
- localtime -- <function>
- mktime -- <function>
- time -- <function>
- sleep -- <function>
- sleep_ms -- <function>
- sleep_us -- <function>
- ticks_ms -- <function>
- ticks_us -- <function>
- ticks_cpu -- <function>
- ticks_add -- <function>
- ticks_diff -- <function>
- time_ns -- <function>

--> Overview

utimeq

```
• object <module 'utimeq'> is of type module
```

```
• __name__ -- utimeq
```

• utimeq -- <class 'utimeq'>

--> Overview

utimeq --> utimeq

```
• object <class 'utimeq'> is of type type
```

- peektime -- <function>
- pop -- <function>
- push -- <function>

--> utimeq

--> Overview

uwebsocket

- object <module 'uwebsocket'> is of type module
- __name__ -- uwebsocket
- websocket -- <class 'websocket'>

--> Overview

uwebsocket --> websocket

- close -- <function>
- ioctl -- <function>
- object <class 'websocket'> is of type type
- read -- <function>
- readinto -- <function>
- readline -- <function>
- write -- <function>

--> uwebsocket

--> Overview

uzlib

MP Home

- object <module 'uzlib'> is of type module
- __name__ -- uzlib
- decompress -- <function>
- DecompIO -- <class 'DecompIO'>

--> Overview

uzlib --> DecomplO

MP Home

- object <class 'DecompIO'> is of type type
- read -- <function>
- readinto -- <function>
- readline -- <function>

--> uzlib

--> Overview

webrepl

MP ESP32 highlight

Hile in Micropython hat fehlgeschlagen

--> Overview

webrepl_setup

MP ESP32 highlight

Hile in Micropython hat fehlgeschlagen

--> Overview

websocket_helper

- object <module 'websocket_helper' from 'websocket_helper.py'> is of type module
- hashlib -- <module 'uhashlib'>
- binascii -- <module 'ubinascii'>
- __name__ -- websocket_helper
- __file__ -- websocket_helper.py
- sys -- <module 'sys'>
- DEBUG -- 0
- server_handshake -- <function server_handshake at 0x3ffeea90>
- client_handshake -- <function client_handshake at 0x3ffeeaa0>

--> Overview