


Instrument panel junction block:**Fuses**

1. AM1 Fuse
2. POWER Fuse
3. HTR Fuse
4. DEF Fuse
5. GAUGE Fuse
6. -
7. D/L Fuse
8. TAIL Fuse
9. -
10. WIPER Fuse
11. ECU-B Fuse
12. -
13. ACC Fuse
14. ECU-IG Fuse
15. OBD Fuse
16. HAZ Fuse
17. A/C Fuse
18. -
19. -
20. STOP Fuse

Relays

- A. Heater Relay
- B. FLASHER Relay
- C. Power Main Relay
- D. C/OPN Relay