

MOUTH APPLIQUE - INSTRUCTIONS

black crescent 5.09 x 1.19 m - row C only - gores 20 / 1 / 2 - three per-panel pieces, applied FLAT before gore assembly

1. CUT

Cut the three pieces (mouth template pages 1-3, 1:1) from black ripstop. Crescent edges are EXACT - hot-cut them. Only the seam-end extensions carry 25 mm allowance (gore 20: right end; gore 1: both ends; gore 2: left end).

2. ALIGN

Lay each piece on its FLAT panel C using the printed panel-C reference outline; the red dotted lines sit exactly on the panel sew lines.

3. BASTE

Glue-baste or pin. The crescent must run continuously across the three panels when the gores are later joined - check against the layout diagram.

4. SEW

Zigzag the hot-cut crescent edges to the panel (3-step zigzag, black thread). Do NOT zigzag the seam-end extensions - they get caught and sealed inside the gore fells at assembly.

5. ASSEMBLE

Join gores normally; the 25 mm extensions are sewn into the 20/1 and 1/2 fells, hiding the joins. Inspect the crescent alignment before the second stitch row.

Panels are appliqued flat BEFORE gore assembly - this is why each piece is templated per panel with exact crescent edges.