

TURNING VENT PANELS - CUTTING GUIDANCE

the master panel i / panel J patterns carry the vent markings

Vent positions (this design)	seams 15/16 and 16/17, flanking gore 16 - LEFT side, face (gore 1) up
Rows	i and J (spanning the equator)
Inner panels to cut	2 extra PANEL J + 2 extra PANEL i with the vent markings
Inner unit width	2 gores wide: J unit ~5542 mm, i unit ~5601 mm (finished)
Panel heights	J 1372 mm, i 1370 mm (finished)
Triangle sew lines	apex-up on J, vee-down on i, apex at the CENTER LINE
CENTER LINE	= the vent seam; align it to gore seam 15/16 (vent 1) / 16/17 (vent 2)
Lip edges	DOUBLE FOLD OVER TAPE per the printed callouts; 70 mm overlap, J lies OUTSIDE i
Port	R70 vent-line port on panel i (bottom center)
Fabric	+8 m ripstop over the base envelope quantity

The outer envelope panels at gores 15-17 rows i-J are the standard i/J panels;
the vent-marked copies form the inner (overlap) layer sewn along the triangles.

overlap-vent construction, applied to this envelope at seams 15/16 & 16/17