

PARACHUTE - PATTERN DATA & RIGGING

CUT from the master parachute pattern (gore x20 + PARACHUTE CENTRE piece)

Parachute Hole Diameter	5,000 mm / 16 ft 5 in (radius 2,500 mm / 8 ft 2 in)
Parachute seal overlap	360 mm / 14.2 in (radial, all round)
Parachute diameter (finished)	~5,720 mm / 18 ft 9 in
Gores	20 - the master gore has the TOP OPENING REFERENCE LINE showing where it sits in the hole
Confluence Lines (cone)	3,600 mm / 11 ft 10 in x 20
Centering Lines	start at 3,639 mm / 11 ft 11 in (longest); may shorten to 3,598 mm / 11 ft 10 in
Crown Line	31.0 m / 101 ft 8 in (+3 m / 10 ft for knots and handling)
Parachute red line	34.0 m / 111 ft 7 in (+3 m / 10 ft) - opposite side, over apex pulley, down to burner frame
Crown overstraps	shorten by 1/2 crown-ring opening width + 50 mm (2 in) to keep tight and flat
Attachment loops	between gores 3&4 and 4&5 tie to a V-line with center ring; red line runs through the ring
Loops on layout	parachute loops = X, vent pulley loops = Y, vent guide rings = Z (the envelope layout diagram)

ASSEMBLY NOTES

1. Print the master parachute pattern at 100 %; verify against the calibration lines on the panel sheets.
2. Cut 20 gores + the PARACHUTE CENTRE piece; 25 mm allowances, 5/8 in double French fell seams; 1 in turn-back at edges.
3. Align the TOP OPENING REFERENCE LINE when setting the parachute in the 5,000 mm hole - it sets the 360 mm seal overlap.
4. Line lengths are measured to the theoretical seam center / parachute edge - subtract loop and quick-link lengths (pattern-set note 1).
5. Add 6-10 in extra per parachute-line end for knots.
6. Rig confluence cone, centering lines, crown line and red line per the table above; adjust centering between 3,598-3,639 mm on the first inflation.