

SCOOP + MOUTH RIGGING - PATTERN DATA

CUT the scoop to suit your burner frame (master pattern, full size) - scoop is BLACK (Nomex zone)

Mouth Diameter	3,988 mm / 13 ft 1 in
Scoop masters	640x640 or Adams (483x483) master scoop pattern
Scoop hang	100 mm below the mouth: 2 x 25 mm loops (mouth + scoop) + 50 mm quick link
Scoop leads	600 mm (24 in) webbing from scoop bottom to the basket carabiners
Nomex	scoop ~8.4 m; Nomex panels ~16.9 m; total ~25 m (cut per the pattern-set nesting sketch)
Seams	25 mm (1 in) allowance, 5/8 in double French fell; 1 in turn-backs at edges

ENVELOPE FLYING WIRE LENGTHS (virtual frame = frame + 100 mm carabiner)

711 x 585 frame (virtual 828 x 682)

- 1 - 2,459 mm (inside center)
- 2 - 2,385 mm
- 3 - 2,349 mm
- 4 - 2,358 mm
- 5 - 2,409 mm (side)

483 x 483 Adams (virtual 613 x 613)

- 1 - 2,572 mm (inside center)
- 2 - 2,524 mm
- 3 - 2,507 mm
- 4 - 2,358 mm
- 5 - 2,572 mm (side)

640 x 640 frame (virtual 750 x 750)

- 1 - 2,419 mm (inside center)
- 2 - 2,356 mm
- 3 - 2,334 mm
- 4 - 2,356 mm
- 5 - 2,419 mm (side)

Flying-wire lengths above are the master (2,610 m3) values.

Do NOT subtract the large 4-point attachment carabiner lengths. Wires repeat around the 20-gore envelope 1-2-3-4-5 per quadrant.

If you add loops/stickmen/quick links, subtract their lengths from the totals (pattern-set note 1).