## **Switches**

#### **Switches Control:**

| Name | PIC32 Pin                            |
|------|--------------------------------------|
| SWo  | RPF3/RF3                             |
| SW1  | RPF5/PMA8/RF5                        |
| SW2  | RPF4/PMA9/RF4                        |
| SW3  | RPD15/RD15                           |
| SW4  | RPD14/RD14                           |
| SW5  | AN11/PMA12/RB11                      |
| SW6  | CVREFOUT/AN10/RPB10/CTED11PMA13/RB10 |
| SW7  | AN9/RPB9/CTED4/RB9                   |

## **Example A:** Configure Switches to input

1. Configure switches TRIS and disable analog:

```
TRISFbits.TRISF3 = 1; // RF3 (SW0) configured as input

TRISFbits.TRISF5 = 1; // RF5 (SW1) configured as input

TRISFbits.TRISF4 = 1; // RF4 (SW2) configured as input

TRISDbits.TRISD15 = 1; // RD15 (SW3) configured as input

TRISDbits.TRISD14 = 1; // RD14 (SW4) configured as input

TRISBbits.TRISB11 = 1; // RB11 (SW5) configured as input

ANSELBbits.ANSB11 = 0; // RB11 (SW5) disabled analog

TRISBbits.TRISB10 = 1; // RB10 (SW6) configured as input

ANSELBbits.ANSB10 = 0; // RB10 (SW6) disabled analog

TRISBbits.TRISB9 = 1; // RB9 (SW7) configured as input

ANSELBbits.ANSB9 = 0; // RB9 (SW7) disabled analog
```

2. Configure LED to be output and connect switches to LEDs (if switch value is 1 the relevant LED will turn on):

```
TRISA &= 0xff00; // set LED to output
while(1) {

PORTAbits.RA0=PORTFbits.RF3 ; // RF3 (SW0) configured as input

PORTAbits.RA1=PORTFbits.RF5 ; // RF5 (SW1) configured as input

PORTAbits.RA2=PORTFbits.RF4; // RF4 (SW2) configured as input

PORTAbits.RA3=PORTDbits.RD15 ; // RD15 (SW3) configured as input

PORTAbits.RA4=PORTDbits.RD14; // RD14 (SW4) configured as input

PORTAbits.RA5=PORTBbits.RB11 ; // RB11 (SW5) configured as input

PORTAbits.RA6=PORTBbits.RB10 ; // RB10 (SW6) configured as input

PORTAbits.RA7=PORTBbits.RB9 ; // RB9 (SW7) configured as input

}
```

## **LCD**

## **LCD Control**:

In order to transfer instructions to the LCD, you need to configure the DISP\_RS, DISP\_RW and DISP\_EN bits. Once they are configured, you need to transfer instructions and data to the LCD.

The table below describes the LCD input / output bits:

| Name      | PIC32 Pin             | Description   |  |  |  |  |
|-----------|-----------------------|---|--|--|--|--|
|           |                       |   |  |  |  |  |
| DISP_RS   |                       | Register Select: High for Data Transfer, Low for  |  |  |  |  |
| D151 _105 | CTED6/PMA0/RB15       | Instruction Transfer.   |  |  |  |  |
| DISP_RW   | IR PIJ5/PIVIR IJ/RIJ5 | Read/Write signal: High for Read mode, Low for Write mode.  Read/Write Enable: High for Read, falling edge writes data. |  |  |  |  |
| DISP_EN   | IR PIJ4/PIVI W/R/RIJ4 |   |  |  |  |  |
| DB0       | PMD0/RE0              |   |  |  |  |  |
| DB1       | PMD1/RE1              |   |  |  |  |  |
| DB2       | AN20/PMD2/RE2         |   |  |  |  |  |
| DB3       | RPE3/CTPLS/PMD3/RE3   | Data bits 0-7   |  |  |  |  |
| DB4       | AN21/PMD4/RE4         |   |  |  |  |  |
| DB5       | AN22/RPE5/PMD5/RE5    |   |  |  |  |  |
| DB6       | AN23/PMD6/RE6         |   |  |  |  |  |
| DB7       | AN27/PMD7/RE7         |   |  |  |  |  |

The table below describes the LCD instructions (DB0-7):

|                                |    |     |     |     | C   | ode |     |     |     |     |   | Execution Time (max) (when f <sub>cp</sub> or |
|--------------------------------|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|---|---|
| Instruction                    | RS | R/W | DB7 | DB6 | DB5 | DB4 | DB3 | DB2 | DB1 | DB0 | Description   | f <sub>osc</sub> is 270 kHz)                  |
| Clear<br>display               | 0  | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 1   | Clears entire display and sets DDRAM address 0 in address counter.  |   |
| Return<br>home                 | 0  | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 1   | _   | Sets DDRAM address 0 in address counter. Also returns display from being shifted to original position. DDRAM contents remain unchanged. | 1.52 ms                                       |
| Entry<br>mode set              | 0  | 0   | 0   | 0   | 0   | 0   | 0   | 1   | I/D | S   | Sets cursor move direction<br>and specifies display shift.<br>These operations are<br>performed during data write<br>and read.          | 37 µs   |
| Display<br>on/off<br>control   | 0  | 0   | 0   | 0   | 0   | 0   | 1   | D   | С   | В   | Sets entire display (D) on/off, cursor on/off (C), and blinking of cursor position character (B).                                       | 37 µs   |
| Cursor or<br>display<br>shift  | 0  | 0   | 0   | 0   | 0   | 1   | S/C | R/L | _   | _   | Moves cursor and shifts display without changing DDRAM contents.  | 37 μs   |
| Function<br>set                | 0  | 0   | 0   | 0   | 1   | DL  | Ν   | F   | _   | _   | Sets interface data length (DL), number of display lines (N), and character font (F).   | 37 μs   |
| Set<br>CGRAM<br>address        | 0  | 0   | 0   | 1   | ACG | ACG | ACG | ACG | ACG | ACG | Sets CGRAM address.<br>CGRAM data is sent and<br>received after this setting.   | 37 µs   |
| Set<br>DDRAM<br>address        | 0  | 0   | 1   | ADD | Sets DDRAM address.<br>DDRAM data is sent and<br>received after this setting.   | 37 μs   |
| Read busy<br>flag &<br>address | 0  | 1   | BF  | AC  | Reads busy flag (BF) indicating internal operation is being performed and reads address counter contents.                               | 0 μs  |

| Code                             |                   |  |   |   |                       |        |     |     | Execution Time (max) (when f <sub>cp</sub> or |                                      |          |   |   |
|----------------------------------|-------------------|--|---|---|-----------------------|--------|-----|-----|---|--------------------------------------|----------|---|---|
| Instruction                      | RS                | R/W  | DB7 DB6   | DB5   | DB4                   | DB3    | DB2 | DB1 | DB0   | Descrip                              | otic     | on  | f <sub>OSC</sub> is 270 kHz)  |
| Write data<br>to CG or<br>DDRAM  | 1                 | 0  | Write data  |   |                       |        |     |     |   | Writes of CGRAN                      |          | a into DDRAM or   | $37 \mu s$<br>$t_{ADD} = 4 \mu s^*$   |
| Read data<br>from CG or<br>DDRAM | 1                 | 1  | Read data   | ı   |                       |        |     |     |   | Reads (                              |          | a from DDRAM or   | 37 μs<br>t <sub>ADD</sub> = 4 μs*   |
|                                  | S/C<br>R/L<br>R/L | = 1:<br>= 0:<br>= 1:<br>= 0:<br>= 1:<br>= 1:<br>= 1: | Increment<br>Decrement<br>Accompant<br>Display sh<br>Cursor mo<br>Shift to the<br>8 bits, DL<br>2 lines, N<br>5 × 10 dot<br>Internally<br>Instruction | nt hies dis hift ove eright e left = 0: 4 = 0: 1 s, F = 0 | bits<br>line<br>): 5× | 8 dots | 5   |     |   | ACG:<br>ADD:<br>(cc<br>add<br>AC: Ac | orreddre | Display data RAM Character generator RAM CGRAM address DDRAM address esponds to cursor ess) ess counter used for DD and CGRAM esses | Execution time changes when frequency changes Example: When $f_{cp}$ or $f_{OSC}$ is 250 kHz, $_{37~\mu s} \times \frac{270}{250} = 40~\mu s$ |

The table below describes common examples of LCD instructions:

| Code | Meaning  |
|------|--|
|      |  |
| 0x38 | Configure LCD instructions to be 8 bit long, over both of LCD lines and each letter to |
|      | expand over 5x8 LCD pixels (0x38 = 0011 1000).   |
| 0xE  | Set the display configurations to be displayed over the LCD screen with a non-         |
|      | blinking cursor ( $0xE = 0000 1110$ ).   |
| 0x1  | Clear display $(0x1 = 0000\ 0001)$ .   |
|      |  |
| 0x40 | Set the Character Generator initial address to 0 (0x40 = 0100 0000).                   |
|      |  |

## **Example A: Write a string to the LCD screen**

**Note:** the 'busy()' function is used to wait for a certain amount of time:

```
void busy(void) {
      char RD, RS;
      int STATUS TRISE, portMap;
      RD = PORTDbits.RD5; // save settings of data / instruction transfer
      RS = PORTBbits.RB15; // save setting of read / write mode
      STATUS_TRISE = TRISE; // save TRIS settings
      PORTDbits.RD5 = 1; // set as read mode from the LCD
      PORTBbits.RB15 = 0; // set as instruction transfer to LCD
      portMap = TRISE; // save the LCD instructions to a new variable
      portMap |= 0x80; /* set DB7 (BF) to 1 in order to let LCD finish its
                          current action (if set to 1 then it is internally
                          operating */
      TRISE = portMap;
      do { // wait for LCD to finish its current action
            PORTDbits.RD4 = 1; // enable = 1
            PORTDbits.RD4 = 0; // enable = 0
      } while (PORTEbits.RE7); // register BF (status of LCD busy or not)
      PORTDbits.RD5 = RD; // restore pervious data / instruction transfer
      PORTBbits.RB15 = RS; // restore previous r / w mode
      TRISE = STATUS_TRISE; // restore previous TRIS settings
```

1. Configure the TRIS to output mode and disable the analog:

```
TRISBbits.TRISB15 = 0; // RB15 set as output

TRISDbits.TRISD5 = 0; // RD5 set as output

TRISDbits.TRISD4 = 0; // RD4 set as output

TRISE &= 0xff00;

ANSELBbits.ANSB15 = 0; // disable analog on RB15

ANSELEbits.ANSE2 = 0; // disable analog

ANSELEbits.ANSE4 = 0; // disable analog

ANSELEbits.ANSE5 = 0; // disable analog

ANSELEbits.ANSE6 = 0; // disable analog

ANSELEbits.ANSE7 = 0; // disable analog
```

2. Configure the PORT to instructions transfer and send the instructions:

3. Configure the PORT to data transfer and send the data:

## Example B: Write a new font to the LCD screen

- 1. Configure the TRIS to output mode and disable the analog (Example A-1).
- 2. Configure the PORT to instructions transfer and send the instructions:

```
char instructions[] = {0x38,0x38,0x38,0xe,0x6,0x1,0x40};

// 0x40 is for new font configuration in CGRAM.

PORTBbits.RB15 = 0; // set RS to receive instructions

PORTDbits.RD5 = 0; // set to write mode

for (i=0; i<6; i++) { // transfer instructions

    PORTE = instructions[i];

    // falling edge -> write data:

    PORTDbits.RD4 = 1;

    PORTDbits.RD4 = 0;

    busy();
}
```

3. Configure the new font via the Character Generator and store it in the RAM memory:

4. Configure the new font via the Character Generator and store it in the RAM memory:

## **Timer**

The MX3 chip has many timers that are scaled to different values.

Each timer can work internally or externally. In the lab we've only used internal clocks.

The timer uses a prescaler (hardware component) to translate its own clock-rate to another clock-rate. Thus, allows us to use less bits for a longer timer duration.

All timers work with a 16-bit or with a 32-bit register comparing. The Timer-# uses 2 registers: TMR# and PR#. Usually, TMR# is set to 0 and PR# and is set to a certain final value. The Timer-# increments the TMR# value until its value is as in PR#. When it occurs, a Timer# event flag turns on.

#### Calculation of the time (in seconds) using prescaler and final value (PR-#):

```
Rate = crystalValue / div / prescalerValue / finalValue [Hz]
Time = 1 / Rate [sec]
```

#### Calculation of final value (PR-#) for a given amount of time (in seconds):

```
finalValue = Time * (crystalValue / div / prescalerValue)
```

What is the PR that gets us a 0.3 seconds delay?

```
(80,000,000 / 2 / 256) * 0.3 = 46875 = 0xB71B
```

crystalValue (ערך גביש=) – Given by the chip manufacturer. At MX3 it is 80,000,000.

div – Normally is 2.

prescalerValue – Programmable, usually is a power of 2 (ex.: timer 1 prescaler can be 1/8/64/256).

finalValue – A programmed value (TMR-#, PR-#).

### **Example A:** Activate Timer 1 (has a 16-bit comparator) as a stopwatch

#### **Timer 1 Configuration:**

```
bit 31-16
                                                                                      Reserved: Write '0'; ignore read
bit 7
               TGATE: Gated Time Accumulation Enable bit
                                                                      bit 15
                                                                                      ON: Timer On bit
               When TCS = 1:
                                                                                      1 = Timer is enabled
               This bit is ignored and read '0'.
                                                                                      0 = Timer is disabled
               When TCS = 0:
               1 = Gated time accumulation is enabled
               0 = Gated time accumulation is disabled
bit 6
               Reserved: Write '0'; ignore read
bit 5-4
               TCKPS<1:0>: Timer Input Clock prescaler Select bits
               11 = 1:256 prescale value
               10 = 1:64 prescale value
               01 = 1:8 prescale value
               00 = 1:1 prescale value
bit 3
               Reserved: Write '0'; ignore read
bit 2
               TSYNC: Timer External Clock Input Synchronization Selection bit
               When TCS = 1:
               1 = External clock input is synchronized
               0 = External clock input is not synchronized
               When TCS = 0:
               This bit is ignored and read '0'.
bit 1
               TCS: Timer Clock Source Select bit
               1 = External clock from T1CKI pin
               0 = Internal peripheral clock
bit 0
               Reserved: Write '0'; ignore read
```

#### Timer 1 activation:

```
void delay(void) {
T1CONbits.ON = 0; // disable timer
T1CONbits.TGATE = 0; // disable time accumulation (clock counter)
T1CONbits.TCS = 1; // use internal clock
T1CONbits.TCKPS0 = 1; // set Prescaler to be 1:256 (according to the table)
T1CONbits.TCKPS1 = 1; // set Prescaler to be 1:256 (according to the table)
T1CONbits.TSYNC = 1; // synchronize the clock ticks
TMR1 = 0; // set initial value
PR1 = 0X04FF; // set final value
T1CONbits.ON = 1; // enable timer
IFS0bits.T1IF = 0; // set interrupt flag to 0
while (!IFS0bits.T1IF); // wait for timer to end and set T1IF bit to 1
}
```

# **Example B**: Activate Timers 2 and 3 (each has a 16-bit comparator) as a 32-bit stopwatch

#### **Timer 2 Prescaler configuration:**

```
bit 6-4
                 TCKPS<2:0>: Timer Input Clock prescaler Select bits
                 111 = 1:256 prescale value
                 110 = 1:64 prescale value
                 101 = 1:32 prescale value
                 100 = 1:16 prescale value
                 011 = 1:8 prescale value
                 010 = 1:4 prescale value
                 001 = 1:2 prescale value
                 000 = 1:1 prescale value
                 T32: 32-bit Timer Mode Select bits
   bit 3
                 1 = TMRx and TMRy form a 32-bit timer
                 0 = TMRx and TMRy form separate 16-bit timers
   bit 2
                 Reserved: Write '0'; ignore read
   bit 1
                 TCS: Timer Clock Source Select bit
                 1 = External clock from TxCK pin
                 0 = Internal peripheral clock
   bit 0
                 Reserved: Write '0'; ignore read
```

#### Timer 2 and 3 activation:

```
void delay(void) {
  T2CONbits.ON = 0; // disable Timer 2
  T2CONbits.TGATE = 0; // disable time accumulation (Timer 2 counter)
  T2CONbits.TCS = 0; // use Timer 2 internal clock
  T2CONbits.T32 = 1; // set Timer 2 register to 32-bit
  T2CONbits.TCKPS0 = 1; // set Timer 2 Prescaler to 256
  T2CONbits.TCKPS1 = 1; // set Timer 2 Prescaler to 256
  T2CONbits.TCKPS2 = 1; // set Timer 2 Prescaler to 256
  T3CONbits.ON = 0; // disable Timer 3
  TMR3 = 0; // set initial value of TMRy to 0
  TMR2 = 0; // set initial value of TMRx to 0
  PR2 = 0X5000; // set final value of PR2x to 0x5000
  PR3 = 0; // set final value of PR2y to 0
  T2CONbits.ON = 1; // start Timer 2
```

```
IFSObits.T2IF = 0; // set Timer 2 flag to 0
IFSObits.T3IF = 0; // set Timer 3 flag to 0
while (!IFSObits.T3IF); // wait for Timer 3 to end and set T3IF bit to 1
}
```

## **Example C:** Activate Timer 1 as a 'x' seconds stopwatch

1. Calculation of PR-# value according to requested delay (in seconds):

2. Delay method, with a given number of seconds, for Timer 1:

```
void delayForXseconds(int seconds) {
  T1CONbits.ON = 0; // disable timer
  T1CONbits.TGATE = 0; // disable time accumulation (clock counter)
  T1CONbits.TCS = 1; // use internal clock
  T1CONbits.TCKPS0 = 1; // set Prescaler to be 1:256 (according to the table)
  T1CONbits.TCKPS1 = 1; // set Prescaler to be 1:256 (according to the table)
  T1CONbits.TSYNC = 1; // synchronize the clock ticks
  TMR1 = 0; // set initial value
  PR1 = calculatePR(seconds, 80000000, 2, 256);
  T1CONbits.ON = 1; // enable timer
  IFS0bits.T1IF = 0; // set interrupt flag to 0
  while (!IFS0bits.T1IF); // wait exactly 5 seconds and then set T1IF bit to 1
  }
```


## Keyboard

The keyboard is based on a matrix of 4x4. In order to figure out the pressed button, we need to iterate the matrix's rows and columns by the 'running-zero' method.

We will set the X values to be 0 and the Y values to be 1. Then we will set y0 to be 0 and check for a matching x. If a matching x is found, we can manage the coordinates of the pressed button. If no button is pressed, we will return a unique value (0xFF).

The keyboard indexes start from bottom right. Ex.: 0x23 means that the button '6' is pressed because:


- $0x23 = (0010 \ 0011)_2$ .
- $2 = (0010)_2$  is the X index (column).
- $3 = (0011)_2$  is the Y index (row).



## **Keyboard Control:**

| Pmod Pin | Schematic Label | PIC32 Pin                     | Meaning |
|----------|-----------------|-------------------------------|---------|
| PMODA_1  | JA1             | RPC2/RC2                      | x0      |
| PMODA_2  | JA2             | RPC1/RC1                      | x1      |
| PMODA_3  | JA3             | RPC4/CTED7/RC4                | x2      |
| PMODA_4  | JA4             | AN16/C1IND/RPG6/SCK2/PMA5/RG6 | х3      |
| PMODA_7  | JA7             | RPC3/RC3                      | y0      |
| PMODA_8  | JA8             | AN17/C1INC/RPG7/PMA4/RG7      | y1      |
| PMODA_9  | JA9             | AN18/C2IND/RPG8/PMA3/RG8      | y2      |
| PMODA_10 | JA10            | AN19/C2INC/RPG9/PMA2/RG9      | у3      |

## **Keyboard Schema:**



## **Example A:** Keyboard management with LED

The program will show the x and y values of the pressed button.

1. Configure the TRIS and PULL UP:

```
TRISA& = 0xff00; // set LED to output

TRISCbits.TRISC2 = 0; // set RC2 (x0) to output

TRISCbits.TRISC1 = 0; // set RC1 (x1) to output

TRISCbits.TRISC4 = 0; // set RC4 (x2) to output

TRISGbits.TRISG6 = 0; // set RG6 (x3) to output

ANSELGbits.ANSG6 = 0; // disable RG6 analog

TRISCbits.TRISC3 = 1; // set RC3 (y0) to input

CNPUCbits.CNPUC3; // PULL UP TD

TRISGbits.TRISG7 = 1; // set RG7 (y1) to input

ANSELGbits.ANSG7 = 0; // disable RG7 analog

CNPUGbits.CNPUG7; // PULL UP TD

TRISGbits.TRISG8 = 1; // set RG8 (y2) to input
```

2. Setup the 'y' axis value (if pressed):

```
int in_y(int x) {
    int y = 1; // the number of the key column (y)
    int flag = 0; // 0 -> not pressed, 1 -> pressed
    if (!PORTCbits.RC3) { // check y0 status (if y0 == 0 it is pressed)
    flag = 1; y = 1; }
    else if (!PORTGbits.RG7) { // check y1 status (y1 == 0 means pressed)
    flag = 1; y = 2; }
    else if (!PORTGbits.RG8) { // check y2 status (y2 == 0 means pressed)
    flag = 1; y = 3; }
    else if (!PORTGbits.RG9) { // check y3 status (y3 == 0 means pressed)
    flag = 1; y = 4; }
    if (flag == 0) // no button is pressed, return unique value
        return 0xff;
    else
        return (y | (x << 4) ); // ex.: if x=1 and y=3 will return 0001 0011
}</pre>
```

3. Setup the 'running zero' to turn on the LED:

```
int i, xy;
while(1) {
     while(1) {
      // set all X to be 1:
      PORTCbits.RC2 = 1; PORTCbits.RC1 = 1;
      PORTCbits.RC4 = 1; PORTGbits.RG6 = 1;
      i = 1;
      PORTCbits.RC2 = 0; // set x0 to 0
      xy = in_y(1); // check if any of y values is 1
      if (xy != 0xff) break; // if y is pressed then stop the loop (x=1)
      PORTCbits.RC2 = 1; // reset x0 to 1
      i=2;
      PORTCbits.RC1 = 0; // set x1 to 0
      xy = in_y(2); // check if any of y values is 1
      if (xy != 0xff) break; // if y is pressed then stop the loop (x=2)
      PORTCbits.RC1 = 1; // reset x1 to 1
      i = 3;
      PORTCbits.RC4 = 0; // set x2 to 0
      xy = in_y(3); // check if any of y values is 1
      if (xy != 0xff) break; // if y is pressed then stop the loop (x=3)
      PORTCbits.RC4 = 1; // reset x2 to 1
      i = 4;
      PORTGbits.RG6 = 0; // set x3 to 0
      xy = in_y(4); // check if any of y values is 1
      if (xy != 0xff) break; // if y is pressed then stop the loop (x=4)
      PORTGbits.RG6 = 1; // reset x3 to 1
      }
      PORTA = xy; // relevant LEDs will turn on (according to xy value)
}
```

## **Example B:** Keyboard management with LCD

The program will show the ASCII value of the pressed button.

- 1. Configure the TRIS and PULL UP as in A-1
- 2. Setup the 'y' axis value (if pressed) as in A-2.
- 3. Setup the 'running zero' to turn as in A-3. The only difference is at the initialization of 'scan\_key' sequence and the replacement of the last line with the following:

## **Example C:** Configure the need to release the button before any continue

If any button is still pressed, the program will be stuck on one of the 'while' loops. When all buttons are released, the program will continue.

```
// set all X to 0 -> all X are pressed
PORTCbits.RC2 = 0; PORTCbits.RC1 = 0; PORTCbits.RC4 = 0;PORTGbits.RG6 = 0;
// wait for all Y to be 1 -> all Y are not pressed
while(!PORTCbits.RC3); while(!PORTGbits.RG7);
while(!PORTGbits.RG8); while(!PORTGbits.RG9);
```

## **Interrupts**

An interrupt is a response by the processor to an event that needs attention from the software. Interrupt received due to an asynchronous signal that can be received by software or hardware. The interrupt allows us to execute a certain method that is not on the main execution flow and then go back to execute the main program flow.

Our chip allows us to perform hardware-initiated interrupts. It contains an interrupt vector, that is composed of N interrupt flags. Each flag has a priority, so that when several interrupts are requested, the processor executes them according to their priority. The higher the priority is, the higher probability for its interrupt method to be executed first.

When an interrupt is requested, the interrupt flag changes its value to 1 and an interrupt is made. When the interrupt is taken care of, the program flow goes back to where it was interrupt originally.

## PIC32 Interrupt Control System – a short brief:

- INTCON: Interrupt Control Register.
- INTSTAT: Interrupt Status Register.
- IPTMR: Interrupt Proximity Timer Register.
- IFS0, IFS1: Interrupt Flag Status Registers.
- IEC0, IEC1: Interrupt Enable Control Registers.
- IPC0 IPC11: Interrupt Priority Control Registers.

## **Example A:** Interrupt by using Timer 1

1. Define the interrupt methods:

```
void __ISR(_CHANGE_NOTICE_VECTOR, IPL4) PinChangeHandler(void) {
    // keep the interrupt vector the same but set 4<sup>th</sup> index to be 0:
    PORTAbits.RA4 ^= 1;
    busy(); // wait for a specific period
    IFS1bits.CNGIF = 0; // Check if CN on BTND - RA15
    IFS1bits.CNCIF = 0; // Check if CN on BTND - RA15
}

void __ISR(_TIMER_1_VECTOR, ipl7) timer1_interrupt(void) {
    PORTAbits.RA7 ^= 1; // set 7<sup>th</sup> index on interrupt vector to 0
    // set Timer 1 interrupt flag to 0 (because the interrupt made it 1):
    IFS0bits.T1IF = 0;
}
```

2. Configure the keyboard:

```
TRISA &= 0xff00; // set LED to output

// set all X to output:

TRISCbits.TRISC2 = 0; // set RC2 to output

TRISCbits.TRISC1 = 0; // set RC1 to output

TRISCbits.TRISC4 = 0; // set RC4 to output

TRISCbits.TRISG6 = 0; // set RG6 to output

ANSELGbits.ANSG6 = 0; // disable RG6 analog

// set all Y to input:

TRISCbits.TRISC3 = 1; // set RC3 to input

CNPUCbits.CNPUC3; // PULL OUT TD
```

```
TRISGbits.TRISG7 = 1; // set RG7 to input

ANSELGbits.ANSG7 = 0; // disable RG7 analog

CNPUGbits.CNPUG7; // PULL OUT TAD

TRISGbits.TRISG8 = 1; // set RG8 to output

ANSELGbits.ANSG8 = 0; // disable RG8 analog

CNPUGbits.CNPUG8; // PULL OUT TAD

TRISGbits.TRISG9 = 1; // set RG9 to output

ANSELGbits.ANSG9 = 0; // disable RG9 analog

CNPUGbits.CNPUG9; // PULL OUT TAD

LATGSET = 9; //???

// set all X to be 0:

PORTCbits.RC2 = 0; PORTCbits.RC1 = 0;

PORTCbits.RC4 = 0; PORTGbits.RG6 = 0;
```

#### 3. Configure Timer 1:

```
T1CONbits.ON = 0; // stop Timer 1

T1CONbits.TGATE = 0; // disable time accumulation (clock counter)

T1CONbits.TCS = 0; // use external clock

T1CONbits.TCKPS0 = 1; // set Prescaler to be 1:256 (by the table)

T1CONbits.TCKPS1 = 1; // set Prescaler to be 1:256 (by the table)

T1CONbits.TSYNC = 1; // set Prescaler to be 1:256 (by the table)

TMR1 = 0; // set Timer 1 initial value

PR1 = 0Xfffff; // set Timer 1 final value

IFSObits.T1IF = 0; // set interrupt flag to value of 0

IECObits.T1IE = 1; // set flag to enable mode

IPC1bits.T1IS = 0; // set interrupt sub-priority to 0
```

4. Configure the interrupt control of the keyboard to hardware control:

```
// Configure y0:
TRISCbits.TRISC3 = 1; // Set RA15 for digital input
CNPUCbits.CNPUC3 = 0; // Disable RC3 pull up resistor
CNENCbits.CNIEC3 = 1; // Enable RC3 change notification
IEC1bits.CNCIE = 1; // Enable RC3 CN interrupts
IFS1bits.CNCIF = 0; // Check if CN on BTND - RC3
// Configure y1:
TRISGbits.TRISG7 = 1; // Set RG7 for digital input
CNENGbits.CNIEG7 = 1; // Enable RG7 change notification
CNPUGbits.CNPUG7 = 0; // Disable RG8 pull up resistor
// Configure y2:
TRISGbits.TRISG8 = 1; // Set RG8 for digital input
CNPUGbits.CNPUG8 = 0; // Disable RG8 pull up resistor
CNENGbits.CNIEG8 = 1; // Enable RG8 change notification
// Configure y3:
TRISGbits.TRISG9 = 1; // Set RG9 for digital input
CNPUGbits.CNPUG9 = 0; // Disable RG9 pull up resistor
CNENGbits.CNIEG9 = 1; // Enable RG9 change notification
```

5. Configure the interrupt details (priority and enable interrupts):

```
CNCONGbits.ON = 1; // Set RA15 change notification on
IEC1bits.CNGIE = 1; // Enable RG CN interrupts
CNCONCbits.ON = 1; // Set RA15 change notification on
IEC1bits.CNCIE = 1; // Enable RC CN interrupts
// Set CN interrupt level:
IPC8bits.CNIP = 4; // Set CN interrupt group level 1
IPC8bits.CNIS = 0; // Set CN interrupt sub group level 0
IFS1bits.CNGIF = 0; // Check if CN on BTND - RG
IFS1bits.CNCIF = 0; // Check if CN on BTND - RC
// Start the interruption:
INTCONbits.MVEC = 1; // this is the interrupt vector -> set to 1 to enable it
IPTMR = 0; // INTERRUPT PROXIMITY TIMER REGISTER -> the counter -> set to 0
T1CONbits.ON = 1; // start the timer
asm("ei"); // assembly command to enable interrupt
while(1); // wait for interrupts! A real flow can be written within the while
```

## Appendix A: Bit Cheat

| Χ | Υ | AND | OR | XOR |
|---|---|-----|----|-----|
| 0 | 0 | 0   | 0  | 1   |
| 1 | 0 | 0   | 1  | 0   |
| 0 | 1 | 0   | 1  | 0   |
| 1 | 1 | 1   | 1  | 1   |