8-Leds

Description	PIC32 pin	Schematic	Label		LEDs
		name		LEDO R17	- 13
Led 0	TMS/CTED1/RAO	LED0	LD0	330 R19	LD0
Led 1	TCK/CTED2/RA1	LED1	LD1	TED1 -	1
Led 2	SCL2/RA2	LED2	LD2	330 R23	LD1
Led 3	SDA2/RA3	LED3	LD3	330	
Led 4	TDI/CTED9/RA4	LED4	LD4	LED3 R28	LD2
Led 5	TDO/RA5	LED5	LD5	330	LD3
Led 6	TRCLK/RA6	LED6	LD6	LED4 R32	₹ 3
Led 7	TRD3/CTED8/RA7	LED7	LD7	330	LD4
				LED5 R38	N)
			1	330	LD5
				LED6 R41	Ö
				330 R42	ĹD6
	led	PORTA		LED/	GND
	100.	RA8-RA15		330	LD7

```
Ports Macro's:

#define LD0 PORTAbits.RA0

#define LD1 PORTAbits.RA1

#define LD2 PORTAbits.RA2

#define LD3 PORTAbits.RA3

#define LD4 PORTAbits.RA4

#define LD5 PORTAbits.RA5

#define LD6 PORTAbits.RA6

#define LD7 PORTAbits.RA7
```

```
#include <xc.h>
                                      TRIS
#pragma config JTAGEN = OFF
                                       0 = output
                                                         1 = input
#pragma config FWDTEN = OFF
                                       הגדרת הפורט ככניסה הגדרת הפורט כיציאה
#pragma config FNOSC =FRCPLL
                                                 מהבקר.
                                                                     לבקר.
#pragma config FSOSCEN = OFF
                                          – כותבים ליציאה)
                                                            – (קוראים מהפורט)
#pragma config POSCMOD =
                             EC
                                            הפורט משתנה
                                                               הפורט משתנה
#pragma config OSCIOFNC =
                            ON
#pragma config FPBDIV = DIV 1
                                         בעקבות שינוי בקוד:
                                                           בעקבות שינוי חיצוני:
#pragma config FPLLIDIV =
                             DIV 2
                                         כיבוי והפעלת לדים
                                                            לחיצת/עזיבת מקש
#pragma config FPLLMUL =
                                                                       ..IOI
MUL 20
#pragma config FPLLODIV =
                              DIV 1
void main(){
                                         //
                                                 הגדרת PORTA כיציאה (RAO-RA7).
    //init starts *******
    TRISA &= 0xff00;
    //init ends ********
                                         // .(0,2,4,6 מספר זוגי: RAi (מספר זוגי: 1,0,2,4,6).
    PORTA = 0x55;
                                                          Ox55=0b10101010 '>
```

Switches

Description	PIC32 pin	Schem' name	Label
Switch 0	RPF3/RF3	SW0	SW0
Switch 1	RPF5/PMA8/RF5	SW1	SW1
Switch 2	RPF4/PMA9/ <mark>RF4</mark>	SW2	SW2
Switch 3	RPD15/RD15	SW3	SW3
Switch 4	RPD14/RD14	SW4	SW4
Switch 5	AN11/PMA12/RB11	SW5	SW5
Switch 6	CVREFOUT/AN10/RPB10/CTED11PMA13/RB10	SW6	SW6
Switch 7	AN9/RPB9/CTED4/RB9	SW7	SW7

```
Switches
Ports Macro's:
#define SWO PORTFbits.RF3
#define SW1 PORTFbits.RF5
                                                                                              SW0
                                                                                      R21 10K
#define SW2 PORTFbits.RF4
                                                                                              SW1
                                                                                      10K R24
#define SW3 PORTDbits.RD15
                                                                                              SW2
                                                                                      R27 10K
#define SW4 PORTDbits.RD14
                                                                                              SW3
                                                                   SW3
#define SW5 PORTBbits.RB11
                                                                                              SW4
                                                                                      R33 10K
#define SW6 PORTBbits.RB10
                                                                                              SW5
                                                                           SW5
                                                                                      10K R37
#define SW7 PORTBbits.RB9
                                                                                              SW6
                                                                                    R39 10K R40 SW7
                                                                                  SW7 0 4.7K
                                                                                           4.7K
                                                                                            TRIG_2
```

```
#include <xc.h>
/*standard "pragma config's" in here... */
void main() {
  //init starts *******
  TRISFbits.TRISF3 = 1;
                                                 את switch מגדירים לכל פורט של*
  TRISFbits.TRISF5 = 1;
                                              הRIST להיות 1 כי הוא PORT כניסה.
  TRISFbits.TRISF4 = 1;
  TRISDbits.TRISD15 = 1;
                                                   TRISFbits.TRISF3 = 1 :ע"יי *
  TRISDbits.TRISD14 = 1;
  TRISBbits.TRISB11 = 1;
  TRISBbits.TRISB10 = 1;
  TRISBbits.TRISB9 = 1;
                                            *פורטי כניסה מסויימים ניתן להגדיר כאנלוגיים ולא
  ANSELBbits.ANSB11 = 0;//SW5 an disable
                                                       כדיגיטליים (0/1 כלומר דלוק\כבוי).
  ANSELBbits.ANSB10 = 0;//SW6 an disable
                                                להיות sw5,sw6,sw7 להיות נגדיר את הפורטים
  ANSELBbits.ANSB9 = 0; //SW7 an disable
                                               שלהם. Analog disable שלהם ע"י ביצוע
  //init ends ********
                                              מטרול ע"י: ANSELBbits.ANSB9 = 0
  while (1) {
                                                  *כאן כל כפתור מדליק\מכבה את הלד
    PORTAbits.RA0 = PORTFbits.RF3;
                                                    המתאים לו (שנמצא פיזית מעליו).
    PORTAbits.RA1 = PORTFbits.RF5;
    PORTAbits.RA2 = PORTFbits.RF4;
    PORTAbits.RA3 = PORTDbits.RD15;
    PORTAbits.RA4 = PORTDbits.RD14;
    PORTAbits.RA5 = PORTBbits.RB11;
    PORTAbits.RA6 = PORTBbits.RB10;
    PORTAbits.RA7 = PORTBbits.RB9;
  }
```

User Buttons

Description	PIC32 pin	Pin Shared With	Schem' name	Label
Left	PGED1/ANO/RPB0/RBO	PGD	BTN L	BTNL
Right	AN8/RPB8/CTED10/RB8	S0_PWM	BTN R	BTN R
Center	RPF0/PMD11/RF0	TRIG_1	BTNC	BTNC
Up	PGEC1/AN1/RPB1/CTED12/RB1	PGC	BTN U	BTN U
Down	RPA15/ RA15	S1_PWM	BTN D	BTN D

Ports Macro's:


#define tris_BTNL TRISBbits.TRISB0
#define ansel_BTNL ANSELBbits.ANSB0
#define prt_BTNL PORTBbits.RB0

#define tris_BTNR TRISBbits.TRISB8
#define ansel_BTNR ANSELBbits.ANSB8
#define prt_BTNR PORTBbits.RB8

#define tris_BTNC TRISFbits.TRISFO #define prt BTNC PORTFbits.RFO

#define tris_BTNU TRISBbits.TRISB1
#define ansel_BTNU ANSELBbits.ANSB1
#define prt_BTNU PORTBbits.RB1

#define tris_BTND TRISAbits.TRISA15
#define prt_BTND PORTAbits.RA15




```
#include <xc.h>
/*standard "pragma config's" in here... */
/*User Buttons defines and prototypes*/
#define tris BTNL TRISBbits.TRISB0
#define ansel BTNL ANSELBbits.ANSB0
#define prt BTNL PORTBbits.RB0
#define tris BTNR TRISBbits.TRISB8
#define ansel BTNR ANSELBbits.ANSB8
#define prt BTNR PORTBbits.RB8
#define tris_BTNC TRISFbits.TRISF0
#define prt_BTNC PORTFbits.RF0
#define tris BTNU TRISBbits.TRISB1
#define ansel BTNU ANSELBbits.ANSB1
#define prt BTNU PORTBbits.RB1
#define tris BTND TRISAbits.TRISA15
#define prt BTND PORTAbits.RA15
void delay();
/*LCD defines and prototypes*/
void busy(void);
void initLCD();
#define DISP EXEC PORTDbits.RD4 = 1;PORTDbits.RD4 = 0;busy();
void main() {
 /*Init User Buttons*/
 tris BTNU = 1;
 tris BTNL = 1;
 tris BTNC = 1;
 tris BTNR = 1;
 tris BTND = 1;
 ansel BTNU = 0;
 ansel_BTNL = 0;
 ansel BTNR = 0;
 /*LCD*/
  initLCD();
 PORTBbits.RB15 = 0; //command mode
 PORTE = 0x1;
 DISP EXEC
 PORTBbits.RB15 = 1; //data mode
```

```
char btn_name = '_';
  int counter = 0;
  while (1) {
        while (1) {
              if (prt BTNL) {
                btn name = 'L';
                break;
              else if (prt BTNR) {
                btn name = 'R';
                break;
              else if (prt BTNC) {
                btn name = 'C';
                break;
              else if (prt BTNU) {
                btn name = 'U';
                break;
              else if (prt_BTND) {
                btn name = 'D';
                break;
              }
        }
        PORTE = btn name;
        DISP EXEC
        delay();
        counter++;
        if (counter == 16) {
          PORTBbits.RB15 = 0; //command mode
          PORTE = 0xc0; //write to second line
          DISP EXEC
          PORTBbits.RB15 = 1; //data mode
        if (counter == 32) {
          PORTBbits.RB15 = 0; //command mode
          PORTE = 0x1; //flush LCD and write in first line
          DISP EXEC
          PORTBbits.RB15 = 1; //data mode
          counter = 0;
        }
    }
}
void delay() {
  int i;
  for (i = 0; i < 64000; i++); for (i = 0; i < 64000; i++);
  for (i = 0; i < 64000; i++); for (i = 0; i < 64000; i++);
  for (i = 0; i < 64000; i++); for (i = 0; i < 64000; i++);
```

RGB Leds

PIC32 pin	Schem' name	Label
AN25/RPD2/RD2	LED8_R	R
RPD12/PMD12/RD12	LED8_G	G
AN26/RPD3/	LED8_B	В




```
#define RGB_R PORTDbits.RD2
#define RGB_G PORTDbits.RD12
#define RGB B PORTDbits.RD3
```

```
#include <stdio.h>
/*standard "pragma config's" in here...*/
void main() {
  TRISFbits.TRISF3 = 1;
                                                  .sw0,sw1,sw2 פורטים כניסה
  TRISFbits.TRISF5 = 1;
  TRISFbits.TRISF4 = 1;
  //init starts *******
  TRISDbits.TRISD2 = 0;
                                            פורטים LED8_R, LED8_G, LED8_B
  TRISDbits.TRISD12 = 0;
  TRISDbits.TRISD3 = 0;
  ANSELDbits.ANSD2 = 0;
                                            פורטים דיגיטליים. LED8_R, LED8_B
  ANSELDbits.ANSD3 = 0;
  //init ends ********
                                                       sw0* מקושר לr
 while (1) {
                                                    sw1* מדליק∖מכבה sw1*
    PORTDbits.RD2 = PORTFbits.RF3;
                                                    sw2* מדליק\מכבה
    PORTDbits.RD12 = PORTFbits.RF5;
    PORTDbits.RD3 = PORTFbits.RF4;
  }
```

Speaker





כדי שספיקר יפעל צריך לתת לתת מתח\להפסיק מתח כל 640 פעולות (זה מה שיוצר רטט ברכיב הספיקר מה שמוציא סאונד).

צפצוף אחיד:

```
#include <stdio.h>
/*standard "pragma config's" in here... */

void main() {
    //init starts*********
    TRISBbits.TRISB14 = 0; //Speaker - as output
    ANSELBbits.ANSB14 = 0; //Speaker - disabled Analog
    //init ends**********

    int i=0;
    PORTBbits.RB14 = 0;


while(1) {
        if(i%640==0)
            PORTBbits.RB14 = !PORTBbits.RB14;
        i++;
        }
    }
}
```


צפצוף לסירוגין:

```
#include <stdio.h>
/*standard "pragma config's" in here... */
void main() {
    //init starts********
    TRISBbits.TRISB14 = 0; //Speaker - as output
    ANSELBbits.ANSB14 = 0; //Speaker - disabled analog
    //init ends*********
    int i;
    PORTBbits.RB14 = 0;
    while(1){
        for (i=0;i<640000;i++);</pre>
        for (i=0;i<640000;i++) {</pre>
            if(i%640==0)
                 PORTBbits.RB14 = !PORTBbits.RB14;
        }
    }
```

LCD

Name	PIN32 Pin	Description
DISP_RS	AN15/RPB15/OCFB/CTED6/PMA0/RB15	0 for command, 1 for data (inside DB0-DB7)
DISP_RW	RPD5/PMRD/RD5	1 for Read ,0 for Write (from/to DB0-DB7)
DISP_EN	RPD4/PMWR/RD4	signal (1 and then 0)
DB0	PMD0/RE0	DB0-DB7 (PORTE)
DB1	PMD1/RE1	
DB2	AN20/PMD2/RE2	
DB3	RPE3/CTPLS/PMD3/RE3	
DB4	AN21/PMD4/RE4	
DB5	AN22/RPE5/PMD5/RE5	
DB6	AN23/PMD6/RE6	
DB7	AN27/PMD7/RE7	





<u>הסבר:</u>

1. תחילה נבצע את הפקודות: (מתבצע בפונקציית <u>initLCD</u>)

TRISE &= 0xff00;

PORTDbits.RD5 = 0; // DISP_RW is Write

שמגדירה את DB0-DB7 כיציאות שאליהן אנחנו כותבים.

2. נבצע את הפקודה:

PORTBbits.RB15 = 0;

כדי להבהיר שהמידע שאנחנו **כותבים** לפורטים DB0-DB7 הוא פעולה שאנחנו רוצים שהמסך יבצע.

פעולות נפוצות:

בשורה הראשונה של המסך. 0x1 = 0x1

תחילת כתיבה בשורה הראשונה של המסך. 0x80

0xc0 = תחילת כתיבה <u>בשורה השניה</u> של המסך.

פעמים באיתחול המסך). (צריך לבצע 3 פעמים באיתחול המסך). (בצע את הפקודה: 3 PORTBbits.RB15 = 1; רבצע את הפקודה מדי להבהיר שהמידע שאנחנו כותבים לפורטים PORTE) DB0-DB7 הוא תו שאנחנו כותבים לפורטים ידפיס.

1. לבצע את הפקודות: 4 //signal PORTDbits.RD4=1; PORTDbits.RD4=0; busy();

כאשר אנו רוצים שהמסך יבצע את הפעולה שכתבנו לפורטי הדאטה או שאנו רוצים

שהמסך ידפיס תו שכתבנו לפורטי הדאטה.

Shahar	
Hikri_	

```
#include <xc.h>
#include <string.h>
/*standard "pragma config's" in here... */
void busy(void); void initLCD();
void main() {
   char* line1 = "Shahar";
    char* line2 = "Hikri";
   int i;
   initLCD();
    /*PRINT TO 1'ST LINE*/
    /*command mode*/
    PORTBbits.RB15 = 0;
    /*flush LCD and print to 1'st line command execute*/
    PORTE = 0x1;
    //execute command
    PORTDbits.RD4 = 1;
    PORTDbits.RD4 = 0;
   busy();
    /*data mode*/
    PORTBbits.RB15 = 1;
    /*print line1 = "Shahar"*/
    for(i=0;i<strlen(line1);i++){</pre>
        PORTE=line1[i];
        //print char
        PORTDbits.RD4 = 1;
        PORTDbits.RD4 = 0;
        busy();
    /*PRINT TO 2'ND LINE*/
    /*command mode*/
    PORTBbits.RB15 = 0;
    /*flush LCD and print to 1'st line command execute*/
    PORTE = 0xc0;
    //execute command
    PORTDbits.RD4 = 1;
    PORTDbits.RD4 = 0;
   busy();
    /*data mode*/
    PORTBbits.RB15 = 1;
    /*print line2 = "Hikri"*/
    for(i=0;i<strlen(line2);i++){</pre>
        PORTE=line2[i];
        //print char
        PORTDbits.RD4 = 1;
        PORTDbits.RD4 = 0;
        busy();
    }
```

```
void busy(void) {
  char RD = PORTDbits.RD5;
  char RS = PORTBbits.RB15;
  int STATUS TRISE = TRISE;
  PORTBbits.RB15 = 0; //Command mode
  PORTDbits.RD5 = 1; //Read mode (from DB0-DB7)
  //DB7 Tris set to input (BF register)
  TRISE |= 0x80;
  do {
   PORTDbits.RD4 = 1; //enable=1
   PORTDbits.RD4 = 0; //enable=0
  while (PORTEbits.RE7); // (DB7) BF register
  PORTDbits.RD5 = RD;
 PORTBbits.RB15 = RS;
 TRISE = STATUS TRISE;
void initLCD() {
  char control[] = \{0x38, 0x38, 0x38, 0xe, 0x6, 0x1\};
  //init DISP RS DISP RW DISP EN
 TRISBbits.TRISB15 = 0; // DISP RS (RB15) as Output
  ANSELBbits.ANSB15 = 0; // DISP RS (RB15) disable analog
  TRISDbits.TRISD5 = 0; // DISP RW (RD5) set as an Output
 TRISDbits.TRISD4 = 0; // DISP EN (RD4) set as an Output
  //init DB0-DB7
  TRISE &= 0xff00;
 ANSELEbits.ANSE2 = 0;
 ANSELEbits.ANSE4 = 0;
 ANSELEbits.ANSE5 = 0;
 ANSELEbits.ANSE6 = 0;
 ANSELEbits.ANSE7 = 0;
  PORTBbits.RB15 = 0; //rs=0 (Command)
  PORTDbits.RD5 = 0; //w=0 (Write into )
  for (i = 0; i < 6; i++) {
   PORTE = control[i];
    //signal
    PORTDbits.RD4 = 1;
    PORTDbits.RD4 = 0;
   busy();
  }
```

רגיסטר ה-BF – לאחר שהמידע נקרא מdb0-db7 אז הdb7 הופך להיות הBF – לאחר שהמידע נקרא מdb0-db7 אז הb7 – BF – לאחר שהמידע נקרא מלומר כאשר הוא 1 המסך כרגע מעבד את המידע ומבצע את הפעולה\מדפיס תו. לכן רק שהFF שהBF יורד ל0 ניתן לעשות פעולה חדשה\להדפיס תו נוסף על המסך. (מופיע בפונקציה (Busy).


<u>הוספת תווים שלא קיימים</u>

האוכסנים בזיכרון זה. ASCII (כמעט כל – CGROM

שמכיל תווים שאנחנו יוצרים. יצירת תו הינה מערך של char-ים שכל – CGRAM – זיכרון שמכיל תווים שאנחנו יוצרים. יצירת חו הינה מערך של ביט כבוי הוא פיקסל אחד מהם מייצג שורה בהתאמה, כל ביט דלוק בו הוא פיקסל דלוק וכל ביט כבוי הוא פיקסל כבוי.

- צורבים לCGRAM את התו בעזרת הפעולה •
- עד 8 תווים חדשים ו"קוד הASCII" שלהם בבקר יהיו מ0 עד CGRAM (לאחסן ב במקר יהיו מ0 עד 8 בהתאם לסדר צריבתם.

דוגמא לצריבת התווים 'ש','ת' והדפסת:



```
#include <xc.h>
/*standard "pragma config's" in here... */
void busy(void);
void initLCD();
#define DISP EXEC
                      PORTDbits.RD4 = 1; PORTDbits.RD4 = 0; busy();
void main() {
    initLCD();
   char CG_{shin[8]} = \{0b10101,
                     0b10101,
                     0b10101,
                     0b10101,
                     0b10101.
                     0b10101,
                     0b10101,
                     0b11111};
   char CG_taf[8] = { 0b01111,
                     0b01001,
                     0b01001,
                     0b01001.
                     0b01001.
                     0b01001,
                     0b01001,
                     0b11001};
    char shin = 0;
    char taf = 1;
    PORTBbits.RB15 = 0;//COMMAND mode
    PORTE=0 \times 40;
                       //Add char's to CDRAM
    DISP EXEC
    PORTBbits.RB15 = 1;//DATA
    /*Write char's to CDRAM*/
    int i;
    for(i = 0;i < 8;i++){ //writing 'W' to CGRAM</pre>
         PORTE=CG shin[i];
         DISP EXEC
    for (i = 0; i < 8; i++) {//writing 'n' to CGRAM
         PORTE=CG taf[i];
         DISP EXEC
```

```
/*Print 'nwsT'*/
PORTBbits.RB15 = 0; //COMMAND mode
PORTE=0x80; //Write in 1'st line command
DISP_EXEC

/*data mode*/
PORTBbits.RB15 = 1;
PORTE=taf;
DISP_EXEC

PORTE=shin;
DISP_EXEC

PORTE='T';
DISP_EXEC

PORTE='T';
DISP_EXEC

PORTE='S';
DISP_EXEC
```

					C	ode					_	Execution Time (max) (when f _{cp} or
Instruction	RS	R/W	DB7	DB6	DB5	DB4	DB3	DB2	DB1	DB0	Description	f _{osc} is 270 kHz)
Clear display	0	0	0	0	0	0	0	0	0	1	Clears entire display and sets DDRAM address 0 in address counter.	
Return home	0	0	0	0	0	0	0	0	1	_	Sets DDRAM address 0 in address counter. Also returns display from being shifted to original position. DDRAM contents remain unchanged.	1.52 ms
Entry mode set	0	0	0	0	0	0	0	1	I/D	S	Sets cursor move direction and specifies display shift. These operations are performed during data write and read.	37 μs
Display on/off control	0	0	0	0	0	0	1	D	С	В	Sets entire display (D) on/off, cursor on/off (C), and blinking of cursor position character (B).	37 µs
Cursor or display shift	0	0	0	0	0	1	S/C	R/L	_	_	Moves cursor and shifts display without changing DDRAM contents.	37 μs
Function set	0	0	0	0	1	DL	Ν	F	_	_	Sets interface data length (DL), number of display lines (N), and character font (F).	37 µs
Set CGRAM address	0	0	0	1	ACG	ACG	ACG	ACG	ACG	ACG	Sets CGRAM address. CGRAM data is sent and received after this setting.	37 µs
Set DDRAM address	0	0	1	ADD	ADD	ADD	ADD	ADD	ADD	ADD	Sets DDRAM address. DDRAM data is sent and received after this setting.	37 μs
Read busy flag & address	0	1	BF	AC	AC	AC	AC	AC	AC	AC	Reads busy flag (BF) indicating internal operation is being performed and reads address counter contents.	0 µs
					Co	ode						Execution Time (max) (when f _{cp} c
Instruction	RS	R/W	DB7	DB6	DB5	DB4	DB3	DB2	DB1	DB0	Description	f _{osc} is 270 kHz)
Write data to CG or DDRAM	1	0	Write	data							Writes data into DDRAM or CGRAM.	$37 \mu s$ $t_{ADD} = 4 \mu s^*$
Read data from CG or DDRAM	1	1	Read	d data							Reads data from DDRAM or CGRAM.	$37 \mu s$ $t_{ADD} = 4 \mu s^*$
	S/C R/L R/L	= 1: = 1:	Decr Acco Disp Curs Shift Shift 8 bits 2 line 5 × 1 Inter	ment ement mpan lay shi or mo to the to the s, DL = es, N = 0 dots nally o	ies dis ift ve right left = 0: 4 = 0: 1 s, F = 0	bits line D: 5×	8 dots				DDRAM: Display data RAM CGRAM: Character generator RAM ACG: CGRAM address ADD: DDRAM address (corresponds to cursor address) AC: Address counter used for both DD and CGRAM addresses	frequency change Example: When f _{op} or f _{osc} is 250 kHz,

מקלדת (Pull Up<u>)</u>

Pmod pin	Schematic Label	PIC32 pin	Description
PMODA_1	JA_1	RPC2/RC2	X0
PMODA_2	JA_2	RPC1/RC1	X1
PMODA_3	JA_3	RPC4/CTED7/RC4	X2
PMODA_4	JA_4	AN16/C1IND/RPG6/SCK2/PMA5/RG6	X3
PMODA_7	JA_7	RPC3/RC3	Y0
PMODA_8	JA_8	AN17/C1INC/RPG7/PMA4/RG7	Y1
PMODA_9	JA_9	AN18/C2IND/RPG8/PMA3/RG8	Y2
PMODA_10	JA_10	AN19/C2INC/RPG9/PMA2/RG9	Y3

צים – פורטים **יציאה** (אותם משנים בקוד - מכבים לשם הבדיקה ואז מדליקים חזרה).

Y-ים – פורטים **כניסה** (אותם בודקים בקוד – אם כבויים).


בדיקה האם כפתור נלחץ:

כאשר רוצים לבדוק האם הכפתור ב(X1,Y2) (הכפתור '6') נלחץ:

נכבה את X0.

נלחץ). (X1,Y2) כבוי (אם כן אז הכפתור ב

נדליק חזרה את X0.



```
#define X0 PORTCbits.RC2
#define X1 PORTCbits.RC1
#define X2 PORTCbits.RC4
#define X3 PORTGbits.RG6
#define Y0 PORTCbits.RC3
#define Y1 PORTGbits.RG7
#define Y2 PORTGbits.RG8
#define Y3 PORTGbits.RG9
/*Left digit represents the X number
 Right digit represents te Y number*/
int getPressedKbBtn(){
   X0=1; X1=1; X2=1; X3=1;
   X0 = 0;
   if(!Y0)
       return 00;
    if(!Y1)
       return 01;
    if(!Y2)
       return 02;
    if(!Y3)
       return 03;
    X0 = 1;
   X1 = 0;
    if(!Y0)
        return 10;
    if(!Y1)
        return 11;
    if(!Y2)
        return 12;
    if(!Y3)
        return 13;
   X1=1;
   X2 = 0;
    if(!Y0)
        return 20;
    if(!Y1)
        return 21;
    if(!Y2)
        return 22;
    if(!Y3)
        return 23;
    X2=1;
   X3=0;
    if(!Y0)
        return 30;
    if(!Y1)
        return 31;
    if(!Y2)
        return 32;
    if(!Y3)
        return 33;
    X3=1;
    return -1;
```

```
void initKeyBoard(){
    /* X's init */
   TRISCbits.TRISC2=0;//X0 (RC2) as Output
   TRISCbits.TRISC1=0;//X1 (RC1) as Output
   TRISCbits.TRISC4=0;//X2 (RC4) as Output
   TRISGbits.TRISG6=0;//X3 (RG6) as Output
   ANSELGbits.ANSG6=0;//
                             disable Anaglog
   X0=1; X1=1; X2=1; X3=1;
    /* Y's init */
   TRISCbits.TRISC3 =1;//Y0 (RC3) as Input
   CNPUCbits.CNPUC3; //Pull Up Resistor enable
   TRISGbits.TRISG7=1;//Y1 (RG7) as Input
   ANSELGbits.ANSG7=0;
   CNPUGbits.CNPUG7;
   TRISGbits.TRISG8=1;//Y2 (RG8) as Input
   ANSELGbits.ANSG8=0;
   CNPUGbits.CNPUG8;
   TRISGbits.TRISG9=1;//Y3 (RG9) as Input
   ANSELGbits.ANSG9=0;
   CNPUGbits.CNPUG9;
```

<u>השהיות בין הלחיצות כדי לקבל לחיצה בודדת:</u>

בין בדיקה לבדיקה (בדיקה = איזה מקש נלחץ ~ הפעלת פונ' ()getPressedBtn) בין בדיקה לבדיקה (בדיקה = איזה מקש נלחץ

```
for(i=0;i<64000;i++);

for(i=0;i<64000;i++);

for(i=0;i<64000;i++);

for(i=0;i<64000;i++);

for(i=0;i<64000;i++);
```

(לדוגמא שרוצים להדפיס על המסך את התו המייצג את המקש שנלחץ – אם לא נשים השהיה בין הלחיצות יודפס למסך כמה פעמים עבור כל לחיצה).

```
void initKeyBoard(); int in_y(int a);
/* תוכנית שמדפיסה על הלדים את המספר של הכפתור שנלחץ בייצוג בינארי
void main(void) {
 TRISA&=0xff00;//led
  initKeyBoard();
  char scan key[] = {
  // XY
    0x44, 1, //0b 0100 0100
    0x34, 2, //0b 0011 0100
    0x24, 3, //0b 0010 0100
    0x43, 4, //0b 0100 0100
0x33, 5, //0b 0100 0100
    0x23, 6, //0b 0100 0100

0x42, 7, //0b 0100 0100

0x32, 8, //0b 0100 0100

0x22, 9, //0b 0100 0100

0x41, 0 //0b 0100 0100
  };
  int i, xy;
  while (1) {
    while (1) {
      i = 1;
      PORTCbits.RC2 = 1;
      PORTCbits.RC1 = 1;
      PORTCbits.RC4 = 1;
      PORTGbits.RG6 = 1;
      i = 1;
      PORTCbits.RC2 = 0;
      xy = in y(1);
      if (xy != 0xff)
        break;
      PORTCbits.RC2 = 1;
       i = 2;
      PORTCbits.RC1 = 0;
      xy = in y(2);
      if (xy != 0xff)
        break;
      PORTCbits.RC1 = 1;
       i = 3;
      PORTCbits.RC4 = 0;
      xy = in y(3);
      if (xy = 0xff)
        break;
      PORTCbits.RC4 = 1;
       i = 4;
      PORTGbits.RG6 = 0;
      xy = in y(4);
      if (xy != 0xff)
         break;
       PORTGbits.RG6 = 1;
    for (i = 0; i < 20; i += 2)
       if (scan key[i] == xy)
         PORTA = scan key[i + 1];
```

```
int in_y(int a) {
  int j = 1, flag = 0;
  if (!PORTCbits.RC3) {
    flag = 1;
    j = 1;
  } else if (!PORTGbits.RG7) {
    flag = 1;
    j = 2;
  } else if (!PORTGbits.RG8) {
    flag = 1;
    j = 3;
  } else if (!PORTGbits.RG9) {
    flag = 1;
    j = 4;
  if (flag == 0)
    return (0xff);
  else
    return (j | (a << 4));</pre>
```

ADC (Analog to Digital)

רכיב אשר **מקבל** מתח מכניסה (אנלוגית) נבחרת מ ANO - AN15.

• כל כניסה ANi מחוברת ליציאה •

מחזיר מספר בעל 10 ביט (0-1024) המייצג את המתח שקיבל.

<u>לדוגמא:</u>

הכניסה הנבחרת AN2 שהמתח בה נע בין 0v ל<3.3v


אם המתח שנדגם בכניסה AN2(שמחוברת ליציאה RB2) הוא 2V

$$\frac{2v}{3.3v-0v}$$
 * 1024 = **621** :אז יחזיר

float V = (((float)ADC_AnalogRead(2)) / 1023) * 3.3; : המרה בקוד

לפני ההפעלה צריך להפעיל את האנלוג:

TRISBbits.TRISB2 = 1;
ANSELBbits.ANSB2 = 1;



התהליך שהADC מבצע:

- 1. דגימה(Sampling) דוגם את המתח ביציאה הנבחרת.
- . מבצעים להתחלת את הדגימה AD1CON1bits.SAMP = 1
- (ואז ההמרה מתחילה אוטומטית) AD1CON1bits.SAMP is 0 *
- 2. **המרה(Conversion)** ממיר את המתח למספר מייצג (בגודל 10-ביט) שאותו שם על הרגיסטר ASVBUFO.
 - cאשר מתחילה ההמרה. AD1CON1bits.DONE is 0
 - AD1CON1bits.DONE is 1 כאשר מסתיימת ההמרה ההמרה.
- * AD1CON3 הערך בו קובע את משך זמן ההמרה (המקסימלי), ככל שיהיה משך זמן גדול יותר אז יהיו פחות שגיאות אך ההמרה תיקח יותר זמן.

```
void ADC Init(){
   AD1CON1 =0;
   AD1CON1bits.SSRC = 7; //Auto convert (after sampeling)
   AD1CON1bits.FORM = 0; //16 bit integer result
   // Setup for manual sampling
   AD1CSSL =0;
   AD1CON3 = 0 \times 0002; //ADC Conversion Clock
   AD1CON2 =0;
   AD1CON2bits.VCFG = 0;
   // Turn on ADC
   AD1CON1bits.ON = \frac{1}{2}; //ADC on (activate)
}
unsigned int ADC AnalogRead (unsigned char analogPIN) {
   int adc val = 0;
   //IECObits.T2IE = 0;
   AD1CHS = analogPIN << 16; // AD1CHS<16:19> controls which
                                 //analog pin goes to the ADC
   adc val = ADC1BUF0;
   //IECObits.T2IE = 1;
   return adc val;
}
```

Virtual Address	Name		Bit 31/23/15/7	Bit 30/22/14/6	Bit 29/21/13/5	Bit 28/20/12/4	Bit 27/19/11/3	Bit 26/18/10/2	Bit 25/17/9/1	Bit 24/16/8/0
BF80_9000	AD1CON1	31:24	_	_	_	_	_	_	_	_
		23:16	_	_	-	_	-	_	_	_
		15:8	ON	FRZ	SIDL	_	-	FORM2	FORM1	FORM0
		7:0	SSRC2	SSRC1	SSRC0	CLRASAM	_	ASAM	SAMP	DONE
BF80_9004	AD1CON1CLR	31:0		Write	clears selected	bits in AD1C0	DN1, read yield	s undefined va	alue	
BF80_9008	AD1CON1SET	31:0		Write	sets selected	bits in AD1CO	N1, read yields	s undefined val	lue	
BF80_900C	AD1CON1INV	31:0		Write	inverts selecte	d bits in AD1C	ON1, read yiek	ds undefined v	alue	
BF80_9010	AD1CON2	31:24	_	_	_	_	_	_	_	_
		23:16	_	_	_	_	_	_	_	_
		15:8	VCFG2	VCFG1	VCFG0	OFFCAL	_	CSCNA	_	_
		7:0	BUFS	_	SMPI3	SMPI2	SMPI1	SMPI0	BUFM	ALTS
BF80_9014	AD1CON2CLR	31:0		Write	clears selected	bits in AD1C0	DN2, read yield	s undefined va	alue	
BF80_9018	AD1CON2SET	31:0		Write	sets selected	bits in AD1CO	N2, read yields	s undefined val	lue	
BF80_901C	AD1CON2INV	31:0		Write i	inverts selecte	d bits in AD1C	ON2, read yield	ds undefined v	alue	
BF80_9020	AD1CON3	31:24	_	_	_	_	_	_	_	_
		23:16	_	_	_	_	_	_	_	_
		15:8	ADRC	_	_	SAMC4	SAMC3	SAMC2	SAMC1	SAMC0
	,	7:0	ADCS7	ADCS6	ADCS5	ADCS4	ADCS3	ADCS2	ADCS1	ADCS0
BF80_9024	AD1CON3CLR	31:0		Write	clears selected	bits in AD1C0	DN3, read yield	ts undefined va	alue	
BF80_9028	AD1CON3SET	31:0		Write	sets selected	bits in AD1CO	N3, read yields	s undefined val	lue	
BF80_902C	AD1CON3INV	31:0		Write i	inverts selecte	d bits in AD1C	ON3, read yield	ds undefined v	alue	
BF80_9040	AD1CHS	31:24	CH0NB	_	_	_	CH0SB3	CH0SB2	CH0SB1	CH0SB0
		23:16	CH0NA	_	_	_	CH0SA3	CH0SA2	CH0SA1	CH0SA0
	'	15:8	_	_	_	_	_	_	_	_
		7:0	_	_	_	_	_	_	_	_
BF80_9044	AD1CHSCLR	31:0		Write	clears selecte	d bits in AD1C	HS, read yield:	s undefined va	lue	•
BF80_9048	AD1CHSSET	31:0		Write	e sets selected	bits in AD1CH	S, read yields	undefined valu	Je .	
BF80_904C	AD1CHSINV	31:0		Write	inverts selecte	d bits in AD10	HS, read yield	s undefined va	lue	
BF80_9060	AD1PCFG	31:24	_	_	_	_	_	_	_	_
	,	23:16	_	_	_	_	_	_	_	_
		15:8	PCFG15	PCFG14	PCFG13	PCFG12	PCFG11	PCFG10	PCFG9	PCFG8
		7:0	PCFG7	PCFG6	PCFG5	PCFG4	PCFG3	PCFG2	PCFG1	PCFG0
BF80_9064	AD1PCFGCLR	31:0		Write	clears selected	bits in AD1P0	CFG, read yield	ls undefined va	alue	
BF80_9068	AD1PCFGSET	31:0		Write	sets selected	bits in AD1PC	FG, read yields	s undefined val	ue	
BF80_906C	AD1PCFGINV	31:0		Write	inverts selecte	d bits in AD1P	CFG, read yield	ds undefined va	alue	
BF80_9050	AD1CSSL	31:24	_	_	_	_	_	_	_	_
		23:16	_	_	_	_	_	_	_	_
		15:8	CSSL15	CSSL14	CSSL13	CSSL12	CSSL11	CSSL10	CSSL9	CSSL8
		7:0	CSSL7	CSSL6	CSSL5	CSSL4	CSSL3	CSSL2	CSSL1	CSSL0

REGISTER 22-1: AD1CON1: ADC CONTROL REGISTER 1 (CONTINUED)

bit 4 CLRASAM: Stop Conversion Sequence bit (when the first A/D converter interrupt is generated)

1 = Stop conversions when the first ADC interrupt is generated. Hardware clears the ASAM bit when the ADC interrupt is generated. "פסיקות

= Normal operation, buffer contents will be overwritten by the next conversion sequence

bit 3 Reserved: Write 'o'; ignore read

bit 2 ASAM: ADC Sample Auto-Start bit

צורת הפעלה

1 = Sampling begins immediately after last conversion completes; SAMP bit is automatically set.

0 = Sampling begins when SAMP bit is set

bit 1 SAMP: ADC Sample Enable bit

אפשור דגימה

1 = The ADC SHA is sampling

The ADC sample/hold amplifier is holding
 When ASAM = 0, writing '1' to this bit starts sampling.

When SSRC = 000, writing '0' to this bit will end sampling and start conversion.

bit 0 DONE: A/D Conversion Status bit

1 = A/D conversion is done

דגל BUSY

a = A/D conversion is not done or has not started
 clearing this bit will not affect any operation in progress.

Note: The DONE bit is not persistent in automatic modes. It is cleared by hardware at the beginning of the next sample.

REGISTER 22-3: AD1CON3: ADC CONTROL REGISTER 3

r-x	r-x	r-x	r-x	r-x	r-x	r-x	r-x
_	_	_	_	_	_	_	_
bit 31	_	-	-				bit

r-x	r-x	r-x	r-x	r-x	r-x	r-x	r-x
_	_	_	_	_	_	_	_
bit 23							bit

R/W-0	r-x	r-x	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
ADRC	_	_			SAMC<4:0>		
bit 15							b

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0			
ADCS<7:0>										
bit 7							b			

Legend:

R = Readable bit W = Writable bit P = Programmable bit r = Reserved bit

U = Unimplemented bit -n = Bit Value at POR: ('0', '1', x = Unknown)

bit 31-16 Reserved: Write '0'; ignore read

bit 15 ADRC: ADC Conversion Clock Source bit

1 = ADC internal RC clock

0 = Clock derived from Peripheral Bus Clock (PBClock)

קצב המרה

bit 14-13 Reserved: Write '0'; ignore read bit 12-8 SAMC<4:0>: Auto-Sample Time bits

11111 = 31 TAD

00001 = 1 TAD 00000 = 0 TAD (Not allowed)

bit 7-0 ADCS<7:0>: ADC Conversion Clock Select bits

11111111 = TpB • (ADCS<7:0> + 1) • 2 = 512 • TpB = TaD

.

00000001 = TpB • (ADCS<7:0> + 1) • 2 = 4 • TpB = TAD 00000000 = TpB • (ADCS<7:0> + 1) • 2 = 2 • TpB = TAD

	22-2: AD1C0	DN2: ADC CO	ONTROL RE	GISTER 2			
r-x	r-x	r-x	r-x	r-x	r-x	r-x	r-x
_		_	_	_	_	_	_
bit 31							bit
r-x	r-x	r-x	r-x	r-x	r-x	r-x	r-x
		_	_	_	_	_	_
bit 23							bit
R/W-0	R/W-0	R/W-0	R/W-0	r-x	R/W-0	r-x	r-x
	VCFG<2:0>		OFFCAL	_	CSCNA	_	
bit 15							bi
					544.0	5	
R-0	r-x	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
BUFS	_		SMP	1<3:0>		BUFM	ALTS
bit 7							bi
Legend:							
R = Readable	a hit	W = Writable	bit	P = Progran	nmable bit	r = Reserved	hit
U = Unimplen			at POR: ('0', '	•		i – iveserved	DIC
	VCEG-2:05:	Voltage Pefere	nce Configure	tion hite			
bit 15-13	VCFG<2:0>:	√oltage Refere	nce Configura		DC VR-]	
DIL 10-13	VCFG<2:0>:	ADO		A	DC VR-		
DIL 19-13		ADO	VR+	AI			
JIL 13*13	000	ADC AV External	VR+	A	AVss		
DIC 10-13	000	ADO A\ External	VR+ /DD VREF+ pin	All Externa	AVss AVss		
ык 13-13	000 001 010	ADC A\ External A\ External	VR+ /DD VREF+ pin /DD	Externa Externa	AVss AVss al Vref- pin		
bit 12	000 001 010 011 1xx	ADC A\ External A\ External	VR+ VDD VREF+ pin VREF+ pin VREF+ pin	Externa Externa	AVss AVss al VREF- pin al VREF- pin AVss		
	000 001 010 011 1xx OFFCAL: Inp 1 = Enable Of VINH and 0 = Disable O	ADC A\ External \ A\ External \ A\	VR+ /DD VREF+ pin /DD VREF+ pin /DD ration Mode Sen mode A are connected mode	Externa Externa Externa	AVss AVss al VREF- pin al VREF- pin AVss OIN' NNY		
	000 001 010 011 1xx OFFCAL: Inp 1 = Enable Of VINH and 0 = Disable Of The input	ADC AV External AV External AV ut Offset Calibration VINL of the SHA ffset Calibration	VR+ /DD VREF+ pin /DD VREF+ pin /DD ration Mode Sen mode A are connected in mode are controlled by	Externa Externa Externa	AVss AVss al VREF- pin al VREF- pin AVss OIN' NNY		
bit 12	000 001 010 011 1xx OFFCAL: Inp 1 = Enable Of VINH and 0 = Disable O The input Reserved: W	ADO AVEXTERNAL External AVEXTERNAL AVE	VR+ /DD VREF+ pin /DD VREF+ pin /DD ration Mode Sen mode A are connected in mode irre controlled by the controlled by th	External External External elect bit ad to VR-	AVSS AVSS al VREF- pin al VREF- pin AVSS OIN' NNY	_	g bit
bit 12	O00 O01 O10 O11 1xx OFFCAL: Inp 1 = Enable Of VINH and 0 = Disable O The input Reserved: W CSCNA: Scar 1 = Scan input 0 = Do not sca	ADO AVEXTERNAL External AVEXTERNAL AVE	VR+ /DD VREF+ pin /DD VREF+ pin /DD ration Mode Sen mode A are connected are controlled by the constant of the	Externa Externa Externa elect bit ed to VR- y AD1CHS of	AVSS AVSS al VREF- pin al VREF- pin AVSS OIN' NNY	_	g bit
bit 12 bit 11 bit 10	000 001 010 011 1xx OFFCAL: Inp 1 = Enable Of VINH and 0 = Disable O The input Reserved: W CSCNA: Scar 1 = Scan input 0 = Do not scar Reserved: W BUFS: Buffer Only valid who 1 = ADC is cu	ADO AV External AV External AV UIT Offset Calibration VINL of the SHA Iffset Calibration VINL of the SHA a rite '0'; ignore in Input Selection an input Selection is an inputs Fill Status bit an BUFM = 1 (irrently filling bu	VREF+ pin VREF+ pin VDD VREF+ pin VDD ration Mode Sen mode A are connected are controlled by the	External External External External elect bit ad to VR- y AD1CHS of GHA Input for GHA input for graph and action 2 x 8-word user should a	AVSS AVSS al VREF- pin al VREF- pin AVSS OIN' NNY. T AD1CSSL MUX A Input Mul	itiplexer Setting סטר תוצאו סטר 2-00	

ADACONO, ADO CONTROL DECICTED O

REGISTER 22-2: AD1CON2: ADC CONTROL REGISTER 2 (CONTINUED)

bit 5-2 SMPI<3:0>: Sample/Convert Sequences Per Interrupt Selection bits

פסיקות

1111 = Interrupts at the completion of conversion for each 16th sample/convert sequence

1110 = Interrupts at the completion of conversion for each 15th sample/convert sequence

0001 = Interrupts at the completion of conversion for each 2^{nd} sample/convert sequence 0000 = Interrupts at the completion of conversion for each sample/convert sequence

bit 1 BUFM: ADC Result Buffer Mode Select bit

1 = Buffer configured as two 8-word buffers, ADC1BUF(7...0), ADC1BUF(15...8)

0 = Buffer configured as one 16-word buffer ADC1BUF(15...0.)

תוצאה

bit 0 ALTS: Alternate Input Sample Mode Select bit

> 1 = Uses MUX A input multiplexer settings for first sample, then alternates between MUX B and MUX A input multiplexer settings for all subsequent samples

0 = Always use MUX A input multiplexer settings

שימוש ב-MUX

REGISTER 22-4: AD1CHS: ADC INPUT SELECT REGISTER

R/W-0	г-х	Г-Х	r-x	R/W-0	R/W-0	R/W-0	R/W-0
CH0NB	_	_	_		CH0SE	<3:0>	
bit 31							bit 24

R/W-0	r-x	r-x	r-x	R/W-0	R/W-0	R/W-0	R/W-0
CH0NA	_	_	_		CH0SA	<3:0>	
bit 23							bit 16

r-x	r-x	Γ-X	r-x	r-x	r-x	r-x	г-х
_	_	_	_	_	_	_	_
bit 15							bit 8

r-x	r-x	r-x	r-x	r-x	r-x	r-x	r-x
_	_	_	_	_	_	_	_
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit P = Programmable bit r = Reserved bit

U = Unimplemented bit -n = Bit Value at POR: ('0', '1', x = Unknown)

bit 31 CH0NB: Negative Input Select for MUX B bit

1 = Channel 0 negative input is AN1

0 = Channel 0 negative input is VR-

bit 30-28 Reserved: Write '0'; ignore read

bit 27-24 CH0SB<3:0>: Positive Input Select for MUX B bits

1111 = Channel 0 positive input is AN15 1110 = Channel 0 positive input is AN14

1101 = Channel 0 positive input is AN13

.

0001 = Channel 0 positive input is AN1 0000 = Channel 0 positive input is AN0

bit 23 CHONA: Negative Input Select for MUX A Multiplexer Setting bit (2)

1 = Channel 0 negative input is AN1

0 = Channel 0 negative input is VR-

bit 22-20 Reserved: Write '0'; ignore read

bit 19-16 CH0SA<3:0>: Positive Input Select for MUX A Multiplexer Setting bits

1111 = Channel 0 positive input is AN15 1110 = Channel 0 positive input is AN14

1101 = Channel 0 positive input is AN13

.

0001 = Channel 0 positive input is AN1 0000 = Channel 0 positive input is AN0

bit 15-0 Reserved: Write '0' ignore read

REGISTER 22-5: AD1PCFG: ADC PORT CONFIGURATION REGISTER

r-0	r-0	r-0	r-0	r-0	r-0	r-0	r-0
_	_	_	_	_	_	_	_
bit 31							bit 24

r-0	r-0	r-0	r-0	r-0	r-0	r-0	r-0
_	_	_	_	_	_	-	_
bit 23							bit 16

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
PCFG15	PCFG14	PCFG13	PCFG12	PCFG11	PCFG10	PCFG9	PCFG8
bit 15							bit 8

R/W-0	RW-0	R/W-0	R/W-0	R/W-0	R/W-0	RW	R/W-0
PCFG7	PCFG6	PCFG5	PCFG4	PCFG3	PCFG2	PCFG1	PCFG0
bit 7	•						bit 0

Legend:

R = Readable bit W = Writable bit P = Programmable bit r = Reserved bit

U = Unimplemented bit -n = Bit Value at POR: ('0', '1', x = Unknown)

bit 31-16 Reserved: Reserved for future use, maintain as '0'

bit 15-0 PCFG<15:0>: Analog Input Pin Configuration Control bits

- 1 = Analog input pin in Digital mode, port read input enabled, ADC input multiplexer input for this analog input connected to AVss
- 0 = Analog input pin in Analog mode, digital port read will return as a '1' without regard to the voltage on the pin, ADC samples pin voltage

PIC32MX3XX/4XX

REGISTER 22-6: AD1CSSL: ADC INPUT SCAN SELECT REGISTER

r-x	r-x	r-x	r-x	r-x	r-x	r-x	r-x
_	_	_	_	_	_	_	_
bit 31							bit 24

r-x	r-x	r-x	r-x	r-x	r-x	r-x	r-x
_	_	_	_	_	_	_	_
bit 23							bit 16

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
CSSL15	CSSL14	CSSL13	CSSL12	CSSL11	CSSL10	CSSL9	CSSL8
bit 15							bit 8

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	RW	R/W-0
CSSL7	CSSL6	CSSL5	CSSL4	CSSL3	CSSL2	CSSL1	CSSL0
bit 7							

Legend:

R = Readable bit W = Writable bit P = Programmable bit r = Reserved bit U = Unimplemented bit P = Bit Value at POR: ('0', '1', X = Unknown)

bit 31-16 Reserved: Write '0'

bit 15-0 CSSL<15:0>: ADC Input Pin Scan Selection bits

1 = Select ANx for input scan 0 = Skip ANx for input scan

TABLE 22-3: PINS ASSOCIATED WITH THE ADC MODULE

Pin Name	Module Control	Controlling Bit Field	Pin Type	Buffer Type	TRIS	Description
AN0	ON	AD1PCFG<0>	Α	_	Input	Analog Input
AN1	ON	AD1PCFG<1>	Α	_	Input	Analog Input
AN2	ON	AD1PCFG<2>	Α	_	Input	Analog Input
AN3	ON	AD1PCFG<3>	Α	_	Input	Analog Input
AN4	ON	AD1PCFG<4>	Α	_	Input	Analog Input
AN5	ON	AD1PCFG<5>	Α	_	Input	Analog Input
AN6	ON	AD1PCFG<6>	Α	_	Input	Analog Input
AN7	ON	AD1PCFG<7>	Α	_	Input	Analog Input
AN8	ON	AD1PCFG<8>	Α	_	Input	Analog Input
AN9	ON	AD1PCFG<9>	Α	_	Input	Analog Input
AN10	ON	AD1PCFG<10>	Α	_	Input	Analog Input
AN11	ON	AD1PCFG<11>	Α	_	Input	Analog Input
AN12	ON	AD1PCFG<12>	Α	_	Input	Analog Input
AN13	ON	AD1PCFG<13>	Α	_	Input	Analog Input
AN14	ON	AD1PCFG<14>	Α	_	Input	Analog Input
AN15	ON	AD1PCFG<15>	Α	_	Input	Analog Input
VREF+	ON	AD1CON2<15:13>	Р	_	_	Positive Voltage Reference
VREF-	ON	AD1CON2<15:13>	Р	_	_	Negative Voltage Reference

Legend: ST = Schmitt Trigger input with CMOS levels
I = Input
O = Output

A = Analog P = Power

Timers

טיימר הוא רכיב בעל גביש שנותן פולס בסוף כל פרק זמן (קבוע).

<u>אורך פרק הזמן</u>


אורך האינטרוול קבוע ומוגדר מראש ע"י הערכי PR,TMR,PS של הטיימר באופן הבא:

$$t = \frac{PS * (PR - TMR)}{f} [sec]$$


in PIC32:
$$f = 80MHz = 80 * 10^6 Hz (Hz = \frac{1}{\text{Sec}})$$

עושים init לטיימר באופן הבא (בדוגמא מאתחלים ומפעילים את TIMER1):

<u>שלב 1</u> – מקור הפולסים:



שלב 2 - ערכים שקובעים את האינטרוול בין הפולסים של הגביש:



00:1, 01:8, 10:64, 11: 256 :timer1 – ביטים שמייצגים מספר 2 = PS0+PS1

(בצד שמאל ערך הביטים בצד ימין הערך האמיתי של הPrescaler).

ככל שהPS גדול יותר, כך האינטרוול יהיה ארוך/איטי יותר.

שלב 3 – שורת איתחול נוספת (לא הורחב עליה)

T1CONbits.TGATE=0;

(חשוב!) IF שלב 4 – איפוס ביט

רגיסטר הInterrupt Flag) IF) של הטיימר הוא ביט שעולה (מקבל ערך 1) בכל פעם שהגביש נותן פולס.

... אם ברגיסטר היה ערך 1 וניתן פולס אז הוא ישאר

לכן לפני שהIF עולה ל-1 צריך לאפס אותו.

```
IFS0bits.T1IF=0;
```

<u>שלב 5</u> – הפעלת הטיימר

```
T1CONbits.ON=1;
```

:דוגמא


תוכנית שגורמת ללד הראשון לשנות מצב (להתכבות\להידלק) כל 0.2 שניות.

```
/*Left digit represents the X number
 Right digit represents te Y number*/
void main() {
    /*INIT TMR1*/
    //stage1
   TMR1=0;
   PR1=0xFFFF; //0xFFFF = 65535
   T1CONbits.TCKPS0=1;
   T1CONbits.TCKPS1=1;
   //stage2
   T1CONbits.TCS=0;
   //stage 3
   T1CONbits.TGATE=0;
   TRISA = 0;
   PORTA = 0;
   while(1){
       PORTAbits.RA0^=1;
        //DELAY by TMR1
                                    //IF down (stag4)
        IFSObits.T1IF=0;
       T1CONbits.ON=1;
                                    //TMR1 on (stage5)
                                   //wait until IF up
       while(!IFSObits.T1IF);
       T1CONbits.ON=0;
                                    //TMR1 off
   }
```

<u>טיימרים: (בINIT ניתנו הזמנים המקסימליים לאינטרוול)</u>

TMR1






```
/*INIT TMR1*/
                                void delay(void) {
//stage1 (time=0.209 sec)
                                    T1CONbits.ON=0; //TMR off
TMR_{1=0};
PR1=0xFFFF; //=65535
                                    //stage1
T1CONbits.TCKPS0=1; //PS=256
                                    TMR1=0;
                                    PR1=0xFFFF; //0xFFFF = 65535
T1CONbits.TCKPS1=1;
//stage2
                                    T1CONbits.TCKPS0=1;
T1CONbits.TCS=0;
                                    T1CONbits.TCKPS1=1;
//stage 3
                                    //stage2
T1CONbits.TGATE=0;
                                    T1CONbits.TCS=0;
T1CONbits.TSYNC=1;
                                    //stage 3
//stag4
                                    T1CONbits.TGATE=0;
IFSObits.T1IF=0;
                                    T1CONbits.TSYNC=1;
//staq5
                                    //stag4
T1CONbits.ON=1;
                                    IFSObits.T1IF=0;
                                    //stag5
                                    T1CONbits.ON=1;
                                    while(!IFSObits.T1IF);//waiting until IF up
                                }
```

TMR2,3,4,5

FIGURE 14-1: TIMER2, 3, 4, 5 BLOCK DIAGRAM (16-BIT)




```
/*INIT TMR2*/
                                void delay(void){
//stage1 (time=0.209 sec)
                                    T2CONbits.ON=0; //TMR off
TMR_{2=0};
PR2=0xFFFF; //=65535
                                    //stage1
T2CONbits.TCKPS0=1; //PS=256
                                    TMR2=0;
T2CONbits.TCKPS1=1;
                                    PR2=0xFFFF; //0xFFFF = 65535
T2CONbits.TCKPS2=1;
                                    T2CONbits.TCKPS0=1;
//stage2
                                    T2CONbits.TCKPS1=1;
T2CONbits.TCS=0;
                                    T2CONbits.TCKPS2=1;
//stage 3
                                    //stage2
T2CONbits.TGATE=0;
                                    T2CONbits.TCS=0;
//stag4
                                    //stage 3
IFSObits.T2IF=0;
                                    T2CONbits.TGATE=0;
                                    //stag4
//stag5
T2CONbits.ON=1;
                                    IFSObits.T2IF=0;
                                    //stag5
                                    T2CONbits.ON=1;
                                    while(!IFSObits.T2IF);//waiting until IF up
```

TMR23,45

מורכב מ2 הטיימרים TMR2, TMR3 על מנת לתת טיימר אחד שהאינטרוול שלו יותר גדול (הספירה מTMR היא 32 ביט ולא 16 ביט).

:TMR&PR •

- ַכל <u>שאר הרגיסטרים הם של TMR2</u> למעט <u>הIF ששייך לTMR3</u>
- T2CONbits.T32=1; כ"י הפעולה: <u>32bit mode</u> •



```
/*INIT TMR23*/
                                   void delay(void) {
                                       T2CONbits.ON=0;
                                       T3CONbits.ON=0;
//stage1(time=1sec)
                                       //stage1(time=1sec)
TMR_{3}=0;
           //TMR msb
                                       TMR3=0;
                                                  //TMR msb
TMR_{2=0};
            //TMR lsb
                                       TMR2=0;
                                                   //TMR lsb
PR_3 = 0x4;
            //PR 0x4c4b4=312500
                                       PR3=0x4;
                                                   //PR msb
PR_2 = 0xc4b4;
                                       PR2=0xc4b4; //PR lsb
T2CONbits.TCKPS0=1;// PS=256
                                       T2CONbits.TCKPS0=1;// PS=256
T2CONbits.TCKPS1=1;
                                       T2CONbits.TCKPS1=1;
T2CONbits.TCKPS2=1;
                                       T2CONbits.TCKPS2=1;
//stage2
                                       //stage2
T2CONbits.TCS=0;
                                       T2CONbits.TCS=0;
//stage 3
                                       //stage3
T2CONbits.TGATE=0;
                                       T2CONbits.TGATE=0;
//staq4
                                       //stage4
IFSObits.T2IF=0;
                                       IFSObits.T2IF=0;
IFSObits.T3IF=0;
                                       IFSObits.T3IF=0;
                                       //stage5
T2CONbits.T32=1;//mode 32bit
                                       T2CONbits.T32=1;//mode 32bit
T2CONbits.ON=1;
                                       T2CONbits.ON=1;
                                       while(!IFSObits.T3IF);
```

Interrupts

ניתן להגדיר לכל טיימר פונקציית interrupt שכל פעם שהIF של הטיימר עולה ל1 (הגביש נתן פולס) אז הפונקציה מתבצעת אוטומטית.

(ניתן להגדיר פונקציית פסיקה לכל מערכת שנותנת interrupt) פיזי ל23).

- כשמגדירים את הפונקציה מגדירים priority וגם subpriority כך שאם 2 פונקציות
 אמורות להיתבצע באותו הזמן אז תתבצע זו עם העדיפות הגבוהה יותר.
 - בנוסף חייבים לייבא את: sys/attribs.h
 - 7 **Priority** פסיקה בעדיפות הגבוהה ביותר, 1 בעדיפות הנמוכה ביותר, 0 פסיקה לא פעילה.
 - . עדיפות גבוהה, 1 עדיפות נמוכה 3 **Subpriority(1-3)** •

TMR2,3,4,5

```
#include <xc.h>
/*standard "pragma config's" in here... */
#include <sys/attribs.h>
void __ISR(_TIMER_5_VECTOR, ipl2auto) Timer5SR(void);
void
       ISR( TIMER <mark>5</mark> VECTOR, ipl<mark>2</mark>)    Timer<mark>5</mark>SR(void) {
  PORTA++;
   IFS0bits.T\frac{5}{1}IF = 0;
}
void main() {
  int j;
   TRISA &= 0xff00;
    /*INIT TMR5*/
    //stage1 (time=0.209 sec)
    TMR_{5}=0;
   PR<mark>5=0xFFFF; //=65535</mark>
   T5CONbits.TCKPS0=1; //PS=256
   T5CONbits.TCKPS1=1;
   T5CONbits.TCKPS2=1;
    //stage2
   T5CONbits.TCS=0;
    //stage 3
   T5CONbits.TGATE=0;
    //staq4
   IFSObits.T5IF=0;
    //staq5
    T5CONbits.ON=1;
   /*Priority TMR<mark>5</mark>*/
   IPC5bits.T5IP = 2; // Priority
   IPC_{5}^{5}bits.T_{5}^{5}IS = 0; // Subpriority
   IECObits.T5IE = 1; // Enable Interrupt
   /*Enable Interrupts*/
   INTCONbits.MVEC = 1; //vector interrupt
   asm("ei");
                         //on interrupt
}
```

Timer1

```
#include <xc.h>
/*standard "pragma config's" in here... */
#include <sys/attribs.h>
void __ISR(_TIMER_1_VECTOR, ipl5auto) Timer1SR(void);
void __ISR(_TIMER_1_VECTOR, ipl5) Timer1SR(void) {
   PORTA++;
   IFSObits.T1IF = 0;
}
void main() {
  int j;
   TRISA &= 0xff00;
    /*INIT TMR1*/
    //stage1 (time=0.209 sec)
    TMR_{1=0};
    PR<mark>1=0xFFFF; //=65535</mark>
    T1CONbits.TCKPS0=1; //PS=256
    T1CONbits.TCKPS1=1;
    //stage2
    T1CONbits.TCS=0;
    //stage 3
    T1CONbits.TGATE=0;
    //stag4
    IFSObits.T1IF=0;
    //stag5
    T1CONbits.ON=1;
   /*Priority TMR1*/
   IPC1bits.T1IP = 5; // Priority
   IPC_{1}^{1}bits.T_{1}^{1}IS = 0; // Subpriority
   IECObits.T1IE = 1; // Enable Interrupt
   /*Enable Interrupts*/
   INTCONbits.MVEC = 1; //vector interrupt
                       //INTERRUPT PROXIMITY TIMER REGISTER
   IPTMR = 0;
   asm("ei");
                          //on interrupt
```

Timer23,45

```
#include <xc.h>
/*standard "pragma config's" in here... */
#include <sys/attribs.h>
void __ISR(_TIMER_3_VECTOR, ipl6auto) Timer23SR(void);
void __ISR(_TIMER_3_VECTOR, ipl6) Timer23SR(void) {
     PORTA++;
      IFSObits.T3IF = 0;
}
void main() {
    int j;
     TRISA &= 0xff00;
     PORTA = 0;
      /*INIT TMR23*/
      //stage1(time=1sec)
      TMR_3 = 0; //TMR msb
      TMR_2^2 = 0; //TMR lsb
      PR_3 = 0x4; //PR 0x4c4b4 = 312500
      PR2 = 0xc4b4;
      T_{2}^{2}CONbits.TCKPS0 = 1; // PS=256
      T_2^{2}CONbits.TCKPS1 = 1;
     T_2^{2}CONbits.T_{2}^{2}CONbits.T_{2}^{2}CONbits.T_{2}^{2}CONbits.T_{2}^{2}CONbits.T_{2}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CONbits.T_{3}^{2}CON
      //stage2
     T_2^{2}CONbits.T_{CS} = 0;
      //stage 3
      T_2^{2}CONbits.T_3^{2}GATE = 0;
      //stag4
      IFSObits.T_2^2IF = 0;
      IFS0bits.T\frac{3}{2}IF = 0;
      //stag5
      T_2^{2}CONbits.T_3^{2} = 1; //mode 32bit
     T_2^{2}CONbits.ON = 1;
      /*Priority TMR23*/
      IPC_3^3bits.T_3^3IP = 6; // priority
      IPC_{3}^{3}bits.T_{3}^{3}IS = 0; // subpriority
      IECObits.T3IE = 1; // Enable Interrupt
      /*Enable Interrupts*/
      INTCONbits.MVEC = 1; //vector interrupt
      IPTMR = 0; //INTERRUPT PROXIMITY TIMER REGISTER
      asm("ei"); //on interrupt
```