## microcom

A minimalistic terminal program, used to access remote devices via a serial, CAN or telnet connection from the console.

• Open a serial port using the specified baud rate:

```
microcom --port {{path/to/serial_port}} --speed {{baud_rate}}
```

• Establish a telnet connection to the specified host:

```
microcom --telnet {{hostname}}:{{port}}
```