
Notes:

- a) R3 only required for 3.3V logic. It can be omitted for 5V logic b) The output is inverted. If your UART can not handle an inverted
- signal you have to use an inverter
 c) Certain 6N138 can not operate from 3.3V (but I had it in my collection).
 A 3.3V compatible substitute would be the H11L1M for instance which is better in mostly every aspect and features a schmitt trigger pulse restauration



TITLE Resol VBus galvanic isolated slave interface		
FILE:		REVISION:
PAGE	OF	DRAWN BY: CIS