




U700
WCD9306
声音IC

U701
SGM6605
稳压IC

U300
WTR2605
RF_IC

U100
SKY77573
PA+SWITCH

FL201
B2/BC1
SAW

FL202
BC0
SAW

U200
SKY77742
BAND2+5

U401
APT

J1400
M_MIC
USB/RGB

Q602
开关管

J700
EARPHONE

S706


U802
EMMC
8G

U800/U801
MSM8628
CPU/RAM

U600
PM8226
PMU

U1501
振动IC

Q601
开关管



J1101
TP_
CONNECT

U1500
G/GSENSOR

U400
WCN3620
FM/BT/WiFi

J1200
M_CAMERA
_CONNECT

FL1201
EMI

U1502
ISA1000
COMPASS

FL501
GPS_SAW

FL400
WL_SAW

U501
GPS放大


FL502
GPS_SAW

J1201
ALS/SPK
SCAM_CON

FL1202
EMI

J1100
LCD_CON

H2AC一、二级框图



H2AC三级框图

