




# SM-A730F/DS Block Diagram








## 8. Level 3 Repair

### 8-3. Flow chart of Troubleshooting.




Oscilloscope




Digital Multimeter



Power Supply



+ driver, ESD Safe Tweezer




8960 & Spectrum Analyzer



Soldering iron

## 8. Level 3 Repair

### 8-4-1. Power On




---

## 8. Level 3 Repair

---

### 8-4-2. Initial




---

## 8. Level 3 Repair

---

### 8-4-3. SIM Part




---

## 8. Level 3 Repair

---

### 8-4-4. T-Flash Part




---

## 8. Level 3 Repair

---

### 8-4-5. Charging Part




---

## 8. Level 3 Repair

---

### 8-4-6. OTG




---

## 8. Level 3 Repair

---

### 8-4-7-1. Magnetic Sensor




---

## 8. Level 3 Repair

---

### 8-4-7-2. Accel & GYRO Sensor




---

## 8. Level 3 Repair

---

### 8-4-7-3. Proximity + RGB Light sensor




---

## 8. Level 3 Repair

---

### 8-4-7-4. Hall Sensor




---

## 8. Level 3 Repair

---

### 8-4-8-1. Microphone Part - Main MIC




---

## 8. Level 3 Repair

---

### 8-4-9. Speaker Part




---

## 8. Level 3 Repair

---

### 8-4-10. Receiver Part




---

## 8. Level 3 Repair

---

### 8-4-11. BT/WIFI




---

## 8. Level 3 Repair

---

### 8-4-12. GPS




---

## 8. Level 3 Repair

---

### 8-4-13. NFC




---

## 8. Level 3 Repair

---

### 8-4-14. Display




---

## 8. Level 3 Repair

---

### 8-4-15. Rear CAMERA




---

## 8. Level 3 Repair

---

### 8-4-16. Front CAMERA




---

## 8. Level 3 Repair

---

### 8-4-17.Finger Print




---

## 8. Level 3 Repair

---

### 8-4-18. Motor




---

## 8. Level 3 Repair

---

### 8-4-19. MST




---

## 8. Level 3 Repair

---

### 8-4-20. 2G QUAD WCDMA B1/2/5/8, LTE B1/2/3/4/5/8/12(17)/13/20/28/66 PRx




---

## 8. Level 3 Repair

---

### 8-4-21. LTE B 7/38/40/41 PRx/Tx




---

## 8. Level 3 Repair

---

### 8-4-22. 2G QUAD WCDMA B1/2/5/8 LTE B1/2/3/4/5/8/12(17)/13/20/28/66 Tx



---

## 8. Level 3 Repair

---

### 8-4-23. 2G QUAD WCDMA B1/2/5/8 LTE B1/2/3/4/5/7/8/12/13/20/26/28/38/40/41 DRx

