













iPhone各机型开机引脚




iPhone 13 mini




iPhone 13




iPhone 13 Pro



iPhone 13 Pro max



iPhone14 & iPhone14 Plus



iPhone14Pro & iPhone14ProMax

