

Upper antenna 1 上天线1	0	0	0	0	404	0	0
	430	359	291	748	747	747	747

Upper antenna 2 上天线2	0	0	0
	640	404	745

Dot matrix projector
点阵投影器

J4500		
514		318
520		359
0		370
359		764
716		698

Receiver sensitivity
听筒感光

J4600		
680		712
402		711
363		403
718		369
0		510
0		512
0		512
0		512
0		369
290		481
781		369
590		779
590		437
590		437

Front camera
前摄像头

J4200		
359		664
292		0
0L		359
697		0
0		0L
365		0L
427		0
0L		0L
0		0L

Infrared receiving connector
红外接收连接器

J4530		
0		725
460		0L
460		696
0		0
482		292
482		364
0		358
482		358
482		391

Wide angle camera base
广角摄像头座子

J3900	360	360	0	535	294	700	439	0	0L	0L	0	0L	0L
	614	561	0	599	0	0L	365	0	0L	0L	0	0L	620

测量设备：福禄克115C
Measuring equipment: fluke 115C

Tail socket
尾插座

J5400		
587		777
587		0
778		678
0		709
0L		472
709		442
366		0
366		0L
0		709
673		89
709		0
357		676
814		675
402		674
288		674
434		0
360		585
429		585
0		776
586		389
586		389
777		389

long-focus
长焦

J4000		
0		696
0		692
292		0
697		0
0L		427
364		0L
0		0L
358		0
358		0L
539		0L
0L		0
664		0L
0		0L

Boot flash
开机闪光灯

J4300		
367		646
367		584
678		617
0L		781
711		782
711		0

touch
触摸

0		0L
660		643
0		519
0		368
663		371
372		374
371		406
369		371
371		370
372		704
372		645
439		600
367		368
664		0

Lower antenna pedestal
下部天线座

JLAT-A		
0		0
743		0
740		745
741		742
742		0
0		479
288		0
370		0
427		0
402		0

Battery holder
电池座

J3200		
0		728
728		429

Wireless charging volume key
无线充电音量键

J3500		
0L		0
642		367
868		366
0L		369