


Redmi note4 does not read the card


Maintenance process:Switch of the card slot was found in the test, and it was in a thousand-closed state when the card was put in or not.



Under normal circumstances, put in the card, and the shrapnel of Switch will be separated, and one corner will be measured to 1.8v VCC.



normal, and the fault is solved!



Redmi note4 component labeling distribution diagram

